

**AC Servo System
TSTA series
Install Operate Manual**

TECO 




**Driving &
Connecting Globally**



سازنده انواع ماشین آلات صنعتی و ماشین مخصوص

WWW.CNCREZA.IR

■ Warning and Caution :



Warning

- ☒ Do not proceed to the assembly of the line while electrifying.
- ☒ circuit & change components between entering shutting down the power supply and stopping showing CHARGE LED light of the Servo driver.
- ☒ The output of Servo driver [U, V, W] must not touch the AC power.



Caution

- ☒ Install the fan if the temperature around is too high while the Servo driver is installed in the Control Board.
 - ☒ Do not proceed to the Anti-Pressure-Test to the Servo driver.
- Confirm if the urgent
Matching up machine to change the user parameter setting before machine performs. If there is no according correct setting number, it could lead to out of control or breakdown.

■ Safety proceeding :

Check the covering letter detail before installing, running, maintaining and examining. Furthermore, only the profession-qualified people can proceed to the line-assembly.

Safety proceeding in the covering letter discriminate between “Warning”&”Caution”.



Indicating the possibility dangerous situation. It could cause the death or serious damage if being ignored.



Indicating the possibility dangerous situation. It could cause smaller or lighter human injured and damage of equipment.

Read this covering letter detail before using Servo driver.

Fist of all, thank you for using TECO Servo Driver TSTA Series (“TSTA” for short) and Servo Motors.

TSTA can be controlled by digital board or PC, and provide excellent performance for a wide range of applications and different requirement from customers.

Read this covering letter before using TSTA. Contents of the letter comprises:

☒ Servo System checking, installing and procedure of assembly line. ☒

Controller procedure for digital board, status displaying, unusual alarm and strategy explanation.

☒ Servo System control function, running testing and procedures adjusted.

☒ Explanation for all parameter of Servo Driver.

☒ Standard specification of TSTA Series.

In order to daily examine, maintain and understand the reason of unusual situation and handle strategy, please put this covering letter in safe place to read it anytime.

P.S: The end user should own this covering letter, in order to make the Servo Driver bring the best performance into full play.

Contents

Chapter 1 Unpacking Check and Installation

1-1 Unpacking Check 1-1

1-1-1 Check the Model of Servo Drive.....	1-1 1-
1-2 Check the Model of Servo Motor	1-2
1-1-3 Synopsis of Servo Drives and Motors.....	1-2 1-2
Parts Description of Servo Drive.....	1-3 1-3
Control Modes of Servo Drive.....	1-4
1-4 Installation and Storage of Servo Drive	1-5 1-
4-1 Storage Conditions	1-5
1-4-2 Mounting Direction and Space Requirements	1-6
1-5 Install-Conditions and Method of Servo Motor.....	1-7
1-5-1 Installation and Storage Conditions	1-7
1-5-2 Installation.....	1-7
1-5-3 Other Hints.....	1-8

Chapter 2 System Configuration and Wiring

2-1 Configuration and Wiring	2-1-
1 General Wiring Diagram.....	2-1-2
Wiring Description for Servo Drive.....	2-1-3 Wire
Specifications	
2-1-4 Motor Terminal	2-
1-5 Standard Wiring-Pictures for Motor and Power.....	2-1-6
Description for TB Terminal	2-1-7
Description for Wiring of Motor with BRAKE.....	2-2 I/O
Description for Signal Terminal.....	2-2-1
Description for CN1-Control-Signal Terminal	2-2-2
Description for CN2-Encoder-Signal Terminal.....	2-3
Standard Wiring Picture for Control-Signal Terminal.....	2-3-
1 Wiring Picture (Line Driver) of Position Control (Pe Mode).	2-3-2
Wiring Picture (Open collector) of Position Control (Pe Mode).....	2-3-3

Wiring Picture of Position Control (Pi Mode).....	2-3-4
Wiring Picture of Speed Control (S Mode).	
2-3-5 Wiring Picture of Torque Control.	

Chapter 3 Description of the Faceplate Control

3-1 Description of Driver-Faceplate.....	3-2
Description of Signal-Display of Faceplate.....	3-2-1
Description of Status-Display Function.....	
3-2-2 Description of Diagnosis Function.	

Chapter 4 Description of Running Operation Testing

4-1 Running Test of non-Load Servo Motor.	4-2
Test Rotating of Motor(no-loaded) with Host controller	
4-3 Test Rotating of Motor(loaded) with Host controller.....	

Chapter 5 Control Function

5-1 Selection of Control Mode.....	5-2
Torque Mode.....	
5-2-1 Ratio of Analog Torque Command.....	
5-2-2 Departure Adjustment of Analog Torque Command	
5-2-3 Lineal Acceleration/Deceleration of Torque Command	
5-2-4 Directional Definition of Torque Output.....	
5-2-5 Limit Setting of Inside Torque	
5-2-6 Speed Limit of Torque Mode.....	
5-3 Speed Mode.....	
5-3-1 Selection of Speed Command	5-
3-2 Ratio of Analog Speed Command.....	5-
3-3 Departure Adjustment of Analog Speed Command.....	5-
3-4 Limit of Analog Speed Command	

5-3-5 Encoder Output	
5-3-6 Smoothness Adjustment of Speed Command.....	5-
3-7 Definition of Speed Turning-Direction.....	5-3-8
Tone up of Speed Loop.....	5-3-9
Notch Filter	5-3-10
Torque Limit of Speed Mode.....	5-3-11
Gain Switching Function.....	5-3-12
Other Function of Speed Control.....	5-4
Position Mode.....	5-4-
1 Outside Pulse Wave Command Mode.....	5-4-2
Inside Location Command Mode	5-4-3
Proportion of Electronic Gear	5-4-4
Position Command: 1-time smooth ac/deceleration	5-4-5
Definition of Location – Command Direction.....	5-4-6
Toning up Adjustment of Location Loop.....	5-4-7
Elimination of Pulse Wave - Error.....	5-4-8
Origin Return	5-4-9
Other Function of Location Control.....	5-5
Servo Toning up Adjustment.....	5-5-
1 Automatic Tone up Adjustment	5-5-2
Man-Made Tone up Adjustment.....	5-5-3
Improvement of Response Characteristic.....	5-6
Other Functions.....	5-6-
1 Function Formulating of Input/Output Contact.....	5-6-2
Switching of Control Mode.....	5-6-3
Function of Contact Assistance.....	5-6-4
Brake Mode.....	5-6-5
Mechanical Braking Timing.....	5-6-6
Method of CW/CCW Drive Forbidding	5-6-7

Selection of Outside Reviving Resistor.....	5-6-8
Setting of Fan Running.....	5-6-9
Analog Monitor.....	
5-6-10 Parameter Reset.....	

Chapter 6 Parameters

6-1 Parameter Groups and Listing.....	6-1
6-2 Parameters Summary	6-2

Chapter 7 Communication Function

7-1 Communication Function (RS232).....	7-1-
1 Communication Wiring	7-1-2
Communication Protocol and Form	7-2
Communicate Location for each Parameter	

Chapter 8 Troubleshooting

8-1 Fault Status Display Operation	8-1
8-2 Fault Definition and Corrective Actions.....	8-3

Chapter 9 Compositive Standard

9-1 Detailed Standards and Model of Servo Driver	9-2
Detailed Standards and Model of Servo Motor.....	

Appendix A Motor-Accessory.....

Chapter 1 Unpacking Check and Installation

1-1 Unpacking Check

Our Servo Pack have already completely been functionally examined before leaving the factory. In order to protect the products from the damage during transportation, please check the items below before sealing off the pack:

Check if the models of servo driver and motor are the same with the models of ordering.

(About the model explanation, please check the chapters below)


Check if there are damage or scrape out side of the servo driver and motor.

(If there is any damage during transportation, do not power ON) Check if there are any bad assembly or slipped component in the Servo Drive and Motor Check if the Motor's rotor and shaft can be rotated smoothly by hand

(The Servo Motor with Mechanical-Brake can not be rotated directly) There must be the "QC"-seal in each servo drive, if not, please do not proceed Power ON.

If there is any bug or irregular under the situation above, please contact TECO's Local sales representative or distributor instantly.

1-1-1 Check the Model of Servo Drive



Note Max. Output Power

15 400 W 50 2 KW

Drive Model :


20 : 750 W 75 : 3 KW

30 : 1 KW

1-1-2 Check the Model of SERVO Motor

TS series :

TS B 08 751 C 2 N H 3 1 0 1



CB, CC, MB series :

7 CB 30 ⑤

C

- 2 D E 7

Frame :
CB series :
 5 : 54 mm
 7 : 76 mm
 8 : 87 mm
CC series :
 6 : 60 mm
 8 : 80 mm
MB series :
 3 : 130 mm

Motor Series :
 CB : CB series
 CC : CC series
 MB : MB series

Motor ratio power :
CB series :
 12 : 120 W
 30 : 300 W
 75 : 750 W
CC series :
 201 : 200 W
 401 : 400 W
 751 : 750 W
MB series :
 100 : 1 KW
 150 : 1.5 KW
 200 : 2 KW
 300 : 3 KW

Motor Speed :
CB series :
 (rate 3000 rpm)
CC series :
 G : 3000 rpm MB series :
 A : 1000 rpm
 B : 2000 rpm
 C : 3000 rpm

AC input voltage :
 1 : Single 100V
 2 : Single 200V
 3 : Three 200V

Motor Connector :
 C : MS (MB series)
 D : AMP (CB, CC series)

Option :
 E : Encoder
 G : Encoder+Brake

Encoder :
 6 : Standard (15 lines)
 7 : Wire-saving (9 lines)
CC series :
 B : Wire-saving (9 lines)

Resolution :
 F : 2000 ppr
 H : 2500 ppr
 I : 5000 ppr
CC series :
 E : 2000 ppr

سازنده انواع ماشین آلات صنعتی و ماشین مخصوص
 WWW.CNCREZA.IR

1-1-3 Synopsis of Servo Drives and Motors


Servo Drives	TSTA 15	TSTA 20	TSTA 30	TSTA 50	TSTA 75
Applicative Servo Motors	TSB07301 7CB30	TSB08751 8CB75	TSB13102 3MB100	TSB13152 3MB150	TSB13302 3MB300
	TSC04101	TSB13551 3MB055	TSC08751 TST08751 8CC751	TSB13202 3MB200	—

	TSC06201 TST06201 6CC201	TSC06401 TST06401 6CC401	—	—	—
--	--------------------------------	--------------------------------	---	---	---


1-2 Parts Description of Servo Drive




TSTA15 / TSTA20




TSTA30



TSTA50 / TSTA75



Keypad



1-3 Control Modes of Servo Drive

There are many kinds of control-mode. The detail modes display as follow:

Name		Code	Explanation
Single Mode	Position Mode (External Pulse Command)	Pe	Position control for the servo motor is achieved via an external pulse command. Position command is entered at CN1.
	Position Mode (Internal Pulse Command)	Pi	Position control for the servo motor is achieved via by 16 commands stored within the servo controller. Execution of the 16 positions is via Digital Input signals.
	Speed Mode	S	Speed control for the servo motor can be achieved via parameters set within the controller or from an external analog -10 ~ +10 Vdc command. Control of the internal speed parameters is via the Digital Inputs. A maximum of three speeds can be stored internally.
	Torque Mode	T	Torque control for the servo motor can be achieved via parameters set within the controller or from an external analog -10 ~ +10 Vdc command.
Multiple Mode		Pe-S	Pe and S can be switched by digital-input-contact-point.
		Pe-T	Pe and T can be switched by digital-input-contact-point.
		S-T	S and T can be switched by digital-input-contact-point.



1-4 Installation and Storage of Servo Drive

1-4-1 Installation and Storage Conditions

The product should be kept in the shipping carton before installation. In order to retain the warranty coverage, the AC drive should be stored properly when it is not to be used for an extended period of time. Some storage suggestions are:

- ☒ Ambient Temperature: 0 ~ + 55 °C; Ambient Humidity: Under 85% RH (Under the condition of no frost).
- ☒ Stored Temperature: - 20 ~ + 85 °C; Stored Humidity: Under 85%RH (Under the condition of no frost).
- ☒ Vibrating: Under 0.5 G.
- ☒ Do not mount the servo drive or motor in a location where temperatures and humidity will exceed specification.
- ☒ To avoid the insolation. ☒ To avoid the erosion of grease and salt. ☒ To avoid the corrosive gases and liquids. ☒ To avoid the invading of airborne dust or metallic particles.
- ☒ When over 1 Drives are installed in control panel, enough space have to be kept to get enough air to prevent the heat; the fan also must be installed, to keep the ambient temperature under 55 °C.
- ☒ Please Install the drive in a vertical position, face to the front, in order to prevent the heat.
- ☒ To avoid the tailing or other unnecessary things falling into the drive when installing.
- ☒ The drive must be stable by M5 screws.
- ☒ When there were the vibrating items nearby, please using vibration-absorber or installing anti-vibration- rubber, if the vibration can not be avoided.
- ☒ When there is any big-size magnetic switch, welding machines or other source of interference. Please install the filter. When the filter is installed, we must install the insulation transformer..

1-4-2 Mounting Direction and Space Requirements



سازنده انواع ماشین آلات صنعتی و ماشین مخصوص

WWW.CNCREZA.IR

1-5 Installation and Storage of Servo Motor

1-5-1 Installation and Storage Conditions ☒ Ambient Temperature: 0 ~ + 40 °C;

Ambient humidity: Under 90% RH (No Frost). ☒ Storage Temperature: - 20 ~ + 60 °C;


Storage temperature: Under 90%RH (No Frost). ☒ Vibration: Under 2.5 G. ☒ In a well-ventilated and low humidity and dust location.

☒ Do not store in a place subjected to corrosive gases, liquids, or airborne dust or metallic particles. ☒ Do not mount the servo motor in a location where temperatures and humidity will exceed specification.

☒ Do not mount the motor in a location where it will be subjected to high levels of electromagnetic radiation.

1-5-2 Installation

1. Horizontal Install: Please let the cable-cavity downside to prevent the water or oil or other liquid flow into the servo motor.




2. Vertical Install: If the motor shaft is side-up installed and annex to the reduction, it is necessary to attend the oil from the reduction gear flowing into the motor by way of the motor shaft.


1-5-3 Other Hints

1. Please using oil-seal-motor to avoid the oil from reduction gear flowing into the motor by way of the motor shaft.

2. The cable need to keep dry.
3. Please fixing the wiring cable certainly, to avoid the cable ablating or breaking.
4. The extending length of the shaft shall be enough, if not, there will be the vibration from motor operating.




- 5, Please do not beat the motor when installing or taking it apart. Otherwise the shaft and the encoder of backside will be damaged.



Chapter 2 System Configuration and Wiring

2-1 Configuration and Wiring

2-1-1 General Wiring Diagram



2-1-2 Wiring Description for Servo Drive

- ☒ The wire material must go by "Wiring Specifications." ☒
- Input Wire: Less than 3m.

Wiring Length: Command

Encoder Input Wire: Less than 20m. The

Wiring goes by the shortest length.

- ☒ Please wire according to the standard wiring schema. Don't connect if no using.
- ☒ Motor output terminal (U、V、W) must be connected correctly. Otherwise the servo motor will abnormally function.
- ☒ Shielded cable must be connected to FG terminal. ☒ Don't install the capacitor or Noise Filter at the output terminal of servo drive.
- ☒ At the control-output-signal relay, the direction of surge arrestor's diode must be correctly connected, otherwise it can not output signal, and cause the protect loop of emergency-stop abnormal.
- ☒ Please do these below to avoid the wrong operation from noise:

Please install devices such as the insulated transformer and noise filter at the POWER.

Keep more than 30 cm between Power wire (power wire or motor wire...etc.) and signal wire, do not install them in the same conduit. ☒ Please set "emergency-stop switch" to prevent abnormal operation.

- ☒ After wiring, check the connection-situation of each joint (ex: loose soldering, soldering point short, terminal order incorrect...etc.). Tighten the joints to confirm if surly connected to the servo drive, if the screw is tight. There can not be the situations such as cable break, cable pulled and dragged, or be heavily pressed.

※ Especially pay attention to the polarity between servo motor wiring and encoder.

- ☒ There is no necessary to add extra regeneration resistance under general situation. If there is any need or problem, please connect to distributor or manufacturer.

2-1-3 Wire Specifications

Connection Terminal			Wire Specifications				
Terminal	Symbol	Name	JSDA-15	JSDA-20	JSDA-30	JSDA-50	JSDA-75
Main Circuit	R、S、T	Main Power Input	2.0mm ² A.W.G.14	2.0mm ² A.W.G.14	2.0mm ² A.W.G.14	2.0mm ² A.W.G.14	3.5mm ² A.W.G.12

	U, V, W	Motor Connection	2.0mm ² A.W.G.14	2.0mm ² A.W.G.14	2.0mm ² A.W.G.14	2.0mm ² A.W.G.14	3.5mm ² A.W.G.12	
	r, s	Control Power Input	1.25mm ² A.W.G.16	1.25mm ² A.W.G.16	1.25mm ² A.W.G.16	1.25mm ² A.W.G.16	1.25mm ² A.W.G.16	
	FG \perp	Ground	2.0mm ² A.W.G.14	2.0mm ² A.W.G.14	2.0mm ² A.W.G.14	2.0mm ² A.W.G.14	3.5mm ² A.W.G.12	
Terminal	Symbol	Name	JSDA-15	JSDA-20	JSDA-30	JSDA-50	JSDA-75	
CN1 I/O Control Signal	26,27,28	Speed/Torque Command Input	0.2mm ² or 0.3mm ² -> Twisted-pair-cable connecting to the Analog Grounding wire (including shield cable)					
	30,31	Analog Monitor Output						
	33,34	Power Output +15V & -15V						
	29,32,44	Analog Ground Terminal	0.2mm ² or 0.3mm ² -> Twisted-pair-cable connecting to the I/O Grounding wire (including shield cable)					
	1~13	General Analog Input						
	18~25,43	General Analog Output						
	45,46, 48,49	24V Power & I/O Ground	0.2mm ² or 0.3mm ² -> Twisted-pair-cable (including shield cable)					
	14~17	Position Command Input						
	35~40	Encoder Signal Output						
CN2 Motor encoder	1,2	Output 5V	0.2mm ² or 0.3mm ² -> Twisted-pair-cable (including shield cable)					
	3,4	Output Grounding wire of power supply						
	5~18	Encoder Signal Input						
Communi- cation	2,3	Data transfer & receive	0.2mm ² or 0.3mm ² -> Twisted-pair-cable (including shield cable)					
	5	Communication grounding wire						
	1,4,6,8	Floating	—					

P.S.: 1. Please pay attention to the NFB and the capacity of noise filter when using multi ServoDrives.

2. CN1 ->50 Pins (3M Co.)

3. CN2 -> 20 Pins (3M Co.)

4. RS232 -> 9 Pins D-type Joint.




2-1-4 Motor Terminal Wiring

A Table of Motor-Terminal Wiring


(1) General Joint:

Terminal Symbol	Color	Signal
1	Red	U
2	White	V
3	Black	W
4	Green	FG
Brake control wire	Fine red	DC +24V
	Fine yellow	0V




(2) Military Specifications Joint(No Brake):

Terminal	Color	Signal
A	Red	U
B	White	V
C	Black	W
D	Green	FG



(3) Military Specifications Joint(Brake) :

Terminal	Color	Signal
B	Red	U
I	White	V
F	Black	W
E	Green	FG
A	Fine red	DC +24V




C	Fine yellow	BK control wire	0V
---	-------------	-----------------	----

P.S.: The military joint with BK of servo motor has 9 Pins; and the encoder joint has also 9 Pins. Please confirm before wiring.


2-1-5 Standard Diagram of Motor and Power

* The Wiring Example of Single Phase Main Power (Less than 1KW)



WWW.CNCREZA.IR

* The Wiring Example of 3 Phase Main Power (More than 1KW)



2-1-6 TB Terminal



Name	Terminal Sign	Detail
Control-loop power input terminal	r	Connecting to external AC Power. Single Phase 200~230VAC +10 ~ -15% 50/60Hz ±5%
	s	
Main-loop power input terminal	R	Connecting to external AC Power. Single / 3 Phase 200~230VAC +10 ~ -15% 50/60Hz ±5%
	S	
	T	
External regeneration resistance terminal	P	Please refer to Cn012 to see resistance value, when using external regeneration resistance. After installing regeneration resistance, set the resistance power in Cn012 .

Regeneration terminal common point	PC	<p>*If no using external regeneration resistance, PC-P1 need be close, P doesn't be connected.</p> <p>*When using external regeneration, add regeneration resistance between PC-P, P1 doesn't be wired.</p>
Internal regeneration resistance terminal	P1	
Motor-power output terminal	U	Motor terminal wire is red
	V	Motor terminal wire is white
	W	Motor terminal wire is black
Motor-case grounding terminal	FG	Motor terminal wire is green or yellow-green.

2-1-7 BRAKE Wiring


Uninstall BRAKE:

- ⌘ 200/300/400/750W series: Use Red wire and yellow wire connecting to DC +24V voltage (**No polarity**)
- ⌘ 550/1K/1.5K/2K/3KW series: BK outputs from A & C of **Motor Power Joint**, servo motor can operate normally after uninstalling.



2-2 I/O Signal Terminal

There are 3 groups of I/O terminal, which contain RS232 communication terminal, CN1 control signal terminal and CN2 encoder terminal. The diagram below displays all positions for the terminal.



2-2-1 CN1 Signal Terminal

(1) Diagram of CN1 Terminal:

Position Number	Name	Function									
			1	DI-1	Servo ON				26	SIN	Speed/Torque Analog Command Input
2	DI-2	ALRS				27	PIC	Torque Control Speed Limit / CCW command Limit			
			3	DI-3	PCNT PLP Switch				28	NIC	CW Torque Command Limit
4	DI-4	CCWL				29	AG	Analog Signal Gound Terminal			
			5	DI-5	CWL				30	MON1	Analog Monitor Outout 1
6	DI-6	TLMT				31	MON2	Analog Monitor Output 2			
			7	DI-7	CLR				32	AG	Analog Signal Gound Terminal
8	DI-8	LOK				33	+15V	+15V PW output			
			9	DI-9	EM C				34	-15V	-15V PW Output
10	DI-10	SFD1				35	PA	Encoder output A Phase			
			11	DI-11	SFD2				36	/PA	Encoder Output / A Phase
12	DI-12	MDC				37	PB	Encoder ouput B Phase			
			13	DI-13	SFDINV				38	/PB	Encoder Output / B Phase
14	Pulse	Position Pulse Command Input(+)				39	PZ	Encoder output Z Phase			
			15	/Pulse	Position Pulse Command input(-)				40	/PZ	Encoder Output / Z Phase
16	Sign	Position Symbol Command Input(+)				41	OPC	Open Collector Position Command PW Input			
			17	/Sign	Position Symbol Command input(-)				42	—	—
18	DO-1	RDY SevoReady				43	ZO	Home Signal Output			
			19	DO-2	ALM				44	AG	Analog Signal Ground Terminal
20	DO-3	Zero Speed				45	IP24	+24V PW Output			
			21	DO-4	INP				46	IG 24	+24V PW Ground Terminal
22	DO-5	Torque Limit(LM)/ ALRS Code0 (A0)				47	DICOM	DI PW Commen Point			
			23	DO-6	PC / (A1)				48	IG 24	+24V PW Ground Terminal
24	DO-7	Drive Limit(ST) / ALRS Code2 (A2)				49	IG 24	+24V PW ground terminal			
			25	DO-8	BASE BLOCK / (A3)				50	FG	Shielded Wire Grounding

P.S.:

1. If there is unused terminal, please do not connect it or let it be the relay terminal.
 2. The Shielded Wire of I/O signal should connect to the case of connector.
- (2) CN1 Signal Name and Explanation:


(a) General I/O Signal:

Signal Function Symbol Pin No. Wired Mode Signal Function Symbol Pin No. Wired Mode

Position Pulse	Pulse	14	Encoder A-Phase Output	PA	35	
Command Input			Encoder Output /		36	
	/Pulse	15	IO3	A Phase		/PA
Position Symbol	Sign	16	Encoder B-Phase Output	PB	37	IO4
Command Input	Encoder Output	38	/Sign	17	/B-Phase	/PB
Open Collector			Encoder Z-Phase Output	PZ	39	



Position	OPC	41	IO3	Encoder /Z-Phase	Output	/PZ	40	Command PW



سازنده انواع ماشین آلات صنعتی و ماشین مخصوص

WWW.CNCREZA.IR

Input.

Speed / Torque 4		26	Analog Signal Ground Terminal	AG	29,32,4
Analog Command Input	SIN		+15Terminal V PW Output	+15V	33
Torque Control					
Speed Limit			IO5 -15V PW Output		34
Command / CCW Torque Command Limit	PIC	27	Terminal	-15V	
CW Torque		28	DI PW Conmen Terminal	DICOM	47
Command Limit	NIC				
Analog Monitor	30	+24V PW Output	IP24	45 Output 1	MON1 IO6
Analog Monitor	31	+24Ground Terminal V	OW	IG24	46,48,9 4 Output 2
	MON2				
Home Signal		43	IO2 Shielded Connect Point	Wire	FG 50
Output	ZO				

Explanation of General I/O Signal Function

Signal Name	Function Symbol	Mode	I/O Operation and Function	Chapter
Position Pulse Command Input	Pulse /Pulse	Pe	The Driver can receive 3 kinds of Command below: . (Pulse)+ (Sign) . (CCW)/ (CW)Pulse . AB Phase pulse	5-4-1
Position Sign Command Input	Sign /Sign			
Open Collect Position Command PW Input	OPC	Pe	When open collect input in position command, OPC and IP24 can be close, and using internal 24V power and resistance.	—

Speed Analog command Input	SIN	S	In Speed Mode, when, external speed command is operated at SPD1=0, SPD2=0, input the voltage range: -10V~+10V , Sn216 can be set input voltage: $\pm 10V$'s Motor output speed.	5-3-1 5-3-2 5-3-3 5-3-4
Torque Analog Command Input		T	In Torque Mode, input the voltage range -10~+10V , Tn103 can be set input voltage $\pm 10V$'s motor output torque.	5-2-15-2-2
Torque Control Speed Limit Command	PIC	T	In Torque Mode, when external speed limit is operated at input connect point SPD1=0 & SDP2=0(P.S) , input voltage range: 0~+10V , 10V's speed limit stands for motor's ratio speed.	5-2-6
CCW Torque Limit Command		S	In Speed Mode, when external torque limit is be used at input connect point TLMT=1(P.S.) , input voltage range: 0~+10V , to input 10V will limit the motor CCW torque having 300% of ratio torque.	5-3-10
CW Torque Limit Command	NIC	S	In Speed Mode, when external torque limit is be used at input connect point TLMT=1(P.S.) , input voltage range: -10~0V , to input -10V will limit the motor CW torque have 300% of ratio torque.	5-3-10
Analog Monitor Output 1	MON1	ALL	Operating the motor to control the current speed to transform the voltage output in accordance with the rate ($\pm 10V/1.5$ times ratio speed) CCW stands for positive voltage, CW negative voltage.	5-6-9
Analog Monitor Output 2	MON2	ALL	Operating the motor to control the current torque to transform the voltage output in accordance with the rate ($\pm 10V/3.5$ times ratio torque) CCW torque stands for positive voltage, CW negative voltage.	5-6-9
Encoder Output A Phase	PA	ALL	Outputting the Motor Encoder Signal through pulse per rotation handle. The pulse quantity of every rotating can be set in Cn005 . When "1" is set in Cn004 , it is CCW rotation from the motor load terminal direction, and A Phase gets 90 degree ahead B Phase. Signal Output is Line Driver.	5-3-5
Encoder Output / A Phase	/PA			
Encoder Output B Phase	PB			
Encoder Output / B Phase	/PB			
Encoder Output Z Phase	PZ			
Encoder Output / Z Phase	/PZ			
Home Signal Output	ZO	ALL	Z Phase Open Collector output connect point.	—

Analog Signal Ground Terminal	AG	ALL	Analog signal grounding: CN1 - > Pin 26、27、28、30、31、33、34.	—
+15V PW Output Terminal	+15V	ALL	To provide $\pm 15V$ output power (Max. 10mA), which can be used in servo drive – external voltage command. Suggestion: Using the variable resistance which is more than 3kΩ.	—
-15V PW Output Terminal	-15V	ALL		
DI PW Conmen Terminal	DICOM	ALL	Analog input power supplement common terminal.	—
+24V PW Output	IP24	ALL	+24V power output terminal(Max. 0.2A).	—
+24V PW Ground Terminal	IG24	ALL	+24V power grounding terminal	—
Shielded Wire Connect Point	FG	ALL	Shielded wire which connects signal wire.	—

P.S.: “1” stands for “close loop with **IG24**”; “0” stands for “open loop with **IG24**”. **(b) Digital I/O Signal:**

For many kinds of application, the digital input/output terminal layout of all operation mode are accordingly different. In order to provide more functions, our drives can provide multi terminal layout settings. Users can set these functions for application.

Digital input terminal-layout provides 12 programmable terminal layout. Digital input terminal layout provides 13 (**Pin1~13**) programmable terminal layout; digital output terminal layout provides 4 (**Pin18~21**) programmable terminal layout. The diagram below shows the default digital output/input terminal layout and functions. Please refer to 5-6-1 to check parameter settings.

Default Digital Input Terminal Layout Functions and Wired Mode

Signal		Function Sign	Pin No.	Wired Mode	Signal		Function Sign	Pin No.	Wired Mode
Servo ON	DI-1	SON	1	IO1	Servo Lock	DI-8	LOK	8	IO1
Clean Abnormal Alarms	DI-2	ALRS	2		Emergency Stop	DI-9	EMC	9	

PI/P Switch	DI-3	PCNT	3	Internal speed command / Limit select 1	DI-10	SPD1	10
CCW Operation Limit	DI-4	CCWL	4	Internal speed command / Limit select 2	DI-11	SPD2	11
CW Operation Limit	DI-5	CWL	5	Control Mode Switch	DI-12	MDC	12
External Torque Limit	DI-6	TLMT	6	Reverse Direction Speed Command	DI-13	SPDINV	13
Pulse error amount delete	DI-7	CLR	7	—			

Default Digital Input Terminal Layout Functions and Wired Mode

Signal	Function	Pin	Wired	Signal	Function	Pin	Wired
--------	----------	-----	-------	--------	----------	-----	-------

	Sign	No.	Mode	Sign	No.	Mode			
Servo ready	DO-1	RDY	18	IO2	Torque limit/ Alarm code A0	DO-5	LM/A0	22	IO2
Alarm	DO-2	ALM	19		P action / Alarm code A1	DO-6	PC/A1	23	
Zero speed	DO-3	ZS	20		Operation limit/ Alarm code A2	DO-7	ST/A2	24	
Fix position	DO-4	INP	21		Base Block/ Alarm code A3	DO-8	BB/A3	25	

Digital Input Function

(Except CCWL and CWL are high electric potential, other terminal layout are low electric potential. Please refer to 5-6-1 to see related parameters)

Signal Name	Function Sign	Mode	I/O Function	Chapter
Servo On	SON	ALL	SON and IG24 close loop: Servo ON ; SON and IG24 open loop: Servo OFF. Attention: Before power on, the input connect point SON (servo on) can not be operated to avoid danger.	5-6-3 5-6-4
Abnormal Reset	ALRS	ALL	ALRS and IG24 close loop: Relieving the stop-situation from of abnormality. But the abnormality of encoder or memory will cause the same alarm again. Please reset power after the abnormality is eliminated.	8-1
PI/P switch	PCNT	Pi/Pe/S	PCNT and IG24 close loop will cause the speed loop control transforming to ratio control from ratio integration control.	5-3-1 1
CCW Operation limit	CCWL	ALL	Connect to CCW over travel detector: CCWL and IG24 close loop; open loop with IG24 -> CCW over travel operates.	5-4-8 5-6-3 5-6-4
CW Operation limit	CWL	ALL	Connect to CW over travel detector: CWL and IG24 close loop; open loop with IG24 -> CW over travel operates.	5-4-8 5-6-3 5-6-4
External torque limit	TLMT	Pi/Pe/S	TLMT and IG24 close loop will cause the motor-output-torque-limit to stay in the command-voltage range of torque-limit-terminal-layout (PIC 、 NIC).	5-3-1 0
Pulse error amount delete	CLR	Pi/Pe	When CLR and IG24 close loop, delete the pulse amount in the Position Error Counter.	5-4-7
Servo lock	LOK	S	When LOK and IG24 close loop will transform speed control mode into position control mode in order to lock the motor at the last position.	5-3-1 2
Emergency stop	EMC	ALL	When EMC and IG24 close loop: Emergency stop -> Servo Off and exit the rotating statue, and Cn008 will decide if the dynamic Brake operates.	5-6-4

Internal speed command / limit select 1 Internal speed command / limit select 2	SPD1 SPD2	S/T	Internal speed setting and limit:				5-2-6 5-3-1
			SPD 2	SPD 1	Speed Command (Speed Mode)	Speed Limit Command (Torque Mode)	
			0	0	External command(SIN)	External limit(PIC)	
			0	1	Sn201	Tn105	
			1	0	Sn202	Tn106	
			1	1	Sn203	Tn107	
<p>“1”: Close loop with IG24 “0”: Open loop with IG24</p>							



Digital Input Function Explanation

(Except CCWL and CWL are the high electric potential, other terminal layout are the low electric potential, please refer to 5-6-1 to check related parameters setting)

Signal Name	Function Symbol	Mode	I/O Function	Chapter															
Control Mode Switch	MDC	Pe/S/T	When MDC and IG24 close loop, current control mode will transform into default control mode, please refer to Cn001 .	5-1 5-6-2															
Position Command Limit	INH	Pe	When INH and IG24 close loop, position command input does not operate (do not accept external pulse command).	5-4-1															
Speed Command Counter Wise	SPDINV	S	When SPDINV and IG24 close loop in speed mode, setting rotating speed will become counter-wise rotating speed.	5-3-7															
Gain Select	G-SEL	Pi/Pe/S	When G-SEL and IG24 close loop, first stage control gain switch to the second control gain.	5-3-11															
Electric Gear ratio Numerator 1~2	GN1 GN2	Pi/Pe	Electric gear ratio: select explanation: <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>GN2</th> <th>GN1</th> <th>Electric Gear Ratio</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Pn302</td> </tr> <tr> <td>0</td> <td>1</td> <td>Pn303</td> </tr> <tr> <td>1</td> <td>0</td> <td>Pn304</td> </tr> <tr> <td>1</td> <td>1</td> <td>Pn305</td> </tr> </tbody> </table> <p>"1": Close loop with IG24 "0": Open loop with IG24</p>	GN2	GN1	Electric Gear Ratio	0	0	Pn302	0	1	Pn303	1	0	Pn304	1	1	Pn305	5-4-3
GN2	GN1	Electric Gear Ratio																	
0	0	Pn302																	
0	1	Pn303																	
1	0	Pn304																	
1	1	Pn305																	
Internal Position Command Trigger	PTRG	Pi	When PTRG and IG24 close loop (positively-triggered), the motor will select related position command to operate in accordance with the terminal layout POS1~POS4 .	5-4-8															
Internal Position Command Hold	PHOLD	Pi	When PHOLD and IG24 close loop(positively-triggered), the motor will stay holding.	5-4-8															
Home	SHOME	Pi/Pe	When SHOME and IG24 close loop(positively-triggered), HOME function operates	5-4-8															
External Origin	ORG	Pi	When ORG and IG24 close loop(positively-triggered), server will use this as external reference point for home position returning.	5-4-8															

Digital Input Function Explanation

(Except CCWL and CWL are the high electric potential, other terminal layout are the low electric potential, please refer to 5-6-1 to check related parameters setting)

Signal Name	Function Symbol	Mode	I/O Function	Chapter																																																																																					
Internal Position Command select 1~4	POS1 POS2 POS3 POS4	Pi	Internal position command select explanation:	5-4-2																																																																																					
			<table border="1"> <thead> <tr> <th>POS4</th> <th>POS3</th> <th>POS2</th> <th>POS1</th> <th>Selection of Pn</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>Pn317, Pn318</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> <td>1</td> <td>Pn320, Pn321</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>0</td> <td>Pn323, Pn324</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>1</td> <td>Pn326, Pn327</td> </tr> <tr> <td>0</td> <td>1</td> <td>0</td> <td>0</td> <td>Pn329, Pn330</td> </tr> <tr> <td>0</td> <td>1</td> <td>0</td> <td>1</td> <td>Pn332, Pn333</td> </tr> <tr> <td>0</td> <td>1</td> <td>1</td> <td>0</td> <td>Pn335, Pn336</td> </tr> <tr> <td>0</td> <td>1</td> <td>1</td> <td>1</td> <td>Pn338, Pn339</td> </tr> <tr> <td>1</td> <td>0</td> <td>0</td> <td>0</td> <td>Pn341, Pn342</td> </tr> <tr> <td>1</td> <td>0</td> <td>0</td> <td>1</td> <td>Pn344, Pn345</td> </tr> <tr> <td>1</td> <td>0</td> <td>1</td> <td>0</td> <td>Pn347, Pn348</td> </tr> <tr> <td>1</td> <td>0</td> <td>1</td> <td>1</td> <td>Pn350, Pn351</td> </tr> <tr> <td>1</td> <td>1</td> <td>0</td> <td>0</td> <td>Pn353, Pn354</td> </tr> <tr> <td>1</td> <td>1</td> <td>0</td> <td>1</td> <td>Pn356, Pn357</td> </tr> <tr> <td>1</td> <td>1</td> <td>1</td> <td>0</td> <td>Pn359, Pn360</td> </tr> <tr> <td>1</td> <td>1</td> <td>1</td> <td>1</td> <td>Pn362, Pn363</td> </tr> </tbody> </table>		POS4	POS3	POS2	POS1	Selection of Pn	0	0	0	0	Pn317, Pn318	0	0	0	1	Pn320, Pn321	0	0	1	0	Pn323, Pn324	0	0	1	1	Pn326, Pn327	0	1	0	0	Pn329, Pn330	0	1	0	1	Pn332, Pn333	0	1	1	0	Pn335, Pn336	0	1	1	1	Pn338, Pn339	1	0	0	0	Pn341, Pn342	1	0	0	1	Pn344, Pn345	1	0	1	0	Pn347, Pn348	1	0	1	1	Pn350, Pn351	1	1	0	0	Pn353, Pn354	1	1	0	1	Pn356, Pn357	1	1	1	0	Pn359, Pn360	1	1	1	1	Pn362, Pn363
			POS4		POS3	POS2	POS1	Selection of Pn																																																																																	
			0		0	0	0	Pn317, Pn318																																																																																	
			0		0	0	1	Pn320, Pn321																																																																																	
			0		0	1	0	Pn323, Pn324																																																																																	
			0		0	1	1	Pn326, Pn327																																																																																	
			0		1	0	0	Pn329, Pn330																																																																																	
			0		1	0	1	Pn332, Pn333																																																																																	
			0		1	1	0	Pn335, Pn336																																																																																	
			0		1	1	1	Pn338, Pn339																																																																																	
			1		0	0	0	Pn341, Pn342																																																																																	
			1		0	0	1	Pn344, Pn345																																																																																	
			1		0	1	0	Pn347, Pn348																																																																																	
			1		0	1	1	Pn350, Pn351																																																																																	
1	1	0	0	Pn353, Pn354																																																																																					
1	1	0	1	Pn356, Pn357																																																																																					
1	1	1	0	Pn359, Pn360																																																																																					
1	1	1	1	Pn362, Pn363																																																																																					
			"1": close loop with IG24																																																																																						
			"0": open loop with IG24																																																																																						
Torque Command Counter Clock Wise	TRQINV	T	When TRQINV and IG24 close loop in torque mode, setting torque command output wise becomes counter wise output.	5-2-4																																																																																					

Digital Output Function Explanation

(The terminal layout here from this explanation are all the low electric potential, please refer to 5-6-1 to check parameter settings)

Signal Name	Function Symbol	Mode	I/O Function	Chapter
Servo Ready	RDY	ALL	Main power and control power input are normal. Under the situation of no alarm, terminal layouts RDY and IG24 close loop.	—


Alarm	ALM	ALL	If normally operates, the terminal layouts ALM and IG24 open loop. When alarm occurs, protection-function operates, the terminal and IG24 close loop.	—
Zero Speed	ZS	S	When the motor speed is less than the speed from Sn215 , the terminal layout ZS and IG24 close loop.	5-3-12
BK Signal	BI	ALL	When Cn008 is set “1” or “3” and the servo on, the terminal layout BI and IG24 close loop; when servo off , terminal layout and IG24 open loop. (When this terminal layout is generally applied, it is the Brake relay, which is connected to control motor).	5-6-4 5-6-5
In Speed	INS	S	When the motor speed has achieved the setting speed from Cn007 , INS and IG24 close loop.	5-3-12
In Position	INP	Pi/Pe	When the amount of position error counter is less than the amount range which is set in Pn307 , INP and IG24 close loop.	5-4-9
Home	HOME	Pi/Pe	When HOME is accomplished, HOME and IG24 close.	5-4-8
Limiting Torque/ Alarm No. 0	LM/A0	ALL	When motor output torque is limited by internal torque limit amount (Cn010&Cn011) or external torque limit command (PIC&NIC). LM/A0 and IG24 close loop. When alarm occurs, this terminal layout is alarm code output A0 .	8-1
P in Action / Alarm No.1	PC/A1	Pe/Pi/S	When speed loop is ratio(P)-control, PC/A1 and IG24 close loop. When alarm occurs, this terminal layout is alarm code output A1 .	8-1
Server in Limiting/ Alarm No.2	ST/A2	ALL	When CCW or CW operation-limit occurs, ST/A2 and IG24 close loop. When alarm occurs, this terminal layout is alarm code output A2	8-1
Base Block 中/ Alarm No.3	BB/A3	ALL	When servo motor has not be operated, BB/A3 and IG24 close loop. When alarm occurs, this terminal layout is alarm code output A3	8-1

(3) CN1 Interface Circuit and Wire Mode:

The diagram below introduces all interface circuit of CN1 and wire-method of host controller.

(a) Digital input interface circuit (IO1):


Digital input interface circuit can be operated by relay or collector transistor circuit. The relay should be the low electric current, in order to avoid the faulty contacting. External voltage: 24V.



Digital Output Interface Circuit (IO2):

When using external power, please attention to the power polarity. Adverse polarity will case damage. Digital output is "Open Collector". The maximum of external voltage is 24V; and the maximum electric current is 12mA.








سازنده انواع ماشین آلات صنعتی و ماشین مخصوص

WWW.CNCREZA.IR

(b) Pulse Command Input Interface Circuit(**IO3**):

Suggesting to use the input method of Line Driver to send the pulse command. The maximum input command frequency is 500kpps. Using the input method of Open Collector will cause the decrease of input command frequency, the maximum input command frequency is 200kpps. The server provides only 24V power, and other power should be prepared. Adverse polarity of power will cause the server damage. The maximum of External power (V_{cc}) is 24V limited. Input current is about 8~15mA. Please refer to the examples below to select resistance. Please refer to 5-4-1 to check pulse input command timing.




(Line Driver)	(Open Collector)		
<p>The max pulse command by differential input</p>  <p>line driver frequency is 500kpps</p>	 <p>Maximum input command frequency of open collector is 200kpps</p>		
<p>Open Collector (Internal 24V)</p>	<p>Open Collector – Selection of Resistance Example</p>		
 <p>The maximum input command frequency of open collector is 200kpps</p>	<p>External Power Vcc=24V R=2KΩ</p>	<p>External Power Vcc=12V R=750Ω</p>	<p>External Power Vcc=5V R=100Ω</p>

(c) Encoder Output Interface Circuit (IO4):

Encoder output interface circuit is the output method of Line Driver, please let end terminal resistance ($R=200\sim 330\Omega$) connect to Line Receiver input terminal.

Encoder Output Interface Circuit (Line Driver)




(d) Analog Input Interface Circuit(105):

There is sometimes ripple inside the server internal power. Adverse external power polarity will cause server damage. Maximum external power voltage (V_c) should be less than 12V; terminal input voltage should not more than 10V. Over voltage will cause damage. When using internal power of server, user need to choose the resistance (suggestion: more than $3K\Omega$), which maximum current is less than 10mA.

SIN Input impedance: $15K\Omega$

PIC Input impedance: $40K\Omega$


NIC Input impedance: $20K\Omega$



(e) Analog Output Interface Circuit(106):

The maximum current of analog output is 5mA, so user need to choose the device, which Impedance is larger.

Analog Input Interface Circuit



CNC REZA

سازنده انواع ماشین آلات صنعتی و ماشین مخصوص

WWW.CNCREZA.IR

2-2-2 CN2 Encoder Signal Terminal Explanation

(1) Diagram of CN2 Terminal:

(a) Diagram of Fewer Wiring Type Encoder:

Pin No.	Terminal Layout	Function											
			1	+5V	PW Output Terminal					11	—	—	
2	+5V	PW Output Terminal				12	—	—					
			3	0V	PW Grounding Terminal					13	—	—	
4	0V	PW Grounding Terminal				14	—	—					
			5	A	Encoder / A Phase Input					15	—	—	
6	/A	Encoder / A Phase Input				16	—	—					
			7	B	Encoder / B Phase Input					17	—	—	
8	/B	Encoder / B Phase Input				18	—	—					
			9	Z	Encoder / Z Phase Input					19	—	—	
10	/Z	Encoder / Z Phase Input				20	FG	Shielded Wire Grounding					

(b) Diagram of non-Fewer Wiring Type Encoder:

Pin No.	Terminal Layout	Function											
			1	+5V	PW Output Terminal					11	U	Encoder / U Phase	
2	+5V	PW Output Terminal				12	/U	Encoder / U Phase					
			3	0V	PW Grounding Terminal					13	V	Encoder / V Phase	
4	0V	PW Grounding Terminal				14	/V	Encoder / V Phase					
			5	A	Encoder / A Phase					15	W	Encoder / W Phase	
6	/A	Encoder / A Phase				16	/W	Encoder / W Phase					
			7	B	Encoder / B Phase					17	—	—	
8	/B	Encoder / B Phase				18	—	—					
			9	Z	Encoder / Z Phase					19	—	—	
10	/Z	Encoder / Z Phase				20	FG	Shielded Wire Grounding					

P.S.: Do not wire to the terminal, which is un-operated.

(2) Name and Explanation of I/O Signal:

**Encoder Output
No. and Color**

Milit

Pi	Func-ti-	General Joint	Joina-ry n	Signal Name	on	t
-----------	-----------------	----------------------	-------------------	--------------------	-----------	----------


Terminal Layout Function

No	Cod	15
.	e	9 wires wires Out (fewer (non-fe put wiring) wer No. wiring)

1 Power output + Terminal +5V white Red B 5driver). When the cable is more than V Power for encoder(provided from 2



20m, user should separately use 2



cables to avoid decreasing voltage of 3 Power output - Terminal 0V Black Black I
 encoder. When the cable is more than 30m, please contact to the 4
 distributorship.

5 A Phase A Green Green A Encoder A Phase: From
 motor terminal
 encoder input

6 A /A Blue Green White C to the driver.

7 B Phase B Red Gray H Encoder B Phase: From motor terminal 8 encoder input /B
 Pink Gray white D to the driver.

9 Z Phase Z Yellow Yellow G Encoder Z Phase: From motor terminal 10 encoder input /Z
 Orange Yellow white E to the driver.

11 U Phase U Brown When using fewer-wiring-type 12
 encoder input /U Brown white motor, do not wire.


13 V Phase V Blue When using fewer-wiring-type 14
 encoder input /V Blue white motor, do not wire.

15 W Phase W Orange When using fewer-wiring-type
 16 encoder input /W Orange white motor, do not wire.


17	No operated		/		Do not wire.
18					
19					
20	Shielded wire terminal layout	FG	Shielded net wire	F	Shielded wire, which is connected to the signal wire.

2-3 Standard Wiring Diagram of Control Signal


2-3-1 Position Control (Pe Mode) Wiring Diagram(Line Driver)




2-3-2 Position Control (Pe Mode) Wiring Diagram(Open Collector)




2-3-3 Position Control (Pi Mode)Wiring Diagram



2-3-4 Speed Control(S Mode)Wire Diagram




2-3-5 Torque Control (T Mode) Wire Diagram



Chapter 3 Functions on Panel Operator

3-1 Functions on Driver Panel Operator













This device includes 5 digits 7 segment LED display, 4 control keys and 2 LED lights as below. When the **POWER-LIGHT**(green) shines, it means this equipment is power on then it can normally operate; when the **CHARGE-LIGHT** shines, it means: this device still has power inside after power off, then the cable could be taken apart only after this light extinguishes.



Key	Key Name	Functions
	MODE/SET (MODE/SET KEY)	<ol style="list-style-type: none"> To select a basic mode, such as the status display mode, utility function mode, parameter setting mode, or monitor mode. Returning back into selection of parameter from data-setting screen.
	No. Increase Key (UP Key)	<ol style="list-style-type: none"> Selection of each item of parameter. To increase the set value.
	No. Decrease Key (DOWN Key)	<ol style="list-style-type: none"> Press and at the same time to clear ALARM.
	Data Setting Key (ENTER Key)	<ol style="list-style-type: none"> To confirm data and parameter-item. To shift to the next digit on the left. To finish the data setting.










After power on, to use MODE-Key to select 9 kinds of parameter. The order is described as below:







Step	Key	LED Display after Operation	Description
1	Power on		To enter User-Control parameter, after power on.
2			To enter Diagnosis parameter after pressing MODE-Key once.
3			To enter Alarm parameter after pressing MODE-Key once.
4			To enter Control parameter after pressing MODE-Key once.

5			To enter Torque parameter after pressing MODE-Key once.
6			To enter Speed parameter after pressing MODE-Key once.
7			To enter Position parameter after pressing MODE-Key once.
8			To enter Quick parameter after pressing MODE-Key once.
9			To enter Hyper-Function parameter after pressing MODE-Key once.
10			To enter User-Control parameter again after pressing MODE-Key once, and so on.










There is an setting example below. All function keys will be used. User can operate to understand all functions directly.

Ex: If Sn203 will be set as 100rpm, please see below:


Step	Key	LED Display after Operation	Description
1	Power On		To enter User-Control parameter, after power on.
2			To enter Speed parameter after pressing MODE-Key 5 times.
3			To select the item in Speed-parameter after pressing UP-Key twice.
4			To enter Sn203 screen after pressing ENTER-Key for 2 seconds.
5			Digit position left shifting (Flashing LED) after pressing ENTER once.

Step	Key	LED Display after Operation	Description
6			Digit position left shifting (Flashing LED) after pressing ENTER-Key once.
7			Adjust third digits position from 3 to 1, after pressing DOWN-Key twice.
8			Pressing ENTER-Key for 2 seconds until – SET- appears. It means current setting has been loaded, than it will return back to current parameter item after – SET-.

Refer to front example: If there is no any setting, press MODE-Key once to return back to parameter-selection.

Step	Key	LED Display after Operation	Description
1	Power ON		To enter User-Control parameter when Power on.
2			To enter Speed parameter after pressing MODE-Key 5 times.
3			To select Speed parameter item after pressing UP-Key twice.
4			To enter Sn203 screen after pressing ENTER-Key for 2 seconds.
5			To return back to parameter-selection-screen after pressing MODE once.

There are some hexadecimal displayed parameters. Some of parameters in this equipment is displayed by hexadecimal. If the highest digit shows **H**, it stands for that the parameter is set by hexadecimal. Ex: **Pn365(origin point mode setting) = 0212**, the screen will be showed as below:



Description of Display in Positive/Negative:

Discription of Positive/Negative Display	Display of Positive	Display of Negative
If the setting number range is equal or less than 4 digits and displayed in Negative, the highest digit will display the minus sign. Ex: Sn201 (Internal Speed Command 1).	3000	-3000
If the setting number range is more than 4 digits and displayed in Negative, the decimals of all digits will shine. Ex: Pn317 (Internal Position Command 1-Rotation number)	30000	-30000

Description of Negative-setting-control:

(1) If the setting number range is equal or less than 4 digits. Ex: Sn201(internal speed command 1)=100 to -100

Step	Key	LED Display after Operation	Description
1	Power ON		To enter Unser-Control parameter after power on.
2			To enter Speed parameter after pressing MODE-Key 5 times.
3			To enter Sn201 setting screen after pressing ENTER-Key for 2 seconds.
4			To move the adjustable digit to left 4 digits(=highest digit), after pressing ENTER-Key 4 times.
5	or		Pressing UP or DOWN once -> minus sign appears -> pressing again -> minus sign disappear.
6			Pressing ENTER-Key for 2 seconds -> -SET- appears -> it stands for current setting has been saved -> The screen will return back to the parameter-item-selection.

(2) If the range can be set more than 4 digits. Ex: **Pn317**(internal position command 1-rotation)=0 is set to -10000

Step	Control Keys	LED Display after Operation	Description
1	Power On		To enter User-Control parameter after power on.
2			To enter position control parameter after pressing MODE-Key 6 times.
3			To select Pn317 items after pressing UP-Key 16 times.
4			To enter Pn317 setting screen after pressing ENTER-Key for 2 second.
5			To adjust the adjustable digit to the left for 4 digits after pressing ENTER-Key 4 times.
6			To adjust the ten thousand digits 0 to 1 after pressing DOWN-Key once. All decimal points of all digits will shine, which means current default number is negative.
7			Pressing ENTER-Key for 2 seconds until – SET- appears, which means current default number is saved. After – SET- appears, the screen will turn back to item-selection immediately.

User can use panel board at this equipment to clean Alarm without using input terminal **ALRS**.

Here below is the operat-discription:

Step	Control Key	LED Display after Opertion	Description
1	Alarm		If voltage over low alarm, AL-01 shines.
2	 		After alarm is cleared, remove input contact point SON operation. (= remove servo on) Then press UP-Key and DOWN-Key at the same time. The panel screen shows RESET and returns back to parameter items selection. And the alarm has been correctly cleared.

3-2 Panel Board 3-2-1 Statu Display Function

User can use User-Control parameter to get all informations of current drives and motor rotation. There are the description below:

Parameter Signal	Displayed	Unit	Description

Un-01	Actual motor speed	rpm	Ex: 120 is displayed. It means current motor speed is 120 rpm.
Un-02	Actual motor torque	%	It is displayed in accordance with ratio torque percentage. Ex: 20 is displayed. It means current motor torque output is 20% of ratio torque.
Un-03	Regeneration load ratio	%	Average regeneration power output percentage.
Un-04	Actual load ratio	%	Average power output percentage.
Un-05	Max load ratio	%	Max value of actual load rate
Un-06	Speed command	rpm	Ex: 120 is displayed. It means current motor speed is 120 rpm.
Un-07	Position incorrect value	pulse	The incorrect value of position command and position feedback.
Un-08	Position feedback value	pulse	The pulse cumulation value of motor encoder.
Un-09	External voltage command	V	Ex: Display: 5.25. Which means external voltage command is 5.25V.
Un-10	Vdc Bus Voltage	V	Ex: Display: 310. Which means mains main circuit voltage is 310V.
Un-11	External speed limit command value	rpm	Ex: Display: 2000. Which means current external speed limit is 2000 rpm.
Un-12	External CCW Torque limit command value	%	Ex: Display 100. Which means current external CCW torque limit command is 100 %.
Un-13	External CW Torque limit command value	%	Ex: Display 100. Which means current external CW torque limit command is 100%.
Un-14	Motor feed back – Rotation value (absolute value)	rev	After power on, it displays motor rotation number in absolute value.
Un-15	Motor feed back – Less than 1 rotation pulse value(absolute value)	pulse	After power on, it displays motor less than 1 rotating pulse value in absolute value.
Un-16	Pulse command – rotation value(absolute value)	rev	After power on, it displays pulse command inputting rotation number in absolute value.
Un-17	Pulse command – Less than 1 rotation pulse value(absolute value)	pulse	After power on, it displays pulse command inputting less than 1 rotation – pulse value in absolute value.
Un-18	Torque command	%	It displays in ratio torque percentage. Ex: Display: 50. Which means current motor torque command is 50% of ratio torque.

Un-19	Load inertia	x0.1	<p>When Cn002.2=0(no use auto gain adjust function), it displays current default load inertia ratio in Cn025.</p> <p>When Cn002.2=1(keep using auto gain adjustfunction), it displays current forecasting load inertia ratio.</p>
--------------	--------------	------	--



3-2-2 Diagnosis Functions


User can use diagnosis parameter to get all informations of current system. There are the description below:

Parameter Signal	Name and Function
dn-01	Current control mode
dn-02	Output connect terminal signal
dn-03	Input connect terminal signal
dn-04	Software version
dn-05	JOG mode operation
dn-06	Maintain
dn-07	External voltage command bias automatic adjusting
dn-08	Servo series

dn-01 (Current Control Mode Display)


User can use **dn-01** to know the equipment in which control mode. The diagram below is the control mode v.s panel board display:

Control Mode	dn-01 (Control mode display)
Torque control –T	
Speed control –S	
Position control(external pulse command) –Pe	
Position/Speed control switch –Pe/S	
Speed/Torque control switch –S/T	
Position/Torque control switch –Pe/T	



dn-02 (Output terminal signal)

User can use dn-02 to get the situation of current output terminal signal. Here below is the description of the panel board:



When output terminal signal is low electric potential (close loop with **IG24**), the corresponding LED will shine; when output terminal signal is high electric potential (open loop with **IG24**), the corresponding LED will not shine. The diagram below is the synopsis of LED number and output terminal number, and **DO-1~DO-4** are hyper function programmed terminals. Please refer to **5-6-1** to set the function. **DO-5~DO-8** are single function output terminal.


LED No.	Output connect terminal number	Default function
1	DO-1	RDY
2	DO-2	ALM
3	DO-3	ZS
4	DO-4	INP
5	DO-5	LM/A0
6	DO-6	PC/A1
7	DO-7	ST/A2
8	DO-8	BB/A3

P.S.: Please refer to 5-6-1 to set high or low electric potential in hyper function programmed output terminal.

Signal function output terminal is low electric potential.

dn-03 (Input terminal signal)

User can use **dn-03** to know the situation of current input terminal signal. Here below is the panel board description:







When output terminal signal is low electric potential (close loop with **IG24**), the corresponding LED will shine; when output terminal signal is high electric potential (open loop with **IG24**), the corresponding LED will not shine. The diagram below is the synopsis of LED number and output terminal number, and **DI-1~DI-10** are hyper function programmed terminals. Please refer to **5-6-1** to set the function.

LED Number	Input terminal number	Default function
1	DI-1	SON
2	DI -2	ALRS
3	DI -3	PCNT
4	DI -4	CCWL
5	DI -5	CWL
6	DI -6	TLMT
7	DI -7	CLR
8	DI -8	LOK
9	DI -9	EMC
10	DI -10	SPD1

dn-04 (Version of Software)

User can use **dn-04** to know the current software version of this equipment. Here is the description below:







Step	Keys	LED Display	Description
1	Power On	Un-01	To enter User-Control parameter after power on.
2		dn-01	To enter diagnosis parameter after pressing MODE-Key once.
3		dn-04	To select dn-04 items after pressing UP-Key 3 times.
4		00200	To enter "software version" after pressing ENTER-Key for 2 seconds. (Software version: 2.00)
5		dn-04	To turn back to parameter selection after pressing MODE-Key once.

dn-05 (JOG Operation)

User can use **dn-05** to turn on JOG J, here is the description below:

Attention: The JOG is operated in accordance with Sn201(internal speed command 1). Please set Sn201 before executing this function.

Attention: The motor will power on immediately when entering JOG mode, no matter the motor use input terminal SON or not.


Step	Key	LED display	Description
1	Power on	Un-01	To enter User-Control parameter after power on.
2		dn-01	To enter diagnosis parameter after pressing MODE-Key once.
3		dn-05	To select dn-05 items after pressing UP-Key 4 times.
4		Jo9--	To enter JOG MODE after pressing ENTER-Key for 2 seconds. Motor will power on immediately.
5		Jo9-P	Press UP-Key: motor will run in current defined positive direction.
6		Jo9-n	Press DOWN-Key: motor will run in current defined negative direction.
7		dn-05	To turn back parameter selection after pressing MODE-Key once. The motor power off immediately.

dn-07 (External Voltage command bias automatic adjusting)

When external torque or speed analog command is 0V, the motor might rotate slowly. User can use **dn-07** to automatically adjust analog command bias. Here below is the step description:

Step	Key	LED Display	Description
1			Please close loop between analog command terminal SIN(CN1-26) and analog grounding terminal AG(CN1-29) before adjusting.
2	Power on	Un-001	To enter User-Control parameter after power on.
3	MODE	dn-001	To enter diagnosis after pressing MODE-Key once.
4	▲	dn-007	To select dn-07 after UP-Key 6 times.
5	ENTER	000000	To enter dn-07 after pressing ENTER-Key for 2 seconds.
6	▲	000001	To press UP-Key once. " 1 " means bias automatic adjusting.
7	ENTER	-SET- dn-07	Pressing ENTER-Key for 2 seconds until - SET- appears, which means bias value is set. After - SET- appears, the screen will turn back to item-selection immediately. If this bias voltage adjusting value want to be saved, please pressing ENTER-Key in Tn104 or Sn217.

سازنده انواع ماشین، آلات صنعتی، و ماشین مخصوص



dn-08 (Servo Series)

User can use **dn-08** to check the current combination of drives and motor, which is showed as below. If the displayed setting value is different from actual combination, please contact to lock distributors.

dn-08 Display Cn030 Setting	Drives Model	Motor Model	Motor Standards		Encoder Standards	
			Watt (W)	Speed (rpm)		
121	JSDA-15	JSMA-LC03AB	300	3000	2500	
122		JSMA-LC03AH			8192	
131		JSMA-SC02AB	200	3000	2500	
132		JSMA-SC02AH			8192	
141		JSMA-SC04AB	400	3000	2500	
142		JSMA-SC04AH			8192	
211	JSDA-20	JSMA-LC08AB	750	3000	2500	
212		JSMA-LC08AH			8192	
221		JSMA-SC04AB	400	3000	2500	
222		JSMA-SC04AH			8192	
231		JSMA-SC08AB	750	3000	2500	
232		JSMA-SC08AH			8192	
241		JSMA-MA05AB	550	1000	2500	
242		JSMA-MA05AH			8192	
251		JSMA-MH05AB	550	1500	2500	
252		JSMA-MH05AH			8192	
311		JSDA-30	JSMA-SC08AB	750	3000	2500
312			JSMA-SC08AH			8192
321	JSMA-MA10AB		1000	1000	2500	
322	JSMA-MA10AH				8192	

331		JSMA-MB10AB	1000	2000	2500
332		JSMA-MB10AH			8192
341		JSMA-MH10AB	1000	1500	2500
342		JSMA-MH10AH			8192
351		JSMA-MA15AB	1500	1000	2500
352		JSMA-MA15AH			8192




dn-08 Display Cn030 Setting	Drives Model	Motor Model	Motor Standards		Encoder Standards	
			Watt (W)	Speed (rpm)		
361	JSDA-30	JSMA-MB15AB	1500	2000	2500	
362		JSMA-MB15AH			8192	
371		JSMA-MC15AB	1500	3000	2500	
372		JSMA-MC15AH			8192	
511	JSDA-50	JSMA-MA15AB	1500	1000	2500	
512		JSMA-MA15AH			8192	
521		JSMA-MB15AB	1500	2000	2500	
522		JSMA-MB15AH			8192	
531		JSMA-MC15AB	1500	3000	2500	
532		JSMA-MC15AH			8192	
541		JSMA-MB20AB	2000	2000	2500	
542		JSMA-MB20AH			8192	
711		JSDA-75	JSMA-MB30AB	3000	2000	2500

712		JSMA-MB30AH			8192
721		JSMA-MC30AB	3000	3000	2500
722		JSMA-MC30AH			8192



Chapter 4 Operation of Trial Run

Before executing trial run, please confirm all wiring work have been accomplished. The description below is the trial run operation and purpose; and when trial run and host controller operate together, it describes in accordance with speed control loop (analog voltage command) and position control loop (external pulse command).

(1) Non-loaded servo motor trial run (Reference:4-1)	
A. ServoDrives wiring and motor installation	B. Purpose of trial run
	<p>Confirm if the items below are correct:</p> <ul style="list-style-type: none"> . Drives power wiring . ServoMotor wiring . Encoder wiring . ServoMotor rotation direction and speed
(2) Non-loaded servo motor with host controller trial run (Reference:4-2)	
A. Servo drives wiring and motor installation	B. Purpose of trial run
	<p>Confirm if the items below are correct:</p> <ul style="list-style-type: none"> . Control signal wiring between host controller and servo drives . Servo motor rotation direction, speed and rotating number . Brake function, operation limit function and protection function
(3) Connect to loaded servo motor with host controller trial run (Reference:4-3)	
A. Servo drives wiring and motor installation	B. Purpose of trial run
	<p>Confirm if the items below are correct:</p> <ul style="list-style-type: none"> . Servo motor rotation direction, speed and mechanical operation range . Set related control parameters

4-1 Non-loaded Servo Motor Trial Run



Attention

⚠

In the process of trial run, user must take the servo motor from the mechanical system apart. Ex.: Coupling or belt etc..

In order to prevent the damage of mechanical system in the process of trial run, the servo motor must execut trial run in non-loaded situation.

In this step of trial run, user can check the drive wiring. If there is abnormal wiring, there will also be abnormal trial run of servo motor.

1. Installation of servo motor:


Fix the servo motor on the mechanical system to prevent the vibration or moving situation in the process of trial run.

2. Wiring:

Check servo drive power wiring, servo motor wiring and encoder wiring. User doesn't use any control signal wire in this step of trial run, so please remove control signal wire(CN1).

3. Turn on the servo drive power:

Turn on the power of servo drive. If the panel borad shows as below, which means abnormal alarm of servo drive:



Reason: Input terminal **CCWL** and **CWL** operates at the same moment (high or low electric potential, please refere to **5-6-1** to set). Because of the alarm, the servo can not operate normally.

User can use the parameter **Cn002.1=1** to turn off the drive limit function temperally at the process of trial run. After the first step of trial,please set the peremeter **Cn002.1=1**.

Setting and operation:

Setp	Keys	LED Display	Description
1	Power on		To enter User-Control parameter after power on.
1			To enter Control parameter after pressing MODE-Key 3 times.
2			To select Cn002 items after pressing UP-Key once
3			To enter Cn002 setting screen after pressing ENTER-Key for 2 seconds.
4			Left-moving the adjustable digit (shining LED), after pressing ENTER-Key once.
5			Pressing UP-Key once to adjust 2 nd digit to 1. Setting to “no operating input terminal CCWL and CWL ”.
6			Pressing ENTER-Key for 2 seconds until – SET- appears, which means current setting value has been saved. After – SET-, it will immediately turn back to current parameter items selection.

After the setting is complete, please reset the power. If there is still other abnormal alarm, it means the drives can not operate normally. (User need refer to **8-2(abnormal clear)**). After the abnormal is cleared, operate the drives again. If the abnormal alarm still can not be cleared again, please contact to local distributors to get the information and help.

4. Release mechanical Brake:

When the motor attaches mechanical Brake, please complete +24V wiring to release mechanical Brake at beginning. In not, there will be abnormal in trial run.

5. Operation of Servo Drives Panel Board:

Using panel board to command **JOG** operating to make sure if motor speed and direction is correct. If not, please confirm if the speed control parameter **Sn201**(internal speed command 1) and the user-control parameter **Cn004**(motor rotation direction setting) are correct or not. Here below is the **JOG** operation description:

Attention: The JOG is operated in accordance with Sn201(internal speed command 1), so user need to set Sn201 before operating this function.

Attention: Regardless of using SON to servo on. After entering JOG mode, motor will servo on immediately.

Step	Keys	LED Display	Description
1	Power on		To enter user-control parameter after power on.
2			To enter diagnosis parameter after pressing MODE-Key once.
3			To select dn-05 items after pressing UP key 4 times.
4			Ater pressing ENTER-Key for 2 seconds, entering JOG mode , than the motor will on.
5			Keep pressing UP-Key, motor rotates in accordance with current setting direction.
6			Keep pressing DOWN-Key, motor rotates in accordance with current setting negative direction.
7			Pressing MODE-Key once → Returning back to parameter selection → Motor will terminate “servo on” immediately.


سازنده انواع ماشین آلات صنعتی و ماشین مخصوص


4-2 Non-loaded Servo Motor Trial Run with Host Controller

During this step, user can make sure the control signal wires and the control signal electric potential between servo drives and host controller are correct or not. Motor can connect to the mechanical after finishing this trial run step.

A. Turn on Servo motor:

Please see the diagram below to execute wiring






a. No command signal input:

In speed control mode, input **0V** to speed analog input terminal.

In position control mode, please connect the external pulse command terminal “Pulse” to “/Pulse”, and “Sign” to “/Sign”.

b. Turn the **Servo ON Signal** on:


Connect the **SON** to low electric potential to turn on servo motor and check if there is any abnormal alarm. If yes, user need refer to Chapter **8-2(Abnormal Clear)**.



B. Trial run in Speed control mode(Cn001=1) :

1. Wiring:

Make sure if the servo drives power and control signal wiring are correct. Confirm if the speed analog signal input is 0V. Here below is the diagram:




2. Turn on Servo Motor:

Let (**SON**) connect to low electric potential \rightarrow turn on servo motor. If the motor rotates slowly, please execute **dn-07** to adjust automatically analog command error value(refer to **3-2-2**).

3. Check the relationship between motor speed and speed analog command input: Increase the speed analog command voltage by degrees. Check the motor actual speed in **Un0-01** and make sure analog speed command ratio(**Sn216**) and analog speed command limit(**Sn218**) are correct or not. And confirm if the motor rotation is abnormal. If yes, please adjust user-control **Cn004**. Finally, let the **SON** connect to high electric potential and turn off the servo motor.

4. To complete the wiring to the host controller:

Confirm the wiring of servo drive and host controller, speed analog signal input(**SIN**), encoder output (**PA, /PA, PB, /PB, PZ, /PZ**) and alarm signal. Here below is the wiring diagram.




5. Confirm the rotation number and encoder output of Servo Motor:

Turn on servo motor ⇨ Executing servo motor rotating number command from host controller ⇨ Checking the motor rotating number in User-Control parameter **Un-14** to see if there is any difference. If yes, please make sure if the parameter encoder signal output **Cn005** is correct. After the setting is complete, connect the **SON** to the high electric potential ⇨ turn off the servo motor. **C. Position control mode trial**

run(Cn001=2) :

1. Wiring:

Confirm if the power and control signal wiring from servo drive are correct. Here below is the diaram:



2. Setting of electric gear ratio:

Please set the necessary position control parameter electric gear ratio **Pn302~Pn306**(refere to 5-4-3) in accordance with the standard of servo motor encoder and motion table application.

3. Turn on Servo Motor:

Connecting the **SON** to the low electric potential to turn on servo motor.

4. Confirm the motor rotation-direction, speed and rotation number:

Outputting the low-speed pulse command from host controller to make servo motor operate at low-speed (compare to the parameter **Un-15** – motor feed back pulse number and **Un-17** – Pulse command number). ⚡

Executing rotation number command (compare to the parameter Un-14 – motor feed back rotation number and Un-16 – pulse command rotation number). If there is any abnormal for actual motor feed back, please adjust position control parameter electric gear ratio **Pn302~Pn306**. **Please recheck until operation is normal.**

If the direction of motor rotation is abnormal, please confirm position control parameter pulsecommand model selection **Pn301.0** and command direction definition **Pn314**. After the setting is accomplished, connect the SON to the high electric potential ⚡ turn off the servo motor.

4-3 Trial Run (connecting to loaded servo motor with host controller)



Attention




Please execut the steps below to operate loaded trial run.

Servo motor operates under the situation of loading mechanical system. It will cause injuring or damage if it is not well setting.

Before executing the trial run, please confirm the items below:

- ④ Please set the related parameters of servo drive in accordance with the necessary of host controller and mechanical system.
- ④ Confirm if the servo motor rotating direction and speed setting is in accord with the necessary of mechanical system.



1. Confirm the ServoDrive Power is off

2. Connecting the load-shaft of servo motor:

Please refer to Chapter 1-5 to check the installation of servo motor.

3. Gain adjusting of servo drive:

Please be in accordance with load system and refer to Chapter 5-5 to execute servo gain adjusting.

4. Trial run of host controller:

Be commanded by host controller. Please refer to operation command in chapter 4-2 and check the operating situation and execut adjusting depends on situations.

5. Repeat adjusting and record the setting value:

Repeat step 3 and 4 until the mechanical system operates normally. Record the setting value very certainly to be the data of future maintaining.

Chapter 5 Control Function

5-1 Selection of control mode


There are torque, speed and position mode in this device. Users can operate single mode, or can use multi mode to switch control mode. The diagram below is the description of parameter.

Parameter Signal	Name	Setting	Description	Control Mode
★Cn001	Control mode select	0	Torque control	ALL
			To use one analog voltage command signal to control torque. Please refer to 5-2.	
		1	Speed control	
			To use input contact SPD1 and SPD2 to switch the default 3-stages speed command and to use one analog voltage command signal in the drive to control speed. Please refer to 5-3-1.	
		2	Position control (External pulse command)	
			To use one pulse command signal to control position. Please refer to 5-4-1.	
		3	Position / Speed control switch	
			To use input contact MDC to switch position and speed control. Please refer to 5-6-2.	
4	Speed / Torque control switch			
	To use input contact MDC to switch speed and torque control. Please refer to 5-6-2.			
5	Position / Torque control switch			
	To use input contact MDC to switch position and torque control. Please refer to 5-6-2.			
6	Position control (internal position command)			
	To use input contact POS1~POS4 to switch the default 16-stage position command to control position. Please refer to 5-4-2.			


★The setting will be in effect after returning on the power.

5-2 Torque mode

Torque mode is applied in printing machine, coil wiring machine, injection molding machine and other torque control applied area. The diagram below is about torque loop control:



The method of torque command input of this device: Using one group of analog voltage to control motor torque. The diagram below is the wiring:



Attention! User need to confirm the relationship between SIN(analog torque command input) and input contacts RS1, RS2(torque command CW/CCW selection). Refer to Chapter 5-2-4.


5-2-1 Analog torque command ratio

Referring to analog torque command ratio to adjust the slope between voltage command to torque command.

Parameter Signal	Name	Default	Unit	Setting range	Control Mode
Tn103	Analog torque command ratio	300	%/10V	0~300	T

Setting example:

- (1) If entering 300 in **Tn103** ⇨ input voltage 10V corresponding 300% ratio torque command; if voltage is 5V ⇨ corresponding 150% ratio torque command.
- (2) If entering 200 in **Tn103** ⇨ input voltage 10V corresponding 200% ratio torque command; if voltage is 5V ⇨ corresponding 100% ratio torque command.




5-2-2 Analog torque command bias adjusting

Even the torque command is 0V, motor could also possibly rotate slowly. The main reason is that external analog voltage has a few bias value. Under this situation, user can directly adjust **Tn104** to adjust the bias value or use auto-adjusting. (Please refer to 3-2-2).

Attention! Please let the analog torque command contact SIN(CN1-26) and analog grounding contact AG (CN1-29) close loop.

Parameter Signal	Name	Default	Unit	Setting range	Control mode
Tn104	Analog torque command bias adjusting	0	mV	-10000~10000	T



5-2-3 Torque command linear ac/deceleration


If users need smooth torque command, they can set the torque command linear ac/deceleration constant to achieve smooth result. **If user need this function, please set Tn101 to "1" to operat this function.**

Parameter Signal	Name	Setting	Description	Control mode
★Tn101	Torque command ac/deceleration	0	No operating torque command linear ac/deceleration function	T
		1	Operating torque command linear ac/deceleration function	

The Definition of torque command linear ac/deceleration constant means **The Time** in which the torque command arises from "0" to the ratio torque. Here is the diagram:

Parameter Signal	Name	Default	Unit	Setting Range	Control mode
★Tn102	Torque command ac/deceleration Constant	1	msec	1~50000	T

★The setting will be in effect after returning on the power



Setting example:

- (1) Achieve 50% of ratio torque output in 10msec:

$$Tn102 = 10(\text{msec}) \times \frac{100\%}{50\%} = 20(\text{msec})$$

- (2) Achieve 75% of ratio torque output in 10msec:

$$Tn102 = 10(\text{msec}) \times \frac{100\%}{75\%} = 13(\text{msec})$$

5-2-4 Definition of torque output direction

In torque mode, user can use the 3 methods below to definit motor rotating direction:

- (1) Input contacts **RS1, RS2**(torque command CW/CCW select)
- (2) **Cn004**(motor rotate direction definition)

(3) Input contact **TRQINV**(torque command inverse)

Attention! 3 methods can operate at the same time. User need to make sure the final motor direction definition in order to avoid erro.

Input Contact		Description	Control mode
RS2	RS1		
0	0	No torque	T
0	1	Rotating in current torque command direction	
1	0	Rotating in current torque command inverse direction	
1	1	No torque	

P.S.: Input contacts status 1 means on; 0 means off. Please check 5-6-1 to set high electric potential or low electric potential

Parameter Signal	Name	Setting	Description		Control mode	
Cn004	Motor rotating direction definition (load terminal)	0	Torque Control	Speed Control	S/T	
			(CCW)	(CCW)		
			1	(CW)		(CCW)
			2	(CCW)		(CW)
			3	(CW)		(CW)

Input contact TRQINV	Description	Control mode
0	Rotating in current torque command direction	T
1	Rotating in current torque command interse direction	

P.S.: Input contacts status 1 means on; 0 means off. Please check 5-6-1 to set high electric potential or low electric potential

5-2-5 Internal torque limit setting

In the Torque Control, user can set internal torque limit value when needed. Here below is the setting:

Parameter Signal	Name	Default	Unit	Setting range	Control mode
Cn010	CCW Torque command limit value	100	%	0~300	ALL
Cn011	CW Torque command limit value	-100	%	-300~0	ALL

5-2-6 Speed limit of torque mode

In torque control, user can use input contacts **SPD1** and **SPD2** switching the 2 methods to operate the motor speed limit.

(1) Internal speed limit: Internal default 3-stages speed limit

(2) External analog command limit: Using a analog voltage command signal and entering to **PIC(CN1-27)** to control speed limit.


Attention! About the setting of the motor speed limit smooth handling, please refer to 5-3-6.

Please refer to the diagram below:

Input contact SPD2	Input contact SPD1	Speed limit command	Control mode
0	0	External analog command PIC(CN1-27)	T
0	1	Internal speed limit1 Tn105	
1	0	Internal speed limit2 Tn106	
1	1	Internal speed limit3 Tn107	

P.S.: Input contacts status 1 means on; 0 means off. Please check 5-6-1 to set high electric potential or low electric potential

Here below is the external analog speed limit command wiring diagram:



The diagram below is the internal 3-stages speed limit setting. The setting value means motor CCW and CW speed limit value.

Parameter Signal	Name	Default	Unit	Setting range	Control mode
Tn105	Internal speed limit 1	100	rpm	0~3000	T
Tn106	Internal speed limit 2	200	rpm	0~3000	T
Tn107	Internal speed limit 3	300	rpm	0~3000	T




5-2-7 Other torque control functions



When the torque of CW or CCW is more than the speed in **Tn108** (torque achieving judging value), the output contact **INT** operates. Here is the description:

Parameter Signal	Name	Default	Unit	Setting range	Control mode
Tn108	Torque achieving judging value	100	%	0~300	ALL



P.S.: Input contacts status 1 means on; 0 means off. Please check 5-6-1 to set high electric potential or low electric potential

سازنده انواع ماشین آلات صنعتی و ماشین مخصوص
WWW.CNCREZA.IR




When there were vibrating noise, user can adjust the Cn034 (torque command smooth filter) to avoid it. To add this filter will cause delay of the response speed of servo.

Parameter Signal	Name	Default	Unit	Setting range	Control mode
Cn034	Torque command smooth filter	0	Hz	0~1000	ALL


5-3 Speed Mode

The speed mode is necessary during the accurate application. Ex: Weaving machine, drilling machine and CNC machine. The 2 diagrams below is about speed loop control. And the detail functions is described in following chapter.

Speed Command Handling



Speed Controller



5-3-1 Speed Command Selecting

There are 2 kinds of input command method. Using input contacts - **SPD1**、**SPD2** – to switch the 2 methods below to operate speed command:

- (1) Internal speed command: Internal default 3-stages speed command.
- (2) External analog command: Using 1 analog voltage command signal \hat{v} entering **SIN(CN1-26)** to control speed.


Please refer to this diagram:

Input Contact SPD2	Input Contact SPD1	Speed Command	Control Mode
0	0	External analog command SIN(CN1-26)	S

0	1	Internal speed command 1 Sn201
1	0	Internal speed command 2 Sn202
1	1	Internal speed command 3 Sn203

P.S.: Input contacts status 1 means on; 0 means off. Please check 5-6-1 to set high electric potential or low electric potential.

The diagram below is about external analog speed command wiring:



And here is the internal 3 stages speed command setting:

Parameter Signal	Name	Default	Unit	Setting range	Control mode
Sn201	Internal speed command 1	100	rpm	-3000~3000	S
Sn202	Internal speed command 2	200	rpm	-3000~3000	S
Sn203	Internal speed command 3	300	rpm	-3000~3000	S

5-3-2 Analog Speed Command Ratio


Matching up analog speed command ratio to adjust the slope of voltage command with speed command.

Parameter Signal	Name	Default	Unit	Setting range	Control mode
Sn216	Analog speed command ratio	3000	rpm/10V	100~4500	S

Setting Example:

- (1) When **Sn216** is 3000, which stands for input voltage 10V matching up 3000rpm; if input voltage is 5V, it matches up 1500rpm speed command.
- (2) When **Sn216** is 2000, which stands for input voltage 10V matching up 2000rpm; if input voltage is 10V,

it matches up 1000rpm speed command.




5-3-3 Analog Speed Command Bias Adjusting

Even the analog speed command is 0V, motor could possibly rotate slowly. The main reason is external analog voltage has few bias. User can use **Sn217** to adjust bias value or automatic adjusting under this situation. (Please refer 3-2-2).

Attention! Please close loop to analog speed contact Sin(CN1-26) and analog grounding contact AG(CN1-29) before adjusting.

Parameter signal	Name	Default	Unit	Setting range	Control mode
Sn217	Analog speed command bias adjusting	0	mV	-10000~10000	S




5-3-4 Analog Speed Command Limit

User can limit the analog speed command, here is the setting:

Parameter signal	Name	Default	Unit	Setting range	Control mode
Sn218	Analog speed command limit	3050	rpm	100~4500	S

5-3-5 Encoder Signal – Encode Output

The encoder signal of motor can be encoded handled through this device then outputting to host control to become to position control loop. Here is the diagram :



Encode handling Pulse signal number of MotorEncoder's one rotation transform to **Cn005** default pulse signal number.

Parameter signal	Name	Default	Unit	Setting range	Control mode
★Cn005	Encoder signal encode output	Encoder Pulse number / 1 rotating	pulse	1~ encoder pulse number of 1 rotating	ALL


★The setting will be in effect after returning on the power.

Attention! The setting range can not more than motor encoder pulse number of 1 rotating.

Pulse signal definition of encode output:

Code of Terminal layout	Name	Number of Terminal layout	Control mode
PA	Encoder output A Phase signal	CN1-35	ALL
/PA	Encoder output /A Phase signal	CN1-36	
PB	Encoder output B Phase signal	CN1-37	
/PB	Encoder output /B Phase signal	CN1-38	

PZ	Encoder output Z Phase signal	CN1-39
/PZ	Encoder output /Z Phase signal	CN1-40



5-3-6 Speed Command Smoothly

When there are overshooting or vibration of motor after entering command, user can execute the 3 kinds of speed command smooth control in this drive and decide to execute which smooth control in accordance with which necessary.

If user executes one of them, please set Sn205 first to turn on all functions.

Parameter Signal	Name	Setting	Description	Control mode
------------------	------	---------	-------------	--------------

Sn205	Speed command ac/deceleration method	0	No using speed command ac/deceleration function	S
		1	To use speed command once smooth ac/deceleration function	
		2	To use speed command linear ac/deceleration function	
		3	To use S-curve speed command ac/deceleration function	


Here is the description of 3 kinds of speed command smooth control.

(1) Speed command once smooth ac/deceleration:

User must set **Sn205=1** to turn on speed command once smooth ac/deceleration function before using this function.

Parameter Signal	Name	Default	Unit	Setting range	Control mode
Sn206	Speed command once smooth ac/deceleration Time Constant	1	msec	1~10000	S

The definition of Speed command once smooth ac/deceleration Time Constant means the time in which the speed increases from 0 to 63.2%. Here below is the diagram:



Setting example:

- (1) If achieving 95% of speed command output in 30msec:

$$Sn206 = \frac{30(\text{msec})}{-\ln(1 - 95\%)} = 10(\text{msec})$$

- (2) If achieving 75% of speed command output in 30msec:


$$Sn206 = \frac{30(\text{msec})}{-\ln(1 - 75\%)} = 22(\text{msec})$$

(2) **Speed command linear ac/deceleration function:**

User must set **Sn205=2** to turn on speed command linear ac/deceleration function before using this function.

Parameter Signal	Name	Default	Unit	Setting range	Control mode
Sn207	Speed command linear ac/deceleration constant	1	msec	1~50000	S

The definition of Speed command linear ac/deceleration Constant means \hat{t} the time in which the speed increases (linear) from zero to the ratio speed. Here below is the diagram:



Setting example:

- (1) If achieving 50% of ratio speed output in 10msec:

$$Sn207 = 10(\text{msec}) \times \frac{100\%}{50\%} = 20(\text{msec})$$

- (2) If achieving 75% of ratio speed output in 10msec:

$$Sn207 = 10(\text{msec}) \times \frac{100\%}{75\%} = 13(\text{msec})$$


(3) **S-Curve Speed Command Ac/Deceleration:**

User must set **Sn205=3** to turn on S-Curve speed command ac/deceleration function before using this function.

Parameter Signal	Name	Default	Unit	Setting range	Control mode
------------------	------	---------	------	---------------	--------------

Sn207	Speed command linear ac/deceleration constant	1	msec	1~50000	S
Sn208	S-Curve speed command ac/deceleration time setting	1	msec	1~1000	S
Sn209	S-Curve speed command acceleration time setting	200	msec	0~10000	S
Sn210	S-Curve speed command deceleration time setting	200	msec	0~10000	S

Ac/deceleration ⚡ Because of strong change of ac/deceleration when on or off, which will cause vibration of mechanical system. Adding S-Curve ac/deceleration in speed command ⚡ it can achieve smoothly operating.



Attention! Setting Rule: $t_{2a} > t_s$, $t_{2d} > t_s$



5-3-7 Speed Rotating Direction Definition

In speed mode, use can use **Cn004**(motor rotating direction definition) and input contact **SPDINV** to definite motor rotating definition. Here below is the description:

Attention! The 2 methods can operate at the same time. User must confirm the final motor direction to avoid confusion.

Here is the motor direction setting:

Parameter Signal	Name	Setting	Description		Control mode
Cn004			Torque control	Speed control	S/T

Motor rotating direction definition (motor load terminal)  	0	(CCW)	(CCW)
	1	(CW)	(CCW)
	2	(CCW)	(CW)
	3	(CW)	(CW)

Input contact SPDINV	Description	Control mode
0	Rotating with current speed command direction	S
1	Rotating with current speed command inverse direction	


P.S.: Input contacts status 1 means on; 0 means off. Please check 5-6-1 to set high electric potential or low electric potential

5-3-8 Speed Loop Gain

The diagram below is the related parameters of speed control loop. This device provides 2 speed controller. User can use gain switch function to switch them. (Please refer to 5-3-11)

Parameter Signal	Name	Default	Unit	Setting range	Control mode
Sn211	Speed loop gain 1	40	Hz	10~450	Pe/Pi/S
Sn212	Speed loop integral time constant 1	100	x0.2 msec	1~500	Pe/Pi/S
Sn213	Speed loop gain 2	40	Hz	10~450	Pe/Pi/S
Sn214	Speed loop integral time constant 2	100	x0.2 msec	1~500	Pe/Pi/S

The foto below is about the speed controller of this device. More the speed loop gain is or less the speed loop integral time is, faster the speed control respond. Please refer to 5-5 to check the method of speed loop control gain.



5-3-9 Notch Filter






When the low machine rigidity, the bearing twisting or other vibration situation causing vibration or noise (the mechanical system can not increase controller gain), this device provides Notch Filter to clear this phenomenon.

Inputing vibrating frequency in Cn013(Notch Filter frequency) and matching up **Cn014** () to adjust the frequency range. Lower the Cn014 value is, wider the frequency range is. User can adjust in accordance with actual situation.

Attention! When Cn013 set “0”, it means no using Notch Filter. Enter the frequency from vibration in Cn013 (frequency of notch filter), then match with Cn014 (quality factor of notch filter).

Parameter Signal	Name	Default	Unit	Setting range	Control mode
Cn013	Notch Filter frequency	0	Hz	0~1000	Pi/Pe/S
Cn014	Quality Factor of Notch Filter	7	X	1~100	Pi/Pe/S

سازنده انواع ماشین آلات صنعتی و ماشین مخصوص
WWW.CNCREZA.IR



5-3-10 Torque Limit in Speed Mode

In speed mode, the motor torque limit is achieved by input contact **TLMT** switching the 2 methods below:

- (1) Inter torque limit: Using internal default **Cn010**(CCW Torque command limit value) and **Cn011**(CW Torque command limit value).
- (2) External analog command: Using 2 groups of analog voltage command signals to enter **PIC(CN1-27)** separately to limit CCW torque and **NIC(CN1-28)** to CCW torque.

Please refer to the diagram below:

Input contact TLMT	CCW torque command limit source	CW torque command limit source	Control mode
0	Cn010	Cn011	ALL
1	External analog command PIC(CN1-27)	External analog command NIC(CN1-28)	Pi/Pe/S


P.S.: Input contacts status 1 means on; 0 means off. Please check 5-6-1 to set high electric potential or low electric potential

Attention! To use external analog torque command limit ⚡ If this analog torque command limit is more than internal torque command limit, the internal torque command limit will be the major finally.

The description below is about the internal torque limit setting:

Parameter signal	Name	Default	Unit	Setting range	Control mode
Cn010	CCW torque command limit value	100	%	0~300	ALL
Cn011	CW torque command limit value	-100	%	-300~0	ALL

The diagram below is about the external analog torque limit command wiring:



5-3-11 Gain Switch Function


The gain switch function in this device contains speed loop gain PI/P switching and 2-stage gain switching. The applications are:

- (1) In speed control, to restrain ac/deceleration overshooting.
- (2) In position control, to restrain the breadth of vibration and decrease the adjusting time.
- (3) To decrease the noise from using Servo Lock function.

Here below are about the related parameter description:



Before PI/P mode ⇨ Selecting **Cn015.0** (Selection of PI/P-mode type), and set PI/P-mode switching condition in related parameters. Here is the description:

Parameter Signal	Name	Setting	Description	Control mode
Cn015.0 	Selection of PI/P-mode type	0	Estimate if the torque command is more than Cn016	Pi/Pe/S
		1	Estimate if the speed command is more than Cn017	
		2	Estimate if the speed command is more than Cn018	
		3	Estimate if the position error value is more than Cn019	
		4	Using input contact PCNT to switch them	


Parameter Signal	Name	Default	Unit	Setting range	Control mode
Cn016	PI/P-mode switching condition (torque command)	200	%	0~399	Pi/Pe/S
Cn017	PI/P-mode switching condition (speed command)	0	rpm	0~4500	Pi/Pe/S
Cn018	PI/P-mode switching condition (acceleration)	0	rps/s	0~18750	Pi/Pe/S
Cn019	PI/P-mode switching condition (position error value)	0	pulse	0~50000	Pi/Pe/S

- (1) Estimating torque command to switch PI/P-mode

When torque command is less than **Cn016** switching condition: Controlled by PI;

When torque command is more than **Cn016** switching condition: switching to : Controlled by P only.

Here is the diagram below:




(2) Estimating speed command to switch PI/P-mode

When speed command is less than **Cn017** switching condition: Controlled by PI;

When speed command is more than **Cn017** switching condition: Controlled by P only.

Here is the diagram below:




(3) Estimating acceleration command to switch PI/P-mode

When acceleration command is less than **Cn018** switching condition: Controlled by PI;

When acceleration command is more than **Cn018** switching condition: Controlled by P only.


Here below is the diagram:



(4) Estimating position error value to switch PI/P-mode

When position error value is less than **Cn019** switching condition: Controlled by PI; When position error value is more than **Cn019** switching condition: Controlled by P only.

Here below is the diagram:




(5) Using input contact **PCNT** to switch PI/P-mode

When input contact **PCNT** doesn't operate: Controlled by PI;

When input contact **PCNT** operates: Controlled by P only.

Here below is the diagram:



P.S.: Input contacts status 1 means on; 0 means off. Please check 5-6-1 to set high electric potential or low electric potential.

2 Stages Gain Switching Mode

Select Cn015.1 (estimating-type selection of 2 stages gain mode) and set the switching conditions of 2 stages gain mode at related parameter, before using 2 stages gain switching mode. The difference between PI/P-mode and this mode is that, this mode contains the delay time setting. Here below is the description:

Parameter Signal	Name	Setting	Description	Control Mode
Cn015.1 	Estimating-type selection of 2 stages gain mode	0	Estimating if torque command is more than Cn021	Pi/Pe/S
		1	Estimating if speed command is more than Cn022	
		2	Estimating if acceleration command is more than Cn023	
		3	Estimating if position error value is more than Cn024	
		4	Using input contact G-SEL to switch	

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Cn020	Delay time of 2 stages gain mode	0	x0.2msec	0~10000	Pi/Pe/S
Cn021	Switching condition of 2 stages gain mode (torque command)	200	%	0~399	Pi/Pe/S
Cn022	Switching condition of 2 stages gain mode (speed command)	0	rpm	0~4500	Pi/Pe/S
Cn023	Switching condition of 2 stages gain mode (acceleration command)	0	rps/s	0~18750	Pi/Pe/S

Cn024	Switching condition of 2 stages gain mode (position error value)	0	pulse	0~50000	Pi/Pe/S
-------	--	---	-------	---------	---------

P.S.: The 1st gain contains **Pn310**(position loop gain 1), **Sn211**(speed loop gain 1) and **Sn212**(Speed loop integral time constant 1).

The 2nd gain contains **Pn311**(position loop gain 2), **Sn213**(speed loop gain 2) and **Sn214**(speed loop integral time constant 2).


(1) Estimating torque command to switch 2 stages gain mode

When torque command is less than **Cn021** switching condition: Using the 1st gain control; ↗

When torque command is more than **Cn021** switching condition: Switching to the 2nd gain control; ↗

When torque command is less than **Cn021** switching condition again: Switching to the 1st gain control in accordance with **Cn020** switching delay time.

Here is the diagram:




(2) Estimating speed command to switch 2 stages gain mode

When speed command is less than **Cn022** switching condition: Using the 1st gain control; ↗

When speed command is more than **Cn022** switching condition: Switchng to the 2nd gain control; ↗

When speed command is less than **Cn022** switching condition again: Switching to the 1st gain control in accordance with **Cn020** switching delay time.




سازنده انواع ماشین آلات صنعتی و ماشین مخصوص
WWW.CNCREZA.IR

(3) Estimating acceleration command to switch 2 stages gain mode

When acceleration command is less than **Cn023** switching condition: Using the 1st gain control. ⇨


When acceleration command is more than **Cn023** switching condition: Switching to the 2nd gain control ⇨ When acceleration command is less than **Cn023** switching condition again: Switching to the 1st gain control in accordance with Cn020 switching delay time.



(4) Estimating position error value to switch 2 stages gain mode

When position error value is less than **Cn024** switching condition: Using the 1st gain control; ⇨

When position error value is more than **Cn024** switching condition: Switching to the 2nd gain control; ⇨ When position error value is less than **Cn024** switching condition again: Switching to the 1st gain control in accordance with Cn020 switching delay time. Here is the diagram:




(5) Using input contact **G-SEL** to switch 2 stages gain mode

When the input contact **G-SEL** doesn't work: Using the 1st gain control; ↗

When the input contact **G-SEL** works: Switching to the 2nd gain control; ↗

When the input contact **G-SEL** doesn't work again: Switching to the 1st gain control in accordance with **Cn020**

switching delay time. Here is the diagram:




P.S.: Input contacts status 1 means on; 0 means off. Please check 5-6-1 to set high electric potential or low electric potential

5-3-12 Other Speed Control Functions

Speed Achieve Function

When the speed of CW or CCW is more than the speed in **Cn007** (Value of speed achieve), output contact INS will work:

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Cn007	Value of speed achieve	1000	rpm	0~4500	S/T




P.S.: Input contacts status 1 means on; 0 means off. Please check 5-6-1 to set high electric potential or low electric potential

Zero Speed Function

When the speed is less than the speed in Sn215 (Value of ZS), the output contact **ZS** works:


Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Sn215	Value of zero speed	50	rpm	0~4500	S



P.S.: Input contacts status 1 means on; 0 means off. Please check 5-6-1 to set high electric potential or low electric potential

User can set Sn204 () to "1". When the Zero-Speed is complete, the speed command is regarded as "0":

Parameter Signal	Name	Setting	Description	Control Mode
Sn204	Operation of Zero Speed completed	0	No any operation	S
		1	Regarding speed commands as zero speed	





In speed mode: the Servo Lock is used to lock servo motor when input voltage command is not 0V. When input contact **LOK** operates: Although this device stays in speed mode, it will change to internal position control mode temporarily to make the motor be fixed. Please refer to **5-6-1** to set input contact **LOK** function.



When the system causes abnormal vibration or noise, user can adjust **Cn032** (speed feed back smooth filter) to restrain vibration or noise. To add this filter will delay the respond speed of servo system.

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Cn032	Speed feed back smooth filter	0	Hz	0~1000	Pe/Pi/S




5-4 Position Mode

Position Mode is used to high-precision system. Ex: all kinds of machines or machine tools of industry...etc. . The Position Mode has 2 kinds of input mode: External pulse command input mode and internal position command mode. External pulse command input mode: Receiving the pulse command from host controller to achieve fixed position function; internal position command mode: The user use 16 groups of command parameters (**Pn317~Pn364**), then use input contacts **POS1 ~ POS4** to switch related position command. User set the **Cn001** (control mode selection) depending on necessary applications. Here below is the setting method:

Parameter Signal	Name	Setting	Description	Control Mode
★Cn001	Control mode selection	2	Position control (External pulse command) Using one pulse command signal control position, please refer to 5-4-3.	ALL
		6	Position control (Internal pulse command) User can use input contacts to switch internal default 16-stages position command to control position. Please refer to 5-4-2.	



★The setting will be in effect after returning on the power.

The diagram below shows the position loop control. Their detail functions are described in following chapters.















5-4-1 External Pulse Command Mode


The pulse command comes from external device. There are 3 kinds of pulse types to be selected. Each types can be programmed to be the positive or negative logic. User can set the corresponding type in accordance with external input pulse command type. Here is the method:



Parameter Signal	Name	Setting	Description	Control Mode
★Pn301.0 	Position pulse command selection	0	(Pulse)+(Sign)	Pe
		1	Pulse from (CCW)and (CW)	
		2	AB-Phase Pulse $\times 2$	
		3	AB-Phase Pulse $\times 4$	
★Pn301.1 	Position pulse command logic selection	0	Positive Logic	Pe
		1	Negative Logic	

★The setting will be in effect after returning on the power.

Position pulse command types	Positive Logic		Negative Logic	
	CW Command	CCW Command	CW Command	CCW Command
(Pulse)+ (Sign)				
(CCW)/ (CW) Pulse				
AB-Phase Pulse				

There are 2 kinds of interfaces of pulse command: (Open collector) and (Line driver). Please refer to 2-2-1 to check the wiring method. Please input the pulse command in accordance with the time sequence standard below.

Pulse Command Types	Time Sequence Diagram of Pulse Command	Time Standard
(Pulse)+ (Sign)		<p>LineDrive: $t_1, t_2 \leq 0.1\mu s, t_3 > 3\mu s$ $\tau \geq 1.0\mu s$ $(\tau/T) \leq 50\%$</p> <p>OpenCollector: $t_1, t_2 \leq 0.2\mu s$ $t_3 > 3\mu s$ $\tau \geq 2.0\mu s$ $(\tau/T) \leq 50\%$</p>

(CCW)/ (CW) Pulse		LineDrive: $t1, t2 \leq 0.1\mu s$ $t3 > 3\mu s$ $\tau \geq 1.0\mu s$ $(\tau/T) \leq 50\%$
AB-Phase Pulse		LineDrive: $t1, t2 \leq 0.1\mu s$ $\tau \geq 1.0\mu s$ $(\tau/T) \leq 50\%$ OpenCollector: $t1, t2 \leq 0.2\mu s$ $\tau \geq 2.0\mu s$ $(\tau/T) \leq 50\%$

This device provide a input contact **INH**. When this contact operates, pulse command \nrightarrow input limit. Which means this device doesn't receive any pulse command. Here is the description :

Input Contact INH	Description	Control Mode
0	Receiving pulse command	Pe
1	No receiving pulse command	

P.S.: Input contacts status 1 means on; 0 means off. Please check **5-6-1** to set high electric potential or low electric potential

5-4-2 Internal Position Command Mode

The command source in this mode is from 16 groups of command parameters (**Pn317~Pn364**). It corresponds with programmed input contacts **POS1~POS4** to switch the corresponding position command. Each position command match to one command parameter to set the moving speed of its position command. Please refer to the table below:

Position Command	POS4	POS3	POS2	POS1	Position Command Parameters		Moving Speed Parameters
P1	0	0	0	0	Rotating Number	Pn317	Pn319
					Pulse Number	Pn318	
P2	0	0	0	1	Rotating Number	Pn320	Pn322


					Pulse Number	Pn321	
P3	0	0	1	0	Rotating Number	Pn323	Pn325
					Pulse Number	Pn324	
P4	0	0	1	1	Rotating Number	Pn326	Pn328
					Pulse Number	Pn327	
P5	0	1	0	0	Rotating Number	Pn329	Pn331
					Pulse Number	Pn330	
P6	0	1	0	1	Rotating Number	Pn332	Pn334
					Pulse Number	Pn333	
P7	0	1	1	0	Rotating Number	Pn335	Pn337
					Pulse Number	Pn336	
P8	0	1	1	1	Rotating Number	Pn338	Pn340
					Pulse Number	Pn339	
P9	1	0	0	0	Rotating Number	Pn341	Pn343
					Pulse Number	Pn342	
P10	1	0	0	1	Rotating Number	Pn344	Pn346
					Pulse Number	Pn345	
P11	1	0	1	0	Rotating Number	Pn347	Pn349
					Pulse Number	Pn348	
Position Command	POS4	POS3	POS2	POS1	Position Command Parameters		Moving Speed Parameters
P12	1	0	1	1	Rotating Number	Pn350	Pn352
					Pulse Number	Pn351	

P13	1	1	0	0	Rotating Number	Pn353	Pn355
					Pulse Number	Pn354	
P14	1	1	0	1	Rotating Number	Pn356	Pn358
					Pulse Number	Pn357	
P15	1	1	1	0	Rotating Number	Pn359	Pn361
					Pulse Number	Pn360	
P16	1	1	1	1	Rotating Number	Pn362	Pn364
					Pulse Number	Pn363	


There are absolute and relative types – internal position command mode in accordance with **Pn316**. Here is the setting:

Parameter Signal	Name	Setting	Description	Control Mode
★Pn316	Internal position command mode	0	Absolute fixing position	Pi
		1	Relative fixing position	


★The setting will be in effect after returning on the power.



In absolute and relative fixing mode (separately): Executing 10 pulse position command ⚡ then executing 20 pulse command. The diagrams below are about the difference of position routes:



After we use input contacts **POS1~POS4** to select the related position command ⚡ to trigger input contact **PTRG** ⚡ then this device will normally accept this position command ⚡ motor rotates. Please refer to the diagram below:




P.S.: Input contacts status 1 means on; 0 means off. Please check 5-6-1 to set

high electric potential or low electric potential


If user would like turn off the motor rotation during the position movement ↗ To trigger the input contact **PHOLD** ↗ and the motor will decelerat and stop.

When the input contact **PTRG** is triggered again ↗ the remaining pulse command will be operated ↗ until the target position(before **PHOLD** triggers) is achieved. Please refer to the diagram below:



P.S.: Input contacts status 1 means on; 0 means off. Please check 5-6-1 to set high electric potential or low electric potential

If user ignores this position command and stop the motor during position movement, user can trigger input contacts **CLR** (**Pn315** must be set **1** or **2**, please refer to **5-4-7**), motor will stop immediately. And the not completely operated pulses will be cleared. When the input contact **PTRG** is triggered again, the motor will rotate in accordance with the position command of what the early **POS1~POS4** set. Please refer to the diagram:



P.S.: Input contacts status 1 means on; 0 means off.


Please check 5-6-1 to set high electric potential or low electric potential

5-4-3 Electronic Gear Ratio

User can use Electronic Gear Ratio to definite the inputted Unit Pulse Command to make the transmission to move to any distance. The Pulse Command from host controller has nothing to do with Transmission System Gear Ratio, Deceleration Ratio or Motor Encoder Pulse Value. Here is the description:

The picture below is about the Servo Motor Transmission Device.

How much Pulse Command must be given by Host Controller, if the 10mm movement of Motion Table is needed?



Without Using Electronic Gear Ratio Function

Using Electronic Gear Ratio Function

1. 1 Rotating of Ballscrew \Rightarrow The Motion Table will move 5mm.
2. If the Motion Table need move 10mm, the Ballscrew need to rotate $10\text{mm} \div 5\text{mm/rev} = 2\text{Rotating}$
3. " 2000pulse/rev \times 4 = 8000pulse" Command will make the motor 1 rotating.
4. So the Host Controllor need give the "8000pulse/rev \times 2 rev = 16000pulse" command

⚠User must count the Pulse Command depending on the steps above when each movement.

⚠Set the Electronic Gear Ratio(Assume: Definiting 1 Pulse Command = moving 1 μ m, the setting method of Electronic Gear Ratio is contained in the next chapter)

1. 1 Pulse value causes 1 μ m movement.
2. If the Motion Table need move 10mm, the Host Controllor need give the $10\text{mm} \div 1\mu\text{m/pulse} = 10000\text{pulse}$ Command.

⚠To definite the distance of 1 Pulse Command and the Electronic Gear Ratio, then the Host Controllor can easily decide the Pulse Command.

To decide the Electronic Gear Ratio in accordance the steps below:

1. To Understand the system specifications:

To get the system standards before deciding Electronic Gear Ratio. Ex: Deceleration Ratio, Gear Ratio, moving value of 1 rotating of load shaft, rotating diameter and the Pulse Value of 1 rotating of Motor Encoder (please refer to 1-1-2 Servo Motor Standards).

2. To Definite the moving distance of 1 Pulse Command

To definite the 1 Pulse Command given by Host Controllor and the distance of transmission system movement. Ex: When 1 Pulse Command move 1 μ m \Rightarrow If the Host Controllor give 2000 pulse command, the transmission device will move: $2000\text{pulse} \times 1\mu\text{m/pulse} = 2\text{mm}$ (The Electronic Gear Ratio must be correctly set).

3. To Count the Electronic Gear Ratio

Counting the electronic gear ratio in accordance with the formula below:

$$ElectronicGearRatio = \frac{LoadMovingDistanceOf1RotatingPulseCommand}{MovingDistanceOf1PulseCommand} \times \frac{m}{n}$$

If the deceleration ratio between motor and load shaft is $\frac{n}{m}$ (m means Motor Rotating Value, n means Load Shaft Rotating Value), and the formula for Electronic Gear Ratio is:

$$ElectronicGearRatio = \frac{MovingDisPulseValueOfMotionOf1RotatingFoTableForrMotorEnco1RotatingOfderLoadShaft \times 4}{MovingDistanceOf1PulseCommand} \div \times \frac{mn}$$

4. Parameter Setting for Electronic Gear Ratio

Reducing the fraction and simplifying the counting for Electronic Gear Ratio to make the Numerator and Denominator to be integer which is less than 50000. Then set the Electronic Gear Ratio – Numerator and Denominator separately into the related parameters. Here is the description below:

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Pn302	Numerator of Electronic Gear Ratio 1	1	X	1~50000	Pi/Pe
Pn303	Numerator of Electronic Gear Ratio 2	1	X	1~50000	Pi/Pe
Pn304	Numerator of Electronic Gear Ratio 3	1	X	1~50000	Pi/Pe
Pn305	Numerator of Electronic Gear Ratio 4	1	X	1~50000	Pi/Pe
★Pn306	Denominator of Electronic Gear Ratio	1	X	1~50000	Pi/Pe

The setting will be in effect after returning on the power.

Attention! The Electronic Gear Ratio must accord with the conditions below, otherwise this device can not work normally.

$$\frac{1}{200} \quad ElectronicGearRatio \leq 200$$

This device contains 4 groups of Numerator of Electronic Gear Ratio. User can use input contacts **GN1** and **GN2** to switch to current necessary Numerator of Electronic Gear Ratio. Please refer to the table below:

Input Contact GN2	Input Contact GN1	Numerator of Electronic Gear Ratio	Control Mode
0	0	Numerator of Electronic Gear Ratio 1 Pn302	Pi/Pe
0	1	Numerator of Electronic Gear Ratio 2 Pn303	
1	0	Numerator of Electronic Gear Ratio 3 Pn304	
1	1	Numerator of Electronic Gear Ratio 4 Pn305	


P.S.: Input contacts status 1 means on; 0 means off. Please check 5-6-1 to set high electric potential or low electric potential



Transmission System

Setting Process

Ball Screw



1. Understanding whole system specifications:

Load Shaft(Ball Screw)moving distance of 1 rotating=5mm

Pulse Value/1 rotating of Motor Encoder =2000pulse

2. Definiting the moving distance of 1 Pulse

Command Moving Distance of 1 Pulse Command=1um 3.


Counting the Electronic Gear Ratio:

$$\text{Electronic Gear Ratio} = \frac{2000 \text{ pulse/rev} \times 4}{5 \text{mm/rev} \div 1 \text{um/pulse}} = \frac{8000}{5000}$$

4. Set the parameter of Electronic Gear Ratio:

Numerator of Electronic Gear Ratio	8000
Denominator of Electronic Gear Ratio	5000

Mechanical Disc



1. Understanding whole system specifications:

DecelerationRatio=1/5

Load Shaft(MechanicalDisc)MovingValue of 1Rotating=360°

PulseValue of 1Rotating for Encoder=2500pulse

2. Definiting the moving distance of 1 Pulse


Command: Distance for 1Pulse Command =0.1° 3.

Counting the Electronic Gear Ratio:

$$\text{Electronic Gear Ratio} = \frac{2500 \text{ pulse/rev} \times 4}{360^\circ \div 0.1^\circ/\text{pulse}} \times \frac{5}{1} = \frac{50000}{3600}$$

4. Set the parameter of Electronic Gear Ratio:

Numerator of Electronic Gear Ratio	50000
Denominator of Electronic Gear Ratio	3600

Transmission System	Setting Process				
<p style="text-align: center;">Transmission Belt</p>  <p>Load Shaft Deceleration Ratio=1/8 Diameter of Idler =100mm Servo Motor Pulse Value Of 1 Rotating for Encoder =8192pulse/rev</p>	<p>1. Understanding whole specifications:</p> <p>Deceleration Ratio=1/8</p> <p>Load Shaft(Idler) Moving Value of 1 Rotating</p> $= 3.14 \times 100\text{mm} = 314\text{mm}$ <p>Pulse Value of 1 Rotating for Encoder =8192pulse</p> <p>2. Definiting the moving distance of 1 Pulse</p> <p>Command: Distance for 1 Pulse Command =10um</p> <p>Counting the Electronic Gear Ratio:</p> $\text{Electronic Gear Ratio} = \frac{8192 \text{ pulse / rev} \times 4}{314\text{mm} + 10 \text{ um / pulse}} \times \frac{8}{1} = \frac{262144}{31400}$ <p>4. Set the parameter of Electronic Gear Ratio:</p> <p>Reducing the fraction and simplifying the counting for Electronic Gear Ratio to make the Numerator and Denominator to be integer which is less than 50000.</p> <table border="1" data-bbox="906 969 1289 1162"> <tr> <td>Numerator of Electronic Gear Ratio</td> <td>32768</td> </tr> <tr> <td>Denominator of Electronic Gear Ratio</td> <td>3925</td> </tr> </table>	Numerator of Electronic Gear Ratio	32768	Denominator of Electronic Gear Ratio	3925
Numerator of Electronic Gear Ratio	32768				
Denominator of Electronic Gear Ratio	3925				


5-4-4 One Time Smooth Ac/Deceleration of Position Command

Using the function , "One Time Smooth Ac/Deceleration of Position Command" will smoothlize the position pulse command of fixed frequency.

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
★Pn313	Time Constant of One Time Smooth Ac/Deceleration of Position Command	10	msec	0~10000	Pi/Pe

★The setting will be in effect after returning on the power.

The definition of **Time Constant of One Time Smooth Ac/Deceleration of Position Command**: The Time in which The Position Pulse Frequency increases (one time) from zero to 63.2% of Position Pulse Command Frequency. Here below is the Diagram:




Setting Example:

(1) If achieving 95% of Position Pulse Command Frequency Output in 30msec:

$$Pn313 = \frac{30(\text{msec})}{-\ln(1 - 95\%)} = 10(\text{msec})$$

(2) If achieving 75% of Position Pulse Command Frequency Output in 30msec:

$$Pn313 = \frac{30(\text{msec})}{-\ln(1 - 75\%)} = 22(\text{msec})$$




5-4-5 Definition of Position Command Direction

In position mode, user can use Pn314 (Position Command Direction Definition) to definite motor rotating direction.

The setting is showed as follow:

WWW.CNCREZA.IR

Parameter Signal	Name	Setting	Description	Control Mode
Pn314	Definition of position command direction (from motor loading terminal)	0	(CW)	★Pi Pe
		1	(CCW)	



★The setting will be in effect after returning on the power


5-4-6 Adjusting of Position Loop Gain

The table below is about the parameter of position control loop. This device provides 2 groups of position controller.

User can use gain switching function to change it. (Please refer to 5-3-11)

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Pn310	Position Loop Gain1	40	1/s	1~450	Pe/Pi
Pn311	Position Loop Gain 2	40	1/s	1~450	Pe/Pi
Pn312	Position Feed-Forward Gain	0	%	0~100	Pe/Pi
Cn033	Speed Feed-Forward Smooth Filter	0	Hz	0~1000	Pe/Pi

The picture below is the position controller. More the position loop gain is, faster the response speed is. Which shortens the adjust-time. User can also use Position Feed-Forward Gain to shorten adjust-time. Please refer to 5-5 to check the method of Position Loop Control Gain Adjusting.



5-4-7 Pulse Incorrect Value Clear

In position mode, user can use **Pn315** (Pulse Incorrect Value Clear Mode) to definite the operation method of input contact **CLR**. The setting is showed as follow:

Parameter Signal	Name	Setting	Description	Control Mode
Pn315	Pulse Incorrect Value Clear Mode	0	When CLR works, pulse incorrect value is clear.	Pe
		1	When CLR is turned on: canceling the position command to stop motor rotating; resetting the mechanical Home and clearing the pulse incorrect value.	Pi Pe

		2	When CLR is turned on: canceling the position command to stop motor rotating and clearing the pulse incorrect value.	Pi
--	--	---	---	----

P.S.: Please refer to 5-6-1 to set high or low electric potential at input contact.




5-4-8 Home



When using the function “HOME”, user can use input contacts **ORG**, **CCWL**, or **CWL** to be reference HOME; user can also use **Z** Phase to be the referent HOME and select CW or CCW to search it. Here is the description:

Parameter Signal	Name	Setting	Description	Control Mode
Pn365.0 	When turning on Home, setting of searching direction and selecting reference Home.	0	After Home is turned on, motor will search Home in 1 st stege speed CW and take the input contacts CCWL and CWL to be the Reference Home. After Home has been in position, the input contacts CCWL and CWL will be Inhibit Limit again. When using this function, Pn365.1 can not be set to 1 or 2 . Attention! Cn002.1 (selection for CCWL and CWL) must be set to 0.	Pi/Pe
		1	After Home is turned on, motor will search Home in 1 st stege speed CCW and take the input contacts CCWL and CWL to be the Reference Home. After Home has been in position, the input contacts CCWL and CWL will be Inhibit Limit again. When using this function, Pn365.1 can not be set to 1 or 2 . Attention! Cn002.1 (selection for CCWL and CWL) must be set to 0.	
		2	After Home is turned on, motor will search Home in 1 st stege speed CW and take the input contact ORG to be the reference Home. If Pn365.1=2 , it will directly find the closest Rising-Edge of ORG to be the Home without Reference Home. Then stopping in accordance with Pn365.3 setting.	
		3	After Home is turned on, motor will search Home in 1 st stege speed CCW and take the input contact ORG to be the reference Home. If Pn365.1=2 , it will directly find the closest Rising-Edge of ORG to be the Home without Reference Home. Then stopping in accordance with Pn365.3 setting.	
		4	After Home is turned on, motor will search Home in 1 st stege speed CW and find the closest Z Phase Home without Referent Home. When using this function, Pn365.1=2 must be set. (After finding Z Phase to be the Home, it stops in accordance with Pn365.3 setting).	

		5	After Home is turned on, motor will search Home in 1 st stage speed CCW and find the closest Z Phase Home without Referent Home. When using this function, Pn365.1=2 must be set. (After finding Z Phase to be the Home, it stops in accordance with Pn365.3 setting).
--	--	---	--

Parameter Signal	Name	Setting	Description	Control Mode
Pn365.1 	After finding Reference Home, searching Home moving method	0	After finding Reference Home, Motor returns in 2 nd stage speed to find the closest Z Phase pulse to be the Home, then stops in accordance with Pn365.3 setting method.	Pi/Pe
		1	After finding Reference Home, Motor continues ahead in 2 nd stage speed to find the closest Z Phase pulse to be the Home, then stops in accordance with Pn365.3 setting method.	
		2	When Pn365.0=2 or 3 , it finds the rising edge of ORG to be the Home, then stops in accordance with Pn365.3 ; when Pn365.0=4 or 5 , it finds Z Phase pulse to be the Home, then stops in accordance with Pn365.3 .	
Pn365.2 	Setting of Home turning on Mode	0	Function of turning off Home	Pi/Pe
		1	After power on, only first time excuting Servo On will automatically operates Home function. When Home function is no needed to be repeatedly operated during the servo is working, user can use this mode to omit a input contact which is used to excute Home function.	
		2	Use SHOME to turn on Home function. In position mode, user can turn on SHOME to operate Home function at any moment.	
Pn365.3 	Setting of stopping mode after finding Home	0	After finding Home signal, recording this position to be the Home (Un-14 encoder feed back rotating number and Un-15 encoder feed back pulse number are all 0), motor will stop. Motor returns in 2 nd stage speed to move to the Home Position after motor stops.	Pi/Pe
		1	After finding Home signal, recording this position to be the Home (Un-14 encoder feed back rotating number and Un-15 encoder feed back pulse number are all 0), motor stops.	



User needs to set **Pn365** in accordance with different applications. The table list below is about the setting value:

Pn365.0 \ Pn365.1	0	1	2	3	4	5
0	●	●	●	●	×	×
1	×	×	●	●	×	×
2	×	×	●	●	●	●

● means HOME operates normally; × means there is no HOME operation

The Speed of HOME is described as follow:


Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Pn366	1 st stage-high speed of HOME	100	rpm	0~2000	Pi/Pe
Pn367	2 nd stage-low speed of HOME	50	rpm	0~500	Pi/Pe

User can set the Home incorrect rotating number/pulse number. After Motor finds the Home position in accordance with **Pn365** (Home Mode), it will be the new Home position in accordance with **Pn368** (Home incorrect rotating number) and **Pn369** (Home incorrect pulse number). The setting follows as below:

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Pn368	Shift rotating value of HOME	0	rev	-30000~30000	Pi/Pe
Pn369	Shift pulse value of HOME	0	pulse	-32767~32767	Pi/Pe

Timing Charts for Home Turning On Mode

During the process of Home: If user cancels **SON** (Servo On) or any alarm happens, Home function will stop and **HOME** (completed Home) doesn't work.



P.S.: Input contacts status 1 means on; 0 means off. Please check 5-6-1 to set high electric potential or low electric potential



The table list below is about the speed/position timing charts of HOME for different **Pn365** setting:

Pn365.0 \ Pn365.1	0	1	2	3	4	5
0	(1)	(2)	(1)	(2)	×	×
1	×	×	(3)	(4)	×	×
2	×	×	(5)	(6)	(7)	(8)

× means no operating HOME function


(1)

Pn365.0=0 or 2(After turning on HOME, CW in 1st stage speed to find Reference HOME: CCWL, CWL or ORG)

Pn365.1=0(After finding Reference HOME, **returning** in 2nd speed to find the closest Z Phase pulse to be the HOME)

Pn365.2=2(Input Contact SHOME turning on HOME)

Pn365.3=0(Returning to HOME)




(2)

Pn365.0=1 or 3(After turning on HOME, CCW in 1st stage speed to find Reference HOME: CWL, CCWL or ORG)

Pn365.1=0(After finding Reference HOME, **returning** in 2nd stage speed to find the closest Z Phase pulse to be the HOME)

Pn365.2=2(Input Contact SHOME turning on HOME) **Pn365.3=0**(Returning to HOME)




(3)

Pn365.0=2(After turning on HOME, CW in 1st stage speed to find Reference HOME: ORG)

Pn365.1=1(After finding Reference HOME, **continue going ahead** in 2nd stage speed to find the closest Z Phase to be the HOME)

Pn365.2=2(Input Contact SHOME turning on HOME)

Pn365.3=0(Returning to the HOME)



(After turning on HOME, CCW in 1st


(4)

Pn365.0=3 stage speed to find the Reference HOME: **ORG**)

Pn365.1=1(After finding Reference HOME, **continue going ahead** in 2nd stage speed to find the closest **Z** Phase pulse to be the HOME)

Pn365.2=2(Input Contact **SHOME** turning on HOME)

Pn365.3=0(Returning to the HOME)



سازنده انواع ماشین آلات صنعتی و ماشین مخصوص

WWW.CNCREZAJR

(5)


Pn365.0=2(After turning on HOME, CW in 1st stage speed to find the Reference HOME: **ORG**)

Pn365.1=2(Finding the Reference HOME: the Rising Edge of **ORG** to be the HOME)

Pn365.2=2(Input Contact **SHOME** turning on HOME)

Pn365.3=0(Returning to the HOME)

(After turning on HOME, CCW in 1st




(6)

Pn365.0=3 stage speed to find the Reference HOME: **ORG**)

Pn365.1=2(Finding the Reference HOME: the Rising Edge of **ORG** to be the HOME)

Pn365.2=2(Input Contact **SHOME** turning on HOME) **Pn365.3=0**(Returning to the HOME)




(7)

Pn365.0=4(After turning on HOME, CW in 1st stage speed to find the closest HOME of Z Phase pulse)

Pn365.1=2(Finding Z Phase pulse to be the HOME)

Pn365.2=2(Input Contact **SHOME** turning on HOME) **Pn365.3=0**(Returning to the HOME)

(After turning on HOME, CCW in 1st




(8)

Pn365.0=5 stage speed to find the closest HOME of Z Phase pulse)

Pn365.1=2(Finding the Z Phase pulse the be the HOME)

Pn365.2=2(Input Contact **SHOME** turning on HOME) **Pn365.3=0**(Returning to the HOME)




5-4-9 Other Position Control Function



When the position incorrect value is less than the pulse value which is set in **Pn307** (Position Complete value), **INP** will work. Here is the Explanation:

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Pn307	Position Complete value	10	pulse	0~50000	Pi/Pe



P.S.: Input contacts status 1 means on; 0 means off. Please check 5-6-1 to set high electric potential or low electric potential.




When the Position Incorrect value is more than the pulse value which is set in **Pn308** (Positive Max Position Incorrect value) or **Pn309** (Position Max Position Incorrect value), **AL-11** (Alarm of Over Position Incorrect Value) occurs. Here is the setting:

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Pn308	Positive Max Position Incorrect value	50000	pulse	0~50000	Pi/Pe
Pn309	Positive Max Position Incorrect value	50000	pulse	0~50000	Pi/Pe

5-5 Adjusting for Servo Gain

The Servo contains 3 kinds of Loop: Current Control, Speed Control and Position Control. Here is the picture.



Theoretically, the bandwidth of inside control loop must be higher than the bandwidth of outside. Otherwise, whole control system will astaticism, then it will cause vibration or abnormally response. The relation of these 3 control loop bandwidths will be showed as follow:

Current Control Loop Bandwidth (Inside) > Speed Control Loop Bandwidth (Middle Side) > Position Control Loop Bandwidth (Outside)

Because the default current control circuit bandwidth has been already the best situation, the user need to only adjust speed and position control loop gain. The Table List below is the related parameters for gain adjusting.

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Sn211	Speed Loop Gain 1	40	Hz	10~450	Pe/Pi/S
Sn212	Speed Loop Integration Time Constant 1	100	x0.2 msec	1~500	Pe/Pi/S
Sn213	Speed Loop Gain 2	40	Hz	10~450	Pe/Pi/S
Sn214	Speed Loop Integration Time Constant 2	100	x0.2 msec	1~500	Pe/Pi/S
Pn310	Position Loop Gain 1	40	1/s	1~450	Pe/Pi
Pn311	Position Loop Gain 2	40	1/s	1~450	Pe/Pi
Pn312	Position Loop Feed-Forward Gain	0	%	0~100	Pe/Pi
Cn025	Load Inertia Ratio	70	x0.1	0~1000	Pe/Pi/S



Speed Loop Gain decides directly the Response Bandwidth of Speed Control Loop. Under the situation of no vibration or noise, higher is the Speed Loop Gain Value, faster is the Speed Response.

If **Cn025**(Load Inertia Ratio) is correctly set: **Speed Loop Bandwidth** = **Sn211** (Speed Loop Gain1) or **Sn213** (Speed Loop Gain2).

$$\text{Load Inertia Ratio} = \frac{\text{Load Inertia transformed to Motor Shaft } (J_L)}{\text{Inertia of Servo Motor Rotor } (J_M)} \times 100\%$$



Adding integral items in Speed Control Loop can delete the error of stabilizing Speed and responds fine speed changing quickly. Basically, under the situation of no vibration or noise, reducing Integral Time Constant of Speed Loop can enhance system rigidity. If the Load Inertia Ratio is very high or the system has vibration factors, user must confirm Speed Loop Integral Time Constant is also high enough, otherwise the mechanical system would produce co-vibration easily. Using the formula below to get the Integral Time Constant of Speed Loop:

$$\text{Sn212 (Integral Time Constant 1 of Speed Loop)} \geq 5 \times \frac{1}{2\pi \times \text{Sn211 (Speed Loop Gain1)}}$$

Setting Example:

Assume: **Cn025** (Load Inertia Ratio) is correctly set, target Speed Loop Bandwidth achieves 100Hz, so user sets:

Sn211(Speed Loop Gain 1)=100(Hz) سازنده انواع ماشین آلات صنعتی و ابزارآلات

$$\text{Sn212 (Integral Time Constant 1 of Speed Loop)} \geq 5 \times \frac{1}{2\pi \times 100} = 40 (\times 0.2\text{msec})$$



Position Loop Gain decides directly the response speed of Position Loop. Under the situation of no vibration or noise from servo, increasing the Position Loop Gain Value can enhance response speed to reduce the time for in position.



Using Position Loop Feed-Forward can enhance response speed. If the Feed-Forward is too high, overshooting and **INP** (In Position Signal) abnormally repeating switching will be possible. So user must observe Speed Curve and **INP** (In Position Signal) at the same time, then increase Feed-Forward Value slowly. If Position Loop Gain is too high, Feed-Forward function will be unobvious.



There are Gain Adjusting Quick-Parameter in this device. The related Gain Adjustin parameters are in the Quick-Parameter folder. Which gives users convenience of adjusting when Gain Adjusted by hand.


When user change the parameter value, the value will **be saved immediately and in effect right away** without pressing Enter-Key. The table list below shows the Gain Adjusting Quick-Parameter.

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
◆qn401	Speed Loop Gain 1	40	Hz	10~450	Pe/Pi/S
◆qn402	Integral Time Constant 1 of Speed Loop	100	x0.2 msec	1~500	Pe/Pi/S
◆qn403	Speed Loop Gain 2	40	Hz	10~450	Pe/Pi/S
◆qn404	Integral Time Constant 2 of Speed Loop	100	x0.2 msec	1~500	Pe/Pi/S
◆qn405	Position Loop Gain 1	40	1/s	1~450	Pe/Pi
◆qn406	Position Loop Gain 2	40	1/s	1~450	Pe/Pi
◆qn407	Position Loop Feed-Forward Gain	0	%	0~100	Pe/Pi

◆Be in effect immediately without pressing Enter-Key

5-5-1 Autotuning

This device provides ON-LINE Autotuning, which can quickly and precisely measure Load Inertia and adjust adequate the Gain automatically. Here is the setting:

Parameter Signal	Name	Setting	Description	Control Mode
Cn002.2 	Autotuning	0	No using Autotuning	Pe/Pi/S
		1	Keep using Autotuning	

When user set **0** in **Cn002.2** No Autotuning. User must adjust the related Gain Adjusting parameters below:

Parameter Signal	Name
Cn025	Set for Autotuning

Sn211	Speed Loop Gain 1
Sn212	Integral Time Constant 1 of Speed Loop
Sn213	Speed Loop Gain 2
Sn214	Integral Time Constant 2 of Speed Loop
Pn310	Position Loop Gain 1
Pn311	Position Loop Gain 2
Pn312	Position Loop Feed-Forward Gain

When user set **1** in **Cn002.2**, it means continuing to use Autotuning. The Servo will adjust adequate Servo Gain in accordance with **Cn026** (Rigidity Setting) and had been measured Load Inertia Ratio. Observing Un-19 (Load Inertia Ratio), when the Load Inertia Ratio is getting stable, user can set **0** in **Cn002.2** to cancel Autotuning. At that moment, servo will record the measured Load Inertia Ratio into **Cn025** (Load Inertia Ratio). If servo is used in a appliance of few variation of Load, we suggest users turn off Autotuning when **Un-19** (Load Inertia Ratio) is getting stable.



The Servo provides Autotuning and use high-class control theory "ON-LINE" to measure Load Inertia Ratio to control system to achieve default speed or Position Response Bandwidth.

System must match the conditions below, so the Autotuning can operate normally.

- (1) The timing from stop to 2000rpm need be less than 1 second.
- (2) Working speed needs be more than 200rpm.
- (3) Load Inertia needs be 100 times less than the inertia from motor.
- (4) Outside force or the variation of Inertia Ratio can not be over violent.




When Autotuning is used, user should set the Rigidity Level depends on many kinds of Gain in a broad application. The table list below shows the rigidity setting range in a broad application.

Rigidity Setting Cn026	Position Loop Gain Pn310 [1/s]	Speed Loop Gain Sn211 [Hz]	Integral Time Constant of Speed Loop Sn212 [x0.2msec]	Mechanical Rigidity	Application
1	15	15	300	Low	The machines driven by Synchronous Belt, Chain or Gear: Man-size Moving Table, Transit Belt.
2	20	20	225		
3	30	30	150		
4	40	40	100	Middle	The machines driven by Ballscrew though decelerator: Ordinary machines, Mechanics arms, moving Machine.
5	60	60	75		
6	85	85	50		
7	120	120	40		
8	160	160	30		
9	200	200	25		
A	250	250	20		
				High	The machines driven by Ballscrew: High precision Machines, Metal engraving Machine, Insertion Machine and IC inspection Machine.

The Diagram below show the process for Autotuning.

سازنده انواع ماشین آلات صنعتی و ماشین مخصوص
WWW.CNCREZA.IR



P.S.: After operate Autotuning (Cn002.2=1): if no set 0 in Cn002.2, it will not record the present measured Load Inertia Ratio when cutting power ↗ When the Autotuning is operated next time again, servo will use the early setting Load Inertia Ratio in Cn025 starting to measure.

5-5-2 Manul Gain Adjusting



Step 1: Please refer to 5-5-1(Autotuning) to set Rigidity Level then get the correct Load Inertia Ratio.

Step 2: If servo system combines with Host Controller to become the Position Control, set the Position Loop Gain of Host Controller to related low value.

Step 3: Manul adjusting **Sn211**(Speed Loop Gain1):

Setting the value in **Sn212** (Integral Time Constant 1 of Speed Loop) higher than the value which is set after Autotuning ↗ Increasing the Speed Loop Gain till there is no vibration or noise ↗ Then decreasing the Speed Loop Gain slowly and enhancing Position Loop Gain of Host Controller till there is no vibration or noise. **Step 4:** Manul Adjusting **Sn212**(Integral Time Constant 1 of Speed Loop):

Under the condition of no producing mechanical vibration to decrease the Integral Time Constant of Speed Loop to shorten settling time.

Step 5: Finally, slowly adjusting the Speed Loop Gain, Position Loop Gain of Host Controller and Integral Time Constant of Speed Loop until servo has the best response.



Step 1: Please refer to 5-5-1 (Autotuning) to set Rigidity Level then get the correct Load Inertia Ratio.

Step 2: Setting the value in **Pn310** (Position Loop Gain1) lower than the value which is set after Autotuning ↗ Setting to related high value in **Sn212** (Integral Time Constant 1 of Speed Loop).

Step 3: Manul Adjusting **Sn211** (Speed Loop Gain 1):

Increasing the Speed Loop Gain until there is no vibration or noise.

Step 4: Manul Adjusting **Pn310** (Position Loop Gain 1):

Slowly decreasing the Speed Loop Gain again, then increasing the Position Loop Gain until there is no vibration or noise.

Step 5: Manul adjusting **Sn212** (Integral Time Constant 1 of Speed Loop):

Under the condition of no producing mechanical vibration to decreasing the Integral Time Constant of Speed Loop and shorten settling time.

Step 6: Finally, slowly adjusting the Speed Loop Gain, Position Loop Gain and the Integral Time Constant of Speed Loop until the servo has the best response.

5-5-3 Improvement for Response Feature

The Servo provides the function of Gain Switching and Position Loop Feed-Forward Gain to improve system Response Feature. Attention! The 2 functions must be correctly used, so it can improve the Response Feature. Otherwise, the Response will become woress. Here is the description below:



The Gain Switch of this servo contains Speed Loop Gain PI/P Switching and 2-stage Gain Switching. Here is the

Applications below:

- (1) Restraining the overshooting of ac/deceleration in speed control.
- (2) Restraining the vibration range result from In Position and shortening settling time in position control.
- (3) Decreasing the noise result from Servo Lock Please refer to **5-3-11**



Using Position Loop Feed-Forward Gain can reduce the error result from position control and enhance the response speed. If the Position Loop Gain is high enough, the effects of this function won't be well. So It is used under the situation, in which user needs high response speed, but the gain value can't be high enough.


The adjusting steps is showed as follow:

Step 1: Refer to the processes in **5-5-1~5-5-2** to adjust Speed and Position Gain.

Step 2: Slow increase **Pn312**(Position Feed-Forward Gain), and observe the **INP** (Signal of In Position) at the same time to cause it output fast and shorten the settling time. Attention: the Position Loop Feed-Forward Gain can not too high, otherwise it will cause speed overshooting and **INP** (Signal of In Position) repeatedly turning on and off.


5-6 Other Functions 5-6-1 I/O Programmed Functions

This device has 13 DI contacts and 4 DO contacts which is programmable. Here is the description below:

Parameter Signal	Name	Setting	Description		Control Mode
★Hn501.0 ★Hn501.1 	DI-1 Function		Signal	Contact Function	ALL
		01	SON	Servo On	
		02	ALRS	Alarm Clear	
		03	PCNT	PI/P Switching	
		04	CCWL	CCW Limit	
		05	CWL	CW Limit	
		06	TLMT	External Torque Limit	
		07	CLR	Clear of Pulse Incorrect Value	
		08	LOK	Servo Lock	

09	EMC	Emergency Stop
10	SPD1	Speed 1
11	SPD2	Speed 2
12	MDC	Mode Changing
13	INH	Inhibition of Position Command
14	SPDINV	Speed Inverse
15	G-SEL	Gain Settle
16	GN1	Electronic Gear Ratio Numerator 1
17	GN2	Electronic Gear Ratio Numerator 2
18	PTRG	Position Trigger
19	PHOLD	Position Hold
20	SHOME	Start Home
21	ORG	Reference Origin
22	POS1	Position 1
23	POS2	Position 2
24	POS3	Position 3
25	POS4	Position 4
26	TRQINV	Torque Inverse
27	RS1	Torque CW Selecting
28	RS2	Torque CCW Selecting



★The setting will be in effect after returning on the power.

Parameter Signal	Name	Setting	Description	Control Mode
★Hn501.2 	DI-1 Electric Potential	0	When the contactor is Low Electric Potential (Close loop to IG24), the function works.	ALL
		1	When the contactor is High Electric Potential (Open loop to IG24), the function works.	

★The setting will be in effect after returning on the power.

Parameter Signal	Name	Description	Control Mode
★Hn502	DI-2 Programming	Please refer to Hn501 to check the setting method.	ALL
★Hn503	DI-3 Programming		
★Hn504	DI-4 Programming		
★Hn505	DI-5 Programming		
★Hn506	DI-6 Programming		
★Hn507	DI-7 Programming		
★Hn508	DI-8 Programming		
★Hn509	DI-9 Programming		
★Hn510	DI-10 Programming		
★Hn511	DI-11 Programming		
★Hn512	DI-12 Programming		
★Hn513	DI-13 Programming		

Attention! The functions of DI-1 ~ DI-13 could be repeat, but the contactors electric potential of repeated functions must be the same, otherwise there will be AL-07 (Abnormal alarm of DI/DO programming).

Parameter Signal	Name	Setting	Description	Control Mode	
★Hn514.0 ★Hn514.1 	DO-1 Electric Potential	Code	Contactor functions	ALL	
		01	RDY		Servo Ready
		02	ALM		Alarm
		03	ZS		Zero Speed
		04	BI		Brake Signal
		05	INS		In Speed
		06	INP		In Position
		07	HOME		HOME
★Hn514.2 	DO-1 Electric Potential	0	When the contactor is Low Electric Potential (Close loop to IG24), the function works.	ALL	
		1	When the contactor is High Electric Potential (Open loop to IG24), the function works.		

★The setting will be in effect after returning on the power.

Parameter Signal	Name	Description	Control Mode
★Hn515	DO-2 Programming		ALL

★Hn516	DO-3 Programming	Please refer to Hn514 to check setting method	
★Hn517	DO-4 Programming		

Attention! The functions of DI-1 ~ DI-4 could be repeat, but the contactors electric potential of repeated functions must be the same, otherwise there will be AL-07 (Abnormal alarm of DI/DO programming).

5-6-2 Control Mode Switching

User can use Input Contactor MDC to switch Control Mode set by Cn001. Here is the setting below:



Parameter Signal	Name	Setting	Description	Control Mode	
★Cn001	Control Mode Selecting		Input Contactor MDC doesn't working	Input Contactor MDC works	ALL
		3	Position Control(External Pulse Command)	Speed Control	
		4	Speed Control	Torque Control	
		5	Position Control (External Pulse Command)	Torque Control	

★The setting will be in effect after returning on the power.

P.S.: Input contacts status 1 means on; 0 means off. Please check 5-6-1 to set high electric potential or low electric potential

5-6-3 Contactor Accessory Functions

User can depend upon the Input Contactors SON, CCWL and CWL to decide if turning the related functions on. Here is the setting method below:

Parameter Signal	Name	Setting	Description	Control Mode
★Cn002.0 	SON Selecting	0	Use SON to switch Servo On.	ALL
		1	Servo on when Power on without using SON to turn the Servo on	
Cn002.1 	CCWL and CWL Selecting	0	Using CCWL and CWL to switch CCW and CW driving inhibit.	ALL
		1	Switching CCW and CW driving Inhibit without using CCWL and CWL, ignoring CCW and CW drive inhibit function	

★The setting will be in effect after returning on the power.

5-6-4 Braking Mode

User can set the Brake Combination when the Servo off, Emergency Stop and CCW/CW driving inhibit occur. Here is the setting below:

Parameter Signal	Name	Setting	Description	Control Mode
Cn008	Brake		Dynamic Brake Mechanical Brake	ALL


	0	Disable	Disable
	1	Disable	Enable
	2	Enable	Disable
	3	Enable	Enable

Attention! When the Drive Inhibit occurs in CCW/CW, the priority of Dynamic Brake in Cn009 should be from Cn008, which means assuming Cn008 setting is 0 or 1 (no Dynamic Brake) and Cn009 1 (with Dynamic Brake), the servo will have Dynamic Brake in the end of process.

5-6-5 Timming for Mechanical Brake

When the servo system has vertical Loading: To prevent the Displacement result from gravity when turning off power, the servo motor with Mechanical Brake should generally be used. This device provides Output Contactor **BI** to decide if the Mechanical Brake works or not, then control the Timming of Mechanical Brake in accordance with **Cn003** (Output Time for Mechanical Brake). Here is the description below:

Wiring Diagram



Timing for Mechanical Brake

Parameter Signal	Name	Default	Default	Setting Range	Control Mode
Cn003	Output time for Mechanical Signal Brake	0	msec	-2000~2000	ALL

Attention! Cn008 (BK Mode) must be set to 1 or 3. When the servo system has vertical loading, please set Cn003 to Positive Number.

(1) When the Cn003(Output Time for Mechanical Brake Signal) is Positive Number:


When the input contactor SON works, servo will immediately on. After exceeding the timing which is set in Cn003, Output Contactor BI works (Mechanical BK stops);

When SON doesn't work, BI doesn't work, either (turning on Mechanical BK). After exceeding the timing which is set in Cn003, Servo ON stops.

(2) When the Cn003(Output Time for Mechanical BK) is Negative Number:

When the input contactor SON works, output contactor BI (Stopping of Mechanical BK) will work immediately, After exceeding the timing which is set in Cn003, servo will be on:

When Son doesn't work, Servo ON will be immediately stop. After exceeding the timing which is set in Cn003, output contactor BI will not work (Mechanical BK will be on).



P.S.: Input contacts status 1 means on; 0 means off. Please check 5-6-1 to set high electric potential or low electric potential.

5-6-6 Drive Inhibit Method for CW/CCW


When CW/CCW Inhibit occur: Here below is the setting for stopping motor:

Parameter Signal	Name	Setting	Description	Control Mode
★Cn009	CW/CCW drive inhibit	0	Using default torque limit(Cn010 、 Cn011)to decelerate ↗ Zero Speed Clamp after stopping.	ALL
		1	Using Dynamic BK to decelerate. ↗ Decelerations status after stopping (Priority from Cn008), it is necessary to return on the power to turn on servo system.	

		2	Using $\pm 300\%$ of torque limit to decelerate \rightarrow Zero Speed Clamp after stopping.
--	--	---	--

★The setting will be in effect after returning on the power.

Attention! When the Drive Inhibit occurs in CCW/CW, the priority of Dynamic Brake in Cn009 should be from Cn008, which means assuming Cn008 setting is 0 or 1 (no Dynamic Brake) and Cn009 1 (with Dynamic Brake), the servo will have Dynamic Brake in the end of process.



5-6-7 Selection for External Regeneration Resistor

When the rotating of servo motor is under the Generator Mode, the power flows to the driver from motor, which is called regenerating power. The applications below will cause servo motor under the Generator (Regeneration) Mode:

- (1) In the Timming during deceleration to stopping when servo motor ac/decelerates.
- (2) When Vertical Loading.
- (3) When operating servo motor from Loading Terminal.

The regeneration power will be absorbed by main loop filtering capacitance. If there is too much regeneration power which can not be absorbed, user must use Regeneration Resistor to absorb otiose regeneration power. Here are the built-in Regeneration Resistor specifications below:

Drive Model	Built-in Regeneration Resistor Specifications		The Regeneration Power(W)(Average Value which Built-in Regenerat Resistor can consume	Minimum allowed Resistance Vaule (Ω)
	Resistance(Ω)	Power(W)		
JSDA-15	50	60	24	50
JSDA-20	50	60	24	41
JSDA-30	25	60	24	23
JSDA-50	20	200	80	15
JSDA-75	12.5	200	80	9

Attention! The consumable Regeneration Power (Average Value) should be the 46% of Ratio Power from

Built-in Regeneration Resistor

The Regeneration Resistor which is built-in this device can consume the Regeneration Power from Ac/Deceleration Running or Vertical Loading. But in the application: driving servo motor at the loading terminal, user must install Regeneration Resistor by themselves, otherwise this device can not work normally. When installing External Regeneration Resistor, please confirm that resistance value is the same with the resistance value built-in in this device. If using many low-watt Regeneration Resistor to exceed parallel connection to increase the watt of Regeneration Resistor, please confirm all the Resistance value must higher than the Minimum allowed Resistance Value on the Table List above.

Setting for the Power of External Regeneration Resistor


When using external regeneration resistor, user must select the Watt for Regeneration Resistor correctly in **Cn012**.

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Cn012	Watt setting for External Regeneration Resistor	60	W	0~10000	ALL



User must use their own Regeneration Resistor, then dismount the wire between **PC** and **P1** on **TB1** Terminal when installing another resistor, then connect the Regeneration Resistor between **P1** and **PC**. For the safety, user is suggested to use the resistor with thermal.

Here is the wiring diagram below:



When the Regeneration Resistor absorbs the regeneration power, it will produce the high temperature over 100°C. Please be careful to cool it. Please select the heatproof wire when wiring Regeneration Resistor and confirm nothing is connecting to the Regeneration Resistor.





If the Loading of Servo Motor is Horizontal Moving, please use the Table List below to decide if the External Regeneration Resistor is necessary. The table list below is about Allowable Frequencies in Regenerative Mode, which definition is: the no-load speed of motor running from 0 to ratio speed then from from ratio speed to 0. And in the process of re-ac/deceleration, the Regeneration Power which internal regeneration resistor can absorb when Allowable Frequencies in Regenerative Mode.


Drive Model	Motor Model	Allowable Frequencies in Regenerative Mode (time/min)	The Power which Main Capacitor can absorb E_c (J)
JSDA-15	JSMA-LC03	433	6
	JSMA-SC02	1775	
	JSMA-SC04	1004	
JSDA-20	JSMA-LC08	118	9
	JSMA-SC04	1004	
	JSMA-SC08	321	
	JSMA-MA05	411	
	JSMA-MH05	186	
JSDA-30	JSMA-SC08	321	13
	JSMA-MA10	213	
	JSMA-MB10	102	
	JSMA-MH10	95	
	JSMA-MA15	145	
	JSMA-MB15	73	
	JSMA-MC15	45	
JSDA-50	JSMA-MA15	484	13
	JSMA-MB15	245	
	JSMA-MC15	152	
	JSMA-MB20	178	
JSDA-75	JSMA-MB30	121	18

Please use the formula below to compute the Allowable Frequencies in Regenerative Mode in accordance with actual Loading and running speed of motor.

$$\text{Allowable Frequencies in Regenerative Mode (time/min)} = \frac{\text{Allowable Frequencies}}{(1 + \alpha)} \times \left(\frac{\text{Ratio Speed}}{\text{Max Running Speed}} \right)^2$$

$\alpha = \text{Load Inertia / Motor Inertia}$

If the motor's actual running Frequencies is more than the computed Allowable Frequencies, user needs to install the external regeneration resistor. Please the necessary Watt of external regeneration resistor in accordance with the description below: (Ingoring the impedance from Motor Coil and the Energy which the circuit consumes)



Step	Item	Formula	Description
1	Compute the working Energie of Servo System.	$E_M = J_T \omega_{rm}^2 / 182$	E_M : Working Energie of Servo system (J) J_T : Inertia which is transformed to motor loading terminal ($kg \cdot m^2$) ω_{rm} : Motor running Speed(rpm)
2	Compute the consumed Energie during deceleration.	$E_L = (\pi / 60) \omega_{rm} T_L t_D$	E_L : The Energie during deceleration (J) T_L : Loading Torque(Nm) t_D : The Time from deceleration to stopping(s)

3	Compute the Energy which main capacitance can absorb	E_C Check the diagram above	E_C : The Energy which main capacitance can absorb (J)
4	Compute the Energy which Regeneration Resistor consumes	$E_R = E_M - (E_L + E_C)$	E_R : The Energy which Regeneration Resistor consumes (J)
5	Compute the Power which Regeneration Resistor needs	$P_R = (E_R/T)/0.4$	P_R : The Power which Regeneration Resistor needs(W) T : Operating cycle for servo system(s)

P.S.1: Compute the 0.4 ⚡ Utility Rate for Regeneration Resistor = 40% (in P_R formula).

P.S.2: If the E_L can not be computed, please let the $E_L = 0$, then count it.

When the Servo is used in the Regenerative Mode, which means Motor Output Torque is adverse to Running direction, a great quantity of Loading Energy will fluent back to the driver. Under this situation, please add the item below before the formula step 4 above. Then compute the necessary Watt for external regeneration resistor:

Item	Formula	Description for Symbols
Compute the working Energy during the continual regenerative mode period.	$E_G = (\pi / 60) \omega_{m,G} T_G I_G$	E_G : Working Energy during the regenerative mode period (J) $\omega_{m,G}$: Motor running speed (rpm) during the regenerative mode period T_G : Loading Torque during the regenerative mode period (Nm) t_G : Regenerative Mode Time(s)

The formula of step 4 will be: $E_R = E_M - (E_L + E_C) + E_G$

5-6-8 Setting for Fan Working

Parameter Signal	Name	Setting	Description	Control Mode
Cn031	Setting for Fan Working (Only for JSDA-50 and JSDA-75)	0	Auto (Depend on Temp.)	ALL
		1	Operate while in RUN mode	
		2	Always Run	


		3	Always Stop
--	--	---	-------------

5-6-9 Analog Monitor

The servo provides 2 Analog Signals to monitor the running situation of motor. Here is the setting below:

Parameter Signal	Name	Setting	Description		Control Mode
Cn006	Selection for Analog Monitor Output		Analog Monitor Output 1 MON1	Analog Monitor Output 2 MON2	ALL
		0	Actual Speed (1.5x Ratio Number /±10V)	Torque Command (3.5x Ratio Number /±10V)	
		1	Actual Speed	Speed Command (1.5x Ratio Number /±10V)	
		2	Actual Speed	Rotor Position (0~360°機械角±10V)	
		3	Actual Speed	Position Pulse error (±16~16368pulse/±10V)	
		4	Actual Speed	U-Phase Current (3.5x Ratio Number /±10V)	


The Diagram below is the Wiring Diagram for Analog Monitor Output:



When there is Analog Monitor Output Voltage Bias, users can manually adjust **Cn027**、**Cn028** to fix the bias value.

Here is the setting below:

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Cn027	Analog Monitor 1 Output Bias Adjusting	4	x40mV	-250~250	ALL
Cn028	Analog Monitor 2 Output Bias Adjusting	4	x40mV	-250~250	ALL



5-6-10 Reset for Parameter

The servo can turn back to the default value with this function. When setting to **1**, the power must be restart:

Parameter Signal	Name	Setting	Description	Control Mode
★Cn029	Reset for Parameter	0	No working	ALL
		1	All parameters return to default value	

★The setting will be in effect after returning on the power.

Chapter 6 Parameter

6-1 Definition

There are following 9 groups for parameters :

Parameter	Definition
Un-xx	Status Display Parameter
dn-xx	Diagnosis Parameter
AL-xx	Alarm Traceback data parameter
Cn-xx	System Parameter
Tn1xx	Torque Control Parameter
Sn2xx	Speed Control Parameter
Pn3xx	Position Control Parameter
qn4xx	Quick Setting Parameter
Hn5xx	Multi-function parameter

P.S: xx stand for the events of parameter groups.

Control Mode Code




Abbreviation	Control Mode
ALL	All Control Mode
Pi	Position Control Mode (Internal Positional Command)
Pe	Position Control Mode (External Puls Command)
S	Speed Control Mode
T	Torque Control Mode



Effective Symbol of Parameter setting

Symbol	Explanation
★	Parameter is effective after the servo drive is restarted.
◆	Parameter is Effective without "Enter".

6-2 Parameter

System Parameter

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chap.		
★Cn001	Control Mode	2	X	0 6	ALL	5-1		
	Setting						Explanation	
	0						Torque Control	
	1						Speed Control	
	2						Position Control (external puls Command)	
	3						Position / Speed Control Switching	5-6-2
	4						Speed / Torque Control Switching	
	5						Position / Torque Control Switching	
6	Position Control (internal position Command)							
★Cn002.0 	Contact Accessory Function – Enter Contact "SON"	0	X	0 1	ALL	5-6-3		
	Setting						Explanation	
	0						Enter Contact "SON" to control "Servo On"	
	1						Control "Servo ON" without entering Contact "SON"; Servo ON when Power ON.	
Cn002.1 	Contact Accessory Function – Eter Contact CCWL & CWL	0	X	0 1				
	Setting						Explanation	
	0						Using entrance contacts CCWL & CWL to control CCW & CW.	
	1						Control CCW & CW Drive Forbid without using contact CCWL & CWL, ignoring CCW & CW Drive Forbid Function.	
Cn002.2 	Auto- Tone up Adjust Setting	0	X	0 1	Pi Pe S	5-5-1		
	Setting						Explanation	
	0						No using Auto-Tone up Adjust Function	
	1						Keep using Auto-Tone up Adjust Function.	

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chap.		
Cn003	Mechanical Brakes signal output sequence	0	msec	-2000 2000	ALL	5-6-5		
	Time Sequence :  <p>P.S.: Input / output contact status 1 means SWITCH; 0 means SWITCH OFF, please refer to 5-6-1 to set high electric action potential or low electric action potential.</p>							
Cn004	Motors rotate direction(Motor Load)	0	X	0 3	ST	5-2-4 5-3-7		
	 <p>When Torque or Speed Command is plus, the setting of Motor Load are:</p>							
	Setting						Explanation	
							Torque Control	Speed Control
	0						CounterClockWise(CCW)	CounterClockWise(CCW)
	1						ClockWise(CW)	CounterClockWise(CCW)
2	CounterClockWise(CCW)	ClockWise(CW)						
3	ClockWise(CW)	ClockWise(CW)						
★Cn005	Encoder Signal Ration output		pulse		ALL	5-3-5		

It stands for that the number of puls-signal numbers of a rotate of the motor-encoder transforming the Cn005-default puls-signal numbers. Ex: Motor-Encoder : One Rotate has 2000pulse output. Set Cn005 =1000 if gain 1000pulse Ration-output.	Amount per Pulse	1 Amount per Pulse	
---	------------------------	----------------------------------	--

Parameter	Name & Function		Default	Unit	Setting Range	Control Mode	Chap.	
Cn006	Analog Monitor Output Selection		2	X	0 4	ALL	5-6-9	
	Explanation							
	Setting	Analog monitor output 1 MON1						Analog monitor output2 MON2
	0	Actual Speed (1.5timesdefault value/±10V)						Torque Command (3.5times rating value/±10V)
	1	Actual Speed						Speed Command (1.5times rating value/±10V)
	2	Actual Speed						Rotor position (0~360° Mechanical angle/±10V)
	3	Actual Speed						Position puls err (±16~16368pulse/±10V)
	4	Actual Speed						U-Phase current (3.5 times rating value /±10V)
Cn007	Speed-achievd determined value		1000	rpm	0 4500	S T	5-3-12	
	When ClockWise's or CounterClockWise's Speed is over Cn007 (when the speed achieves the determined value) Setting, output contact INS .							
Cn008	Brakes Mode		2	X	0 3	ALL	5-6-4	
	(Servo off)、(EMC)、CCW/CW Brake status in Drive Limit static state.							
	Setting	Explanation						
		Dynamic brakes						Mechanical brakes
	0	No						No
	1	No						Yes
	2	Yes						No
	3	Yes						Yes
★Cn009	CW/CCW Drive forbid			X		ALL	5-6-6	

Setting	Explanation	0	0		
0	ServoMotor decelerate then stop through default torque forbid(Cn010 、 Cn011).				
1	ServoMotor decelerate then stop through default torque forbid (Cn010 、 Cn011),and drive the dynamic brake (priority to Cn008)		2		
2	ServoMotor decelerate then stop through $\pm 300\%$ Torque forbid decelerate then stop.				


Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chap.		
Cn010	CCW direction torque Command forbid number	100	%	0	ALL	5-2-5 5-3-10		
	Ex: If 2 times of default Torque forbid of CCW Torque Command, set Cn001 =200.			 300				
Cn011	CW Torque Command forbid number.	-100	%	-300	ALL	5-2-5 5-3-10		
	Ex: If 2 times of default Torque forbid of CW Torque Command, set Cn011 =-200.			 0				
Cn012	Setting of the duty of External Re-generate resister	60	W	0	ALL	5-6-7		
	Referring to 5-6-7 to choose external Regenerate resister and set its duty at Cn012			 10000				
★ Cn013	Frequency of resonance restrain Filter	0	Hz	0	Pi Pe S	5-3-9		
	Please enter the frequency of vibration in Cn013 , if the noise of vibration must be eliminated.			 1000				
★ Cn014	Quality-Factors of the Resonance restrain Filter	7	X	1	Pi Pe S	5-3-9		
	Adjusting the range of the frequency, lower the number of Cn014 is, wider the restrained range of frequency is.			 100				
Cn015.0 	Type-Chois of the Switch-estimation in PI/P Mode.	4	X	0	Pi Pe S	5-3-11		
	Setting			Explanation				
	0			Estimate if Torque Command over Cn016			4	S
	1			Estimate if Speed Command over Cn017				
	2			Estimate if acceleration Command over Cn018				
	3			Estimate if position mistake over Cn019				
	4			Using Enter Contact PCNT to switch it				
Cn015.1 	Choise of Type of SwitchingEstimation in 2 part increase Mode	4	X	0	Pi Pe S			
	Setting			Explanation				
	0			Estimate if Torque Command over Cn021			4	
	1			Estimate if Speed Command over Cn022				
	2			Estimate if acceleration Command over Cn023				

	3	Estimate if position mistake over Cn024					
	4	Using Enter Contact PCNT to switch it					
Cn016	Switch-condition in PI/P Mode(Torque Command)		200	%	0 399	Pi Pe S	5-3-11
	Set the Cn015.0=0 first , when Torque Command under Cn016 switch-condition, controled by PI ; when Torque Command over Cn016 switch-condition, controled by P only.						
Cn017	Switch-condition in PI/P Mode(Speed Command)		0	rpm	0 4500	Pi Pe S	5-3-11
	Set the Cn015.0=1 first , when Speed Command is under Cn017 switch-condition, controled by PI ; when Speed Command is over Cn017 switch-condition, controled by P only.						

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chap.
Cn018	Switch-condition in PI/P mode (accelerate Command)	0	rps/s	0 18750	Pi Pe S	5-3-11
	Set the Cn015.0=2 first , when acceleration Command is under Cn018 switch-condition, controled by PI ; when acceleration Command is over Cn018 switch-condition, controled by P only.					
Cn019	Switch-condition in PI/P mode(position error number)	0	pulse	0 50000	Pi Pe S	5-3-11
	Set the Cn015.0=3 first , when position error number is under Cn019 switch-condition , controled by PI ; when position error number is over Cn019 switch-condition, controled only by P.					
Cn020	Switch-delay time of 2-parts increase mode.	0	x02 msec	0 10000	Pi Pe S	5-3-11
	When using 2-parts increase mode, the delay that switching from the second part to the first part can be set.					
Cn021	Switch-condition of 2-parts increase mode.(Torque Command)	200	%	0 399	Pi Pe S	5-3-11
	Set Cn015.1=0 first , when Torque Command is under Cn021 switch-condition, use the first part increase-condrol; when Torque Command is over Cn021 switch-condition, switch to the second part of increase-control. If Torque Command is under Cn021 switch-condition again, it will be switched to the first part of increase-control in accordance with Cn020 .					
Cn022	Switch-condition of 2-parts increase mode. (Speed Command)	0	rpm	0	Pi Pe	5-3-11


	Set the Cn015.1=1 first, when Speed Command is under Cn022 switch-condition, use the first-part increase-control. When Speed Command is over Cn022 switch-condition, switch to the second part of increase-control. When Speed Command is under Cn022 switch-condition again, it will be switched to the first part of increase-control in accordance with Cn020 .			4500	S	
Cn023	Switch-condition of 2-parts increase mode.(Accelerate Command) Set the Cn015.1=2 first, when accelerate Command is under Cn023 switch-condition, use the first-part increase-control. When accelerate Command is over Cn023 switch-condition, switch to the second part of increase control. When accelerate Command is under Cn023 switch-condition again, it will be switched to the first part of increase-control in Cn020 switch-delay time.	0	rps/s	0 18750	Pi Pe S	5-3-11
Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chap.
Cn024	Switch-condition of 2-parts increase mode. (Position error amount) Set Cn015.1=3 first, when the error amount is under Cn024 switch-condition, use the first part of increase-control; when the position-error amount is over Cn024 switch-condition, switch to the second part of increase-control; when position-error amount is under Cn024 switch-condition, switch to the first part of increase-control in accordance with Cn020 switch-delay time.	0	pulse	0 50000	Pi Pe S	5-3-11
Cn025	Load-Inertia rate $LoadInertiaRatio = \frac{LoadInertiaToMotor(J)}{MotorRotorInertia(JM)} \times 100\%$	70	x0.1	0 1000	Pi Pe S	5-5
Cn026	Rigidity Setting When using the auto-increase adjustment function, Rigidity Range should be set first in accordance with all appliance. The Rigidity Setting ranges in all kinds of appliance follow as below: Explanation	4	X	1 A	Pi Pe S	5-5-1

Setting	Position Loop Gain Pn310 [1/s]	Speed Loop Gain Sn211 [Hz]	Speed Loop Integration-Time Constant Sn212 [x0.2msec]
1	15	15	300
2	20	20	225
3	30	30	150
4	40	40	100
5	60	60	75
6	85	85	50
7	120	120	40
8	160	160	30
9	200	200	25
A	250	250	20



Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chap.
Cn027	Analog monitor out put –'1' shift adjustment	4	x40 mV	-250 250	ALL	5-6-9
	Analog monitor out put '1' : When there are phenomenon of voltage departure, it could be adjusted. <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>Before Offset adjust</p> </div> <div style="text-align: center;"> <p>After Offset adjust</p> </div> </div>					
Cn028	Analog monitor out put –'2' departure adjustment	4	x40 mV	-250 250	ALL	5-6-9
	Analog monitor out put '2' : When there are phenomenon of voltage departure, it could be adjusted.					
★Cn029	Parameter reset	0	X	0 1	ALL	5-6-10
	Setting	Explanation				
	0	Un-functional				
	1	All Parameters return to default				

★Cn030	Setting of Servo-Seriation		Default	X	X	ALL	3-2-2
	When the Setting of what dn-08 display is different between ServoDrive and ServoMotor, please contact with our local distributor to set this parameter.						
Cn031	Setting of fan running(Application only to JSDA-50 & JSDA-75)		0	X	0 3	ALL	5-6-8
	Setting	Explanation					
	0	Auto-running of temperature sensor.					
	1	Running when Servo ON					
	2	Keeping Running					
	3	Stop Running					



Torque-Control Parameter

Parameter	Name & Function		Default	Unit	Setting Range	Control Mode	Chap.
★Tn101	Ac/de-celeration in Torque Command		0	X	0 1	T	5-2-3
	Setting	Explanation					
	0	No using function of torque command - linear acceleration.					
	1	Using function of torque command - linear acceleration.					
★Tn102	Torque Command – Linear ac/deceleration-constant		1	msec		T	5-2-3

	<p>The constant of torque-command-linear ac/deceleration means the time in which from '0' to 'default amount' .</p>			1 50000		
Tn103	<p>Analog Torque Command – Ratio adjust</p> <p>The slope : Adjustment of voltage command v.s. adjustment of Torque command.</p>	300	%/10V	0 300	T	5-2-1
Tn104	<p>Departure-Adjustment in Analog Torque Command</p> <p>When there is the phenomenon of Voltage-Departure in analog torque command, it is used to adjust the departure-amount.</p>	0	mV	-10000 10000	T	5-2-2
Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chap.
Tn105	Internal Speed Limit '1'	100	rpm	0	T	5-2-6



	<p>In “Torque Control”, the input-contacts “SPD1 & SPD2” can be used to switch 3 parts of internal speed limit. When internal speed limit is “1”, the status of input contact “SPD1 & SPD2” follow as below:</p> <table border="1"> <thead> <tr> <th>Input-Contact SPD2</th> <th>Input-Contact SPD1</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>1</td> </tr> </tbody> </table> <p>P.S: Contact status “1” stands for ON, “0” is OFF. Refer to 5-6-1 to set high or low action potential.</p>	Input-Contact SPD2	Input-Contact SPD1	0	1			3000		
Input-Contact SPD2	Input-Contact SPD1									
0	1									
Tn106	<p>Internal Speed Limit “2”</p> <p>In “Torque Control”, the input-contacts SPD1 & SPD2 can be used to 3 parts of internal speed limit. When internal speed limit is “2”, the status of input-contact SPD1 & SPD2 follow as below:</p> <table border="1"> <thead> <tr> <th>Input Contact SPD2</th> <th>Input Contact SPD1</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>0</td> </tr> </tbody> </table> <p>P.S: Contact status “1” stands for ON, “0” is OFF. Refer to 5-6-1 to set high or low action potential.</p>	Input Contact SPD2	Input Contact SPD1	1	0	200	rpm	0 3000	T	5-2-6
Input Contact SPD2	Input Contact SPD1									
1	0									
Tn107	<p>Internal Speed Limit “3”</p> <p>In “Torque Control”, the input-contacts SPD1 & SPD2 can be used to 3 parts of internal speed limit. When internal speed limit is “3”, the status of input-contact SPD1 & SPD2 follow as below:</p> <table border="1"> <thead> <tr> <th>Input Contact SPD2</th> <th>Input Contact SPD1</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>1</td> </tr> </tbody> </table> <p>P.S: Contact status “1” stands for ON, “0” is OFF. Refer to 5-6-1 to set high or low action potential.</p>	Input Contact SPD2	Input Contact SPD1	1	1	300	rpm	0 3000	T	5-2-6
Input Contact SPD2	Input Contact SPD1									
1	1									

Speed-Control Parameter

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chap.
-----------	-----------------	---------	------	---------------	--------------	-------

Sn201	Internal Speed Command “1”		100	rpm	-3000 3000	S	5-3-1
	In “Speed Control”, the input-contacts SPD1 & SPD2 can be used to switch 3 parts of internal speed command. When the Internal Speed Command is “1”, the status of Input Contact SPD1 & SPD2 follow as below: <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Input Contact SPD2</th> <th>Input Contact SPD1</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td style="text-align: center;">1</td> </tr> </tbody> </table> <p>P.S: Contact status “1” stands for ON, “0” is OFF. Refer to 5-6-1 to set high or low action potential.</p>						
Input Contact SPD2	Input Contact SPD1						
0	1						
Sn202	Internal Speed Command “2”		200	rpm	-3000 3000	S	5-3-1
	In “Speed Control”, the input-contacts SPD1 & SPD2 can be used to switch 3 parts of internal speed command. When the Internal Speed Command is “2”, the status of Input Contact SPD1 & SPD2 follow as below: <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Input Contact SPD2</th> <th>Input Contact SPD1</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> </tbody> </table> <p>P.S: Contact status “1” stands for ON, “0” is OFF. Refer to 5-6-1 to set high or low action potential.</p>						
Input Contact SPD2	Input Contact SPD1						
1	0						
Sn203	Internal Speed Command “3”		300	rpm	-3000 3000	S	5-3-1
	In “Speed Control”, the input-contacts SPD1 & SPD2 can be used to switch 3 parts of internal speed command. When the Internal Speed Command is “3”, the status of Input Contact SPD1 & SPD2 follow as below: <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Input Contact SPD2</th> <th>Input Contact SPD1</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> </tbody> </table> <p>P.S: Contact status “1” stands for ON, “0” is OFF. Refer to 5-6-1 to set high or low action potential.</p>						
Input Contact SPD2	Input Contact SPD1						
1	1						
Sn204	Motion of Zero-Speed judgment		0	X	0 1	S	5-3-12
	Setting	Explanation					
	0	No Action					
	1	Let the Speed Command be “Zero-Speed”					


Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chap.
-----------	-----------------	---------	------	---------------	--------------	-------

Sn205	Ac/deceleration of Speed Command		0	X	0 3	S	5-3-6
	Setting	Explanation					
	0	Not Function					
	1	1 time soft Ac/deceleration					
	2	Linear Ac/deceleration					
3	S curve to Ac/deceleration						
Sn206	One Time Soft ac/deceleration-time Constant in SpeedCommand		1	msec	1 10000	S	5-3-6
	<p>Set Sn205=1 to turn on One-Time ac/deceleration function in SpeedCommand.</p> <p>The time-constant stands for the time in which the speed arise to 63.2 of Full-Speed.</p> 						
Sn207	Linear ac/deceleration Constant in SpeedCommand		1	msec	1 50000	S	5-3-6
	<p>Set Sn205=2 to turn on Linear ac/deceleration function of SpeedCommand.</p> <p>The ac/deceleration constant stands for the time in which the speed arise from 0 to the default time.</p> 						

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chap.
Sn208	Ac/deceleration Constant in S-curve SpeedCommand	1	msec	1	S	5-3-6

Set **Sn205=3** to turn on S-curve ac/deceleration function in Speed-Command.

Set **Sn208** to get softer slope then **Sn207**, and watch **Sn209** and **Sn210** to switch these 2 rising slope.



Attention:Sn207 must under Sn208, then the smooth effect appear.

50000

Sn209	S-curve varying Speed	1000	rpm	0	S	5-3-6
	Please refer to Sn208			3000		
Sn210	S-curve varying Speed – 2	2000	rpm	0	S	5-3-6
	Please refer to Sn208			3000		
Sn211	Speed loop gain – 1	40	Hz	10	Pi	5-3-8
	Speed loop gain effect directly the frequency response bandwidth of Speed-control loop. If there is no vibration or noise, more Speed-loop-gain amount it has, the faster speed response is. If Cn025 correctly set, the speed-loop-bandwidth equal to speed-loop-gain.			450	Pe S	5-5
Sn212	The Time-Constant of Speed-loop Integration – 1	100	x0.2 ms	1	Pi	5-3-8
	Speed-Control Loop with integration-elements can eliminate the speed error and show the slight variations. Decreasing Speed –loop time can increase system rigidity. The formula below provides the speed-loop-integration time-constant. $SpeedLoopIntegrationTimeConstant \geq 5 \times \frac{1}{2\pi \times SpeedLoopGain}$			500	Pe S	5-5

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chap.
Sn213	Speed loop gain – 2	40	Hz	10	Pi	

	Please refer to Sn211			450	Pe S	5-3-8 5-5
Sn214	Speed-loop-integration Time-constant 2	100	x0.2 msec	1	Pi	5-3-8 5-5
	Please refer to Sn212			500	Pe S	
Sn215	ZeroSpeed Judgement Value	50	rpm	0	S	5-3-12
	When speed is lower what Sn215 sets, input the contact ZS .			4500		
Sn216	Analog Speed Command Ratio	3000	rpm /10V	100	S	5-3-2
	Slope , which is used to adjust voltage command v.s. speed command.			4500		
Sn217	AgalogSpeed Command Offset adjustment	0	mV	-10000	S	5-3-3
	When there is the phenomenon of analog speed command voltage offset, it is used to adjust the offset value.			10000		
Sn218	Analog Speed Command Limit	3050	rpm	100	S	5-3-4
	User can set Sn218 to limit analog speed command			4500		

Position Control Parameter

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chap.
	Position PulseCommand Type	0	X		Pe	5-4-1

★Pn301.0 	Setting	Explanation			0					
	0	(Pulse)+(Sign)								
	1	(CCW)/(CW) Pulse			3					
	2	AB-Phase pulse x 2								
	3	AB-Phase pulse x 4								
★Pn301.1 	Position-Pulse Command Logic		0	X	0					
	Setting	Explanation								
	0	Positive Logic			1					
Pn302	Electronic Gear Ratio Numerator 1		1	X	1	Pi	5-4-3			
	<p>Use input contacts GN1 & GN2 to switch 4 groups of Electronic Gear Ratio Numerator. When using the Numerator 1, the statue of the input-contacts GN1 & GN2 are:</p> <table border="1" data-bbox="427 792 858 943"> <thead> <tr> <th>Input-contact GN2</th> <th>Input-contact GN1</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> </tr> </tbody> </table> <p>P.S.:Input-contact-stature 1 stands for Switch ON, 0 stands for SwitchOFF. If setting high potential action or low potential action, please refer to 5-6-1 to set.</p>		Input-contact GN2	Input-contact GN1	0	0				Pe
Input-contact GN2	Input-contact GN1									
0	0									
					50000					
Pn303	Electronic Gear Ratio Numerator 2		1	X	1	Pi	5-4-3			
	<p>Use input contacts GN1 & GN2 to switch 4 groups of Electronic Gear Ratio Numerator. When using the Numerator 2, the statue of the input-contacts GN1 & GN2 are:</p> <table border="1" data-bbox="427 1249 858 1400"> <thead> <tr> <th>Input-contact GN2</th> <th>Input-contact GN1</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>1</td> </tr> </tbody> </table> <p>P.S.:Input-contact-stature 1 stands for Switch ON, 0 stands for SwitchOFF. If setting high potential action or low potential action, please refer to 5-6-1 to set.</p>		Input-contact GN2	Input-contact GN1	0	1				Pe
Input-contact GN2	Input-contact GN1									
0	1									
					50000					

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chap.
-----------	-----------------	---------	------	---------------	--------------	-------

Pn304	Electronic Gear Ratio Numerator 3	1	X	1 50000	Pi Pe	5-4-3
	Use input contacts GN1 & GN2 to switch 4 groups of Electronic Gear Ratio Numerator. When using the Numerator 3, the statue of the input-contacts GN1 & GN2 are: <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Input-contact GN2</th> <th>Input-contact GN1</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> </tbody> </table> <p>P.S.:Input-contact-statue 1 stands for Switch ON, 0 stands for SwitchOFF. If setting high potential action or low potential action, please refer to 5-6-1 to set.</p>					
Input-contact GN2	Input-contact GN1					
1	0					
Pn305	Electronic Gear Ratio Numerator 4	1	X	1 50000	Pi Pe	5-4-3
	Use input contacts GN1 & GN2 to switch 4 groups of Electronic Gear Ratio Numerator. When using the Numerator 4, the statue of the input-contacts GN1 & GN2 are: <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Input-contact GN2</th> <th>Input-contact GN1</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> </tbody> </table> <p>P.S.:Input-contact-statue 1 stands for Switch ON, 0 stands for SwitchOFF. If setting high potential action or low potential action, please refer to 5-6-1 to set.</p>					
Input-contact GN2	Input-contact GN1					
1	1					
★ Pn306	Electronic Gear Ratio Denominator	1	X	1 50000	Pi Pe	5-4-3
	Set Pn306 (Electronic Gear Ratio Denominator) to match input-contacts GN1 and GN2's electronic gear ratio numerator. And the final electroni gear ratio must match the condition below, otherwise, it can not normally operate $\frac{1}{200} \leq \text{ElectronicGearRatio} \leq 200$					
Pn307	Position Fixed Judgement Value	10	pulse	0 50000	Pi Pe	5-4-9
	When the Position error value is lower then Pn307 's pulse number(Position Fixed Judgement Value), output-contact INP carry into effect.					
Pn308	Positive-maximum Position Error Judgement Value	50000	pulse	0 50000	Pi Pe	5-4-9
	When the Position error value is higher then Pn308 's pulse number(Positive maximum position error judgement value), this device give us AL-11 (Position error value alert)					
Pn309	Negative Maximum Position Error Judgement Value	50000	pulse	0 50000	Pi Pe	5-4-9
	When the Position error value is higher then Pn309 's pulse number(Negative maximum position error judgement value), this device give us AL-11 (Position error value alert)					

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chap.
Pn310	Position Loop Gain 1	40	1/s	1 450	Pi Pe	5-4-6 5-5
	Under the situation that there are no vibration or noise of machinery system. Increasing the position loop gain value can speed up reaction and shorten the time of fixing position. Generally, the position loop bandwidth can not higher then speed loop bandwidth. Here is the suggested formula below: $PositionLoopGain \leq 2\pi \times \frac{SpeedLoopGain}{5}$					
Pn311	Position Loop Gain 2	40	1/s	1 450	Pi Pe	5-4-6 5-5
	Please refer to Pn310					
Pn312	Position Loop Feed Forward Gain	0	%	0 100	Pi Pe	5-4-6 5-5
	It can reduce the follow up error of position control and speed up the reaction. If the feed forward gain is too over, it might cause speed overshooting and re-ON/OFF of output contact INP(Position Complete signal).					
★Pn313	Position Command : one Time smooth ac/decelerational Time-Constant	10	msec	0 10000	Pi Pe	5-4-4
	It cause the position pulse command of original constant frequency smooth. Position Command-one time smooth ac/decelerational Time-Constant stands for the time in which position pulse command frequency starts from 0 to 63.2%. 					
Pn314	Position Command direction definition(Load Side) 	1	X	0 1	★Pi Pe	5-4-5
	Setting	Explanation				

	0	(CW)					
	1	(CCW)					
Parameter	Name & Function		Default	Unit	Setting Range	Control Mode	Chap.
Pn315	Pulse Error amount Eliminate Mode		0	X	0 2	Pe	5-4-7
	Setting	Explanation					
	0	When CLR act, it eliminates the Pulse-error-amount.					
	1	When CLR works, it cancels the position command to interrupt Motor's Rotate, reset machinery origin and clean pulse error amount.					
	2	When CLR works, it cancels position command to interrupt Motor's Rotate and clean pulse error amount.			Pi		
★Pn316	Internal Position Command Mode		0	X	0 1	Pi	5-4-2
	Setting	Explanation					
	0	Absolute Position					
	1	Relative Position					
Pn317	Internal Position Command 1 – Rotation Number		0	rev	-30000 30000	Pi	5-4-2
	Setting the Rotation number of the internal Position Command 1 Using input contacts POS1~POS4 to operate the first part of position command. Please refer to 5-4-2.						
Pn318	Internal Position Command 1-Pulse Number		0	pulse	-32767 32767	Pi	5-4-2
	Setting the rotation pulse number of internal position Command 1 Internal Position Command 1 =Pn317(Rotation Number)x Pulse number of One Rotate x4+Pn318(Pulse number)						
Pn319	Internal Position Command 1-Move Speed		0	rpm	0 3000	Pi	5-4-2
	Setting the Move Speed of internal Position Command 1						
Pn320	Internal Position Command 2-Rotation Number		0	rev	-30000 30000	Pi	5-4-2
	Please refer to Pn317						
Pn321	Internal Position Command 2-Pulse Number		0	pulse	-32767 32767	Pi	5-4-2
	Please refer to Pn318						
Pn322	Internal Position Command 2-Move Speed		0	rpm	0 3000	Pi	5-4-2
	Please refer to Pn319						

Pn323	Internal Position Command 3-Rotation Number	0	rev	-30000 30000	Pi	5-4-2
	Please refer to Pn317					

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chap.
Pn324	Internal Position Command 3-Pulse Number	0	pulse	-32767 32767	Pi	5-4-2
	Please refer to Pn318					
Pn325	Internal Position Command 3-Move Speed	0	rpm	0 3000	Pi	5-4-2
	Please refer to Pn319					
Pn326	Internal Position Command 4 -Rotation Number	0	rev	-30000 30000	Pi	5-4-2
	Please refer to Pn317					
Pn327	Internal Position Command 4-Pulse Number	0	pulse	-32767 32767	Pi	5-4-2
	Please refer to Pn318					
Pn328	Internal Position Command 4-Move Speed	0	rpm	0 3000	Pi	5-4-2
	Please refer to Pn319					
Pn329	Internal Position Command 5 -Rotation Number	0	rev	-30000 30000	Pi	5-4-2
	Please refer to Pn317					
Pn330	Internal Position Command 5-Pulse Number	0	pulse	-32767 32767	Pi	5-4-2
	Please refer to Pn318					
Pn331	Internal Position Command 5-Move Speed	0	rpm	0 3000	Pi	5-4-2
	Please refer to Pn319					
Pn332	Internal Position Command 6 -Rotation Number	0	rev	-30000 30000	Pi	5-4-2
	Please refer to Pn317					
Pn333	Internal Position Command 6-Pulse Number	0	pulse	-32767 32767	Pi	5-4-2
	Please refer to Pn318					
Pn334	Internal Position Command 6-Move Speed	0	rpm		Pi	5-4-2

	Please refer to Pn319			0 3000		
Pn335	Internal Position Command 7 -Rotation Number	0	rev	-30000 30000	Pi	5-4-2
	Please refer to Pn317					
Pn336	Internal Position Command 7-Pulse Number	0	pulse	-32767 32767	Pi	5-4-2
	Please refer to Pn318					


Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chap.
Pn337	Internal Position Command 7-Move Speed	0	rpm	0 3000	Pi	5-4-2
	Please refer to Pn319					
Pn338	Internal Position Command 8 -Rotation Number	0	rev	-30000 30000	Pi	5-4-2
	Please refer to Pn317					
Pn339	Internal Position Command 8-Pulse Number	0	pulse	-32767 32767	Pi	5-4-2
	Please refer to Pn318					
Pn340	Internal Position Command 8-Move Speed	0	rpm	0 3000	Pi	5-4-2
	Please refer to Pn319					
Pn341	Internal Position Command 9 -Rotation Number	0	rev	-30000 30000	Pi	5-4-2
	Please refer to Pn317					
Pn342	Internal Position Command 9-Pulse Number	0	pulse	-32767 32767	Pi	5-4-2
	Please refer to Pn318					
Pn343	Internal Position Command 9-Move Speed	0	rpm	0 3000	Pi	5-4-2
	Please refer to Pn319					
Pn344	Internal Position Command 10 -Rotation Number	0	rev	-30000 30000	Pi	5-4-2
	Please refer to Pn317					
Pn345	Internal Position Command 10-Pulse Number	0	pulse	-32767 32767	Pi	5-4-2
	Please refer to Pn318					


Pn346	Internal Position Command 10-Move Speed	0	rpm	0	Pi	5-4-2
	Please refer to Pn319			 3000		
Pn347	Internal Position Command 11 -Rotation Number	0	rev	-30000	Pi	5-4-2
	Please refer to Pn317			 30000		
Pn348	Internal Position Command 11-Pulse Number	0	pulse	-32767	Pi	5-4-2
	Please refer to Pn318			 32767		
Pn349	Internal Position Command 11-Move Speed	0	rpm	0	Pi	5-4-2
	Please refer to Pn319			 3000		


Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chap.
Pn350	Internal Position Command 12 -Rotation Number	0	rev	-30000	Pi	5-4-2
	Please refer to Pn317			 30000		
Pn351	Internal Position Command 12-Pulse Number	0	pulse	-32767	Pi	5-4-2
	Please refer to Pn318			 32767		
Pn352	Internal Position Command 12-Move Speed	0	rpm	0	Pi	5-4-2
	Please refer to Pn319			 3000		
Pn353	Internal Position Command 13 -Rotation Number	0	rev	-30000	Pi	5-4-2
	Please refer to Pn317			 30000		
Pn354	Internal Position Command 13-Pulse Number	0	pulse	-32767	Pi	5-4-2
	Please refer to Pn318			 32767		
Pn355	Internal Position Command 13-Move Speed	0	rpm	0	Pi	5-4-2
	Please refer to Pn319			 3000		
Pn356	Internal Position Command 14 -Rotation Number	0	rev	-30000	Pi	5-4-2
	Please refer to Pn317			 30000		
Pn357	Internal Position Command 14-Pulse Number	0	pulse	-32767	Pi	5-4-2
	Please refer to Pn318			 32767		



Pn358	Internal Position Command 14-Move Speed		0	rpm	0	Pi	5-4-2
	Please refer to Pn319				 3000		
Pn359	Internal Position Command 15 -Rotation Number		0	rev	-30000	Pi	5-4-2
	Please refer to Pn317				 30000		
Pn360	Internal Position Command 15-Pulse Number		0	pulse	-32767	Pi	5-4-2
	Please refer to Pn318				 32767		
Pn361	Internal Position Command 15-Move Speed		0	rpm	0	Pi	5-4-2
	Please refer to Pn319				 3000		
Pn362	Internal Position Command 16 -Rotation Number		0	rev	-30000	Pi	5-4-2
	Please refer to Pn317				 30000		
Parameter	Name & Function		Default	Unit	Setting Range	Control Mode	Chap.
Pn363	Internal Position Command 16-Pulse Number		0	pulse	-32767	Pi	5-4-2
	Please refer to Pn318				 32767		
Pn364	Internal Position Command 16-Move Speed		0	rpm	0	Pi	5-4-2
	Please refer to Pn319				 3000		
Pn365.0	After Zero Point Return operates, the Setting of ZeroPoint Direction Searching and Zero Reference.		0	X	0	Pi Pe	5-4-8
	Setting				5		
	Explanation						
	0	After zero-point-return operates, the Motor searches the origin in first stage of speed ClockWise, and the input contacts CCWL or CWL is the origin reference point. When origin point – return position is accomplished, input contacts CCWL or CWL become extreme function. When this function is used, Pn365.1 can not be set 1 or 2. Attention: Cn002.1(Contact assistant function – input contact CCWL and CWL function selection) must be set 0.					


1	After zero-point-return operates, the Motor searches the origin in first stage of speed CounterClockWise, and the input contacts CCWL or CWL is the origin reference point. When origin point – return position is accomplished, input contacts CCWL or CWL become extreme function. When this function is used, Pn365.1 can not be set 1 or 2. Attention: Cn002.1(Contact assistant function – input contact CCWL and CWL function selection) must be set 0.				
2	After zero-point-return operates, the Motor searches the origin in first stage of speed ClockWise , and the input contact ORG (external sensor point input point) will be the origin reference point. If Pn365.1=2 , it directly searches the closest input contact ORG 's edge above to be the machinery origin point without origin reference point. And it stops in compliance with Pn365.3 .				

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chap.
Pn365.0 	After Zero Point Return operates, the Setting of ZeroPoint Direction Searching and Zero Reference.	0	X	0 5	Pi Pe	5-4-8
	Setting	Explanation				
	3	After zero-point-return operates, the Motor searches the origin in first stage of speed CounterClockWise , and the input contact ORG (external sensor point input point) will be the origin reference point. If Pn365.1=2 , it directly searches the closest input contact ORG 's edge above to be the machinery origin point without origin reference point. And it stops in compliance with Pn365.3 .				
4	After origin point-return operates, the Motor searches the origin in first stage of speed ClockWise . It searches directly the closest Z phase origin without origin reference point. When this function is used, Pn365.1=2 must be set.(Searching the Z phase to be the machinery origin and stopping in compliance with Pn365.3)					

	5	After origin point-return operates, the Motor searches the origin in first stage of speed CounterClockWise . It searches directly the closest Z phase origin without origin reference point. When this function is used, Pn365.1=2 must be set. (Searching the Z phase to be the machinery origin and stopping in compliance with Pn365.3)				
Pn365.1 	After finding Origin Reference Point, the Settings of Move Method of searching machinery origin		0	X	0	 2
	Setting	Explanation				
	0	After finding origin reference point, the motor turns back to search the closest Z Phase with 2 nd stage speed to be the machinery origin, and stops in compliance with Pn365.3 .				
	1	After finding origin reference point, the motor continues forward to search the closest Z Phase with 2 nd stage speed to be the machinery origin, and stops in compliance with Pn365.3				



Parameter	Name & Function		Default	Unit	Setting Range	Control Mode	Chap.
Pn365.1 	After finding Origin Reference Point, the Settings of Move Method of searching machinery origin		0	X	0 2	Pi Pe	5-4-8
	Setting	Explanation					
	2	When Pn365.0=2 or 3 , using input contact ORG's upper edge to be machinery origin, then stops in compliance with Pn365.3 . When Pn365.0=4 or 5 , using Z Phase to be the machinery origin, and stops in compliance with Pn365.3 .					
Pn365.2 	Origin Return Mode Setting		0	X	0 2		
	Setting	Explanation					
	0	Turn off the Origin Return Function					
	1	After the power is ON, the function operates only when the first Servo ON. When the function is not needed to operate during servo system works, this mode can be used to abridge a input contact which is used to operate the origin return function.					

	2	Input contact SHOME triggers origin return function, and SHOME can be operated anytime in position mode.					
Pn365.3 	The Setting of Stop after Finding Machinery Origin		0	X	0		
	Setting	Explanation			1		
	0	After finding the signal of machinery origin, record this position to be machinery origin (Un-14 Encoder feedback rotation count and Un-15 Encoder feedback pulse number are both 0), motor decelerates and stop, then the 2 nd stage speed turns back to machinery origin position.					
	1	After finding the signal of machinery origin, record this position to be machinery origin (Un-14 Encoder feedback rotation count and Un-15 Encoder feedback pulse number are both 0), motor decelerates and stop.					
Pn366	Machine Zero Point Return – 1st stage – High Speed		100	rpm	0	Pi	5-4-8
	Setting of machine zero point return – 1 st stage move speed				 2000	Pe	
Pn367	Machine Zero Point Return – 2nd stage – Low Speed		50	rpm	0	Pi	5-4-8
	Setting of machine zero point return – 2 nd stage move speed				 500	Pe	
Parameter	Name & Function		Default	Unit	Setting Range	Control Mode	Chap.
Pn368	Machine Zero Point Return Off-Set Rotate Number		0	rev	-30000	Pi	5-4-8
	After the motor return to the machine zero point in compliance with Pn365 (Machine Zero Point Return Mode), it will again take the Pn368 (Machine Zero Point Return Off-Set Rotate Number) AND Pn369 (Machine Zero Point Return Off-Set Pulse number) to its new machine zero point.				 30000	Pe	
Pn369	Zero Point Return OFF-Set Pulse Number		0	pulse	-32767	Pi	5-4-8
	Zero Point Return OFF-Set Position = Pn368(Rotate Number) x Number of Encoder Pulse per Rotation x 4 + Pn369(Pulse Number)				 32767	Pe	

Prompt-Parameter


Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chap.
◆ qn401	Speed Loop Gain 1	40	Hz	10 450	Pi Pe S	5-3-8 5-5
	Speed Loop Gain decides directly the Speed Control Loop response bandwidth. If there is no vibration or noise in mechanical system, more speed loop gain value it increases, faster the speed response operates. If Cn025 is correctly set, speed loop bandwidth is equal to speed loop gain.					
◆ qn402	Speed Loop Integration Time Constant 1	100	x0.2 ms	1 500	Pi Pe S	5-3-8 5-5
	Speed control loop plus integration component can eliminate the speed error and responses quickly tiny speed change. Generally, If there is no vibration or noise in mechanical system, lower speed loop integration time constant it decreases, higher the system rigidity it increases. Using the formula below to get the speed loop integration time constant: $SpeedLoopIntegrationTimeConstant \geq 5 \times \frac{1}{2\pi \times SpeedLoopGain}$					


سازنده انواع ماشین آلات صنعتی و ماشین مخصوص

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chap.
◆ qn403	Speed Loop Gain 2	40	Hz	10 450	Pi Pe S	5-3-8 5-5
	Please refer to qn401					
◆ qn404	Speed Loop Integration Time Constant 2	100	x0.2 ms	1 500	Pi Pe S	5-3-8 5-5
	Please refer to qn402					
◆ qn405	Position Loop Gain 1	40	1/s	1 450	Pi Pe	5-4-6 5-5
	If there is no vibration or noise in mechanical system, increasing position loop gain value can increase the response-speed and decrease position fixing. Generally, Position loop bandwidth can not be higher than speed loop bandwidth. Here is the suggested formula: $PositionLoopGain \leq 2\pi \times \frac{SpeedLoopGain}{5}$					

◆ qn406	Position Loop Gain 2	40	1/s	1	Pi Pe	5-4-6 5-5
	Please refer to qn405			 450		
◆ qn407	Position Loop Feed Forward Gain	0	%	0	Pi Pe	5-4-6 5-5
	It can decrease the fellow up error of position control and increase response speed. If feed forward gain value is too high, it could cause speed overshooting and re-ON and OFF of INP output contacts (position complete signal).			 100		

Multi-Function Contacts Parameter

Parameter	Name & Function		Default	Unit	Setting Range	Control Mode	Chap.
★Hn501.0	DI-1		01	X	01	ALL	5-6-1
★Hn501.1	Setting	Explanation			 26		
		Signal					
		Functions					
	01	SON Servo ON					
	02	ALRS Alarm Eliminated					
	03	PCNT PI/P switch					
	04	CCWL CCW drive limit					
	05	CWL CW drive limit					
	06	TLMT External Torque limit					
	07	CLR Pulse Error value Eliminated					
	08	LOK Servo Lock					
	09	EMC Emergency Stop					
	10	SPD1 Internal Speed Command 1					
	11	SPD2 Internal Speed Command 2					
	12	MDC Control Mode Switch					
	13	INH Position Command Limit					
	14	SPDINV Speed Inverse Command					
	15	G-SEL Gain Selection					
	16	GN1 Electronic Gear Numerator 1					
	17	GN2 Electronic Gear Numerator 2					
	18	PTRG Internal Position Command ON					
	19	PHOLD Internal Position Command Stop					
	20	SHOME HOME					
	21	ORG External reference Home					



	22	POS1	Internal Position Command 1				
	23	POS2	Internal Position Command 2				
	24	POS3	Internal Position Command 3				
	25	POS4	Internal Position Command 4				
	26	TRQINV	Torque Inverse Command				
★Hn501.2 	DI-1 voltage level			0	X	0	
	Setting	Explanatoin					
	0	When DI-1 is low voltage level (close loop with IG24), it woks.				1	
	1	When DI-1 is high voltage level (open loop with IG24), it works.					

Attention: DI-1~DI-13 may repeat, and these repeat's voltage level must be the same, otherwise, AL-07 operates (input/output contacts functions alarm)

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chap.
★Hn502	DI-2	002	X	001	ALL	5-6-1
	Please refer to Hn501			 126		
★Hn503	DI-3	003	X	001	ALL	5-6-1
	Please refer to Hn501			 126		
★Hn504	DI-4	104	X	001	ALL	5-6-1
	Please refer to Hn501			 126		
★Hn505	DI-5	105	X	001	ALL	5-6-1
	Please refer to Hn501			 126		
★Hn506	DI-6	006	X	001	ALL	5-6-1
	Please refer to Hn501			 126		
★Hn507	DI-7	007	X	001	ALL	5-6-1
	Please refer to Hn501			 126		
★Hn508	DI-8	008	X	001	ALL	5-6-1
	Please refer to Hn501			 126		
★Hn509	DI-9	009	X		ALL	5-6-1

	Plearse refer to Hn501			001 126		
★Hn510	DI-10	010	X	001 126	ALL	5-6-1
	Plearse refer to Hn501					
★Hn511	DI-11	011	X	001 126	ALL	5-6-1
	Plearse refer to Hn501					
★Hn512	DI-12	012	X	001 126	ALL	5-6-1
	Plearse refer to Hn501					
★Hn513	DI-13	014	X	001 126	ALL	5-6-1
	Plearse refer to Hn501					

Attention: DI-1~DI-13 may repeat, and these repeat's voltage level must be the same, otherwise, AL-07 operates (input/output contacts functions alarm)

Parameter	Name & Function		Default	Unit	Setting Range	Control Mode	Chap.
★Hn514.0	DO-1		01	X	01 07	ALL	5-6-1
★Hn514.1	Setting	Explanation					
	Signal	Functions					
	01	RDY Servo Ready					
	02	ALM Alarm					
	03	ZS Zero Speed					
	04	BI Brake					
	05	INS Speed achieve					
	06	INP Location Fixed Completed					
	07	HOME Home					
★Hn514.2	DO-1		0	X	0 1		
	Setting	Explanation					
	0	When it operates, the contact is low electric potential. (Close loop with IG24).					
	1	When it operates, the contact is high electric potential. (Open loop with IG24).					
★Hn515	DO-2		002	X	001 107	ALL	5-6-1
	Plearse refer to Hn514						

★Hn516	DO-3	003	X	001 107	ALL	5-6-1
	Please refer to Hn514					
★Hn517	DO-4	006	X	001 107	ALL	5-6-1
	Please refer to Hn514					

Attention: DO-1~DO-4 can not repeat, and these repeat's voltage level must be the same, otherwise, AL-07 operates (input/output contacts functions alarm)

Display Parameter

Parameter	Display	Unit	Explanation
Un-01	Actual Motor Speed	rpm	Ex: If 120 displayed, it means 120 rpm.
Un-02	Actual Motor Torque	%	Ratio Torque percent. Ex: if 20 displayed, it means 20% of ratio torque.
Un-03	Regenerated Load Ratio	%	Average regenerated output percent
Un-04	Actual Load Ratio	%	Average output percent
Un-05	Maximum Load Ratio	%	Maximum value which is ever shown in actual load ratio
Un-06	Speed Command	rpm	Ex: If 120 displayed, it means current speed command is 120 rpm
Un-07	Position Error Value	pulse	The different departure value between position command and position feed-back
Un-08	Position Feed-back Value	pulse	The comulate value of Encoder
Un-09	External Voltage Command	V	Ex: If 5.25 displayed, it means external voltage command is 5.25V.
Un-10	(Vdc Bus) Main Loop Voltage	V	Ex: If 310 is displayed, it means main loop voltage is 310V

Un-11	External Spped Limit Command Value	rpm	Ex: If 2000 is displayed, it means current external spped limit command is 2000 rpm.
Un-12	External CCW Torque Limit Command Value	%	Ex: If 100 is displayed, it means current external CCW torque limit command is 100%.
Un-13	External CW Torque LimitCommand Value	%	Ex: If 100 is displayed, it means current external CW torque limit command is 100%.
Un-14	Motor Feed-back Rotate Number (Absolute Value)	rev	After power ON, it shows Motor's Rotate Value in Ablolute Value.
Un-15	MotorFeedBack–PulseNumber/1 Rotate(Absolute Value)	pulse	After power ON, it shows the pluse number of Motor's 1 rotate.
Un-16	PulseCommand–RotateNumber (Absolute Value)	rev	After power ON, it shows the pluse command input rotate number in absolute value.
Un-17	PulseCommand-Pulse Number /1 Rotate(Absolute Value)	pulse	After power ON, it shows pulse command input – pulse number of 1 rotate.
Un-18	Torque Command	%	Shown by ratio torque percent Ex: If 50 is displayed, it means current motor torque command is 50% of ratio torque.
Un-19	Load Inertia Ratio	x0.1	When Cn002.2=0 (without auto-gain-adjust function), it displays the default load inertia ratio of Cn025 When Cn002.2=1 (keep on using auto-gain-adjust function), it displays current estimated load inertia ratio.


Diagnosis Parameter

WWW.CNCREZA.IR


Parameter	Name & Function	Chap.
dn-01	Current Control Mode Display	3-2-2
dn-02	Output Contacts Signal	
dn-03	Input Contacts Signal	
dn-04	Software Edition	
dn-05	JOG Mode Operation	
dn-06	Resume	
dn-07	External Voltage Command OffSet-Value Auto-adjust.	
dn-08	Show Model Type	

Chapter 8 Troubleshooting

8-1 Fault Status Display Operation

When the AC servo drive has a fault, the LED display will show . Users please observe the following sections' explanation to repair the fault, then follow up the normal operation procedure to using the AC servo drive. If you still can not repair the fault, please contact your local TECO sales representative for assistance.

Fault Status Display :



For the information of fault code, please refer to next section. Refer to the example, the fault code is 01. (Undervoltage)

The AC servo drive also provide the fault record history for users. The explanation is listed in the following table.


Fault Record History









Display	Explanation
AL - XX	The Latest Fault Record.
A1 - XX	Previous First Time Fault Record.
A2 - XX	Previous Second Times Fault Record.
A3 - XX	Previous Third Times Fault Record.
A4 - XX	Previous Fourth Times Fault Record.
A5 - XX	Previous Fifth Times Fault Record.
A6 - XX	Previous Sixth Times Fault Record.
A7 - XX	Previous Seventh Times Fault Record.
A8 - XX	Previous Eighth Times Fault Record.
A9 - XX	Previous Ninth Times Fault Record.

Note : XX means the Fault Code.

Example :

Please observe the following steps to refer to the fault record history.

Step	Key	LED Display	Explanation
1	Turn the Power On		When the power is applied to the AC servo drive, the LED display will show Status Display Mode.

2			Pressing MODE key twice can enter into Fault Record History Mode.
3			Pressing UP arrow key once can enter into Previous First Time Fault Record. Refer to the example, the fault code is 03. (Overload)
4			Pressing UP arrow key once can enter into Previous Senond Times Fault Record. Refer to the example, the fault code is 01. (Undervoltage)
5			Pressing MODE key once can enter into System Parameter Mode.



8-2 Fault Definition and Corrective Actions

Fault Code	Fault Name and Definition	Corrective Actions	Clearing Method	Fault Status Digital Output			
				CN1-25 BB/A3	CN1-24 ST/A2	CN1-23 PC/A1	CN1-22 LM/A0
00	Normal	—	—	If there is no Alarm, CN1-22~CN1-25 operates in accordance with default function. Please refer to 2-2-1 .			
01	Undervoltage	Use voltmeter to check whether the input voltage is within the specified limit. If it can not be solved, there may be failure inside the Driver. *This message appears when power flow into driver.	Turn ALRS(DI) ON	1	1	1	0
	The main circuit voltage is below its minimum specified value. (190Vac)						
02	Overvoltage (Regeneration error)	1、 Use voltmeter to check whether the input voltage is within the specified limit. 2、 Check the Parameter Cn012 if be set by regulation. 3、 This signal appear when operation: To extend ac/deceleration time or reduce load ratio in permitted range. Otherwise, it need extra regeneration resistance. (Please contact to distributors or manufacturers)	Turn ALRS(DI) ON	1	1	0	1
	1、 The main circuit voltage has exceeded its maximum allowable value. (410Vac) 2、 Regeneration voltage is too high.						
03	Overload		Turn	1	1	0	0

<p>The drive has exceeded its rated load during continuous operation. If 2 times over then ratio load, alarm occurs after 10sec.</p>	<ol style="list-style-type: none"> 1、 Check Motor terminal(U、 V、 W) and Encolder. 2、 Adjusting the Driver gain, once gain is not correctly adjusted, it would cause motor co-vibration and large current to let motor over load. 3、 To extend ac/deceleration time or reduce load ratio in permitted range. <p>* This signal appears usually during the process. If alarm, please check "1".</p>	<p>ALRS(DI) ON</p>				
--	---	------------------------	--	--	--	--

Fault Code	Fault Name and Definition	Corrective Actions	Clearing Method	Fault Status Digital Output			
				CN1-25 BB/A3	CN1-24 ST/A2	CN1-23 PC/A1	CN1-22 LM/A0
04	<p>Output transistor abnormal</p> <p>Driver's Temperature, current, voltage are over protective range. Output transistor abnormal alarm.</p>	<ol style="list-style-type: none"> 1、 Check the motor terminal line(U、 V、 W) and encoder line. And please refer to the diagram in Chapter 2 to combine external power. 2、 Tern off the power, and turn on again after 30 min. If the alarm still exists, there may be the error or noise interference of Output transistor abnormal inside. 	<p>Reset Power Supply</p>	1	0	1	1
05	<p>EncolderABZ-phase signal abnormal</p> <p>Motor's encolder breakdown or encoder line not well connected.</p>	<ol style="list-style-type: none"> 1.Check the motor's encoder line if connect to the driver 2.Check the encoder if short circuit, loose solder or break. 3.Check the encoder signal terminal CN2-1 and CN2-2. 	<p>Reset Power Supply</p>	1	0	1	0
06	<p>Encoder UVW-phase signal error</p>		<p>Reset Power Supply</p>	1	0	0	1

	Motor's encoder breakdown or encoder line not well connected.						
07	Multi-function point planning error	<p>1. Check the parameter Hn501~Hn513-input point planning if match: DI-1~DI-13 connector may repeat, but the action voltage level of the repeat-function connector must the same.</p> <p>2. Check if the parameter: Hn514~Hn517 output contacts function match: DO-1~DO-4contact point can not repeat.</p>	Reset Power Supply	1	0	0	0
	Input/output point function planning error.						

Fault Code	Fault Name and Definition	Corrective Actions	Clearing Method	Fault Status Digital Output			
				CN1-25 BB/A3	CN1-24 ST/A2	CN1-23 PC/A1	CN1-22 LM/A0
08	Memory Error Parameter input error	Take all joint apart, when alarm during power ON, the driver need be changed.	Reset Power Supply	0	1	1	1
09	Emergent Stop When the input contact point EMC operates then alarm appears. *High electric potential or low electric potential, please refer to 5-6-1 to set.	<p>1. Stop the input contact point EMC's operation.</p> <p>2. Inside of the driver is interference. Please refer to Chpther 2 : "The diagram of motor and power and control" & "Diagram of signal and standard wiring."</p>	Turn ALRS(DI) ON	0	1	1	0
10	Motor over-current		Turn ALRS(DI)	0	1	0	1



	Motor's current value is 4 times then motor's ratio current.	<ol style="list-style-type: none"> 1. Check if the motor wiring (U, V, W) and encoder wiring correct or not. 2. Inside of the driver is interference. Please refer to Chapter 2: "The standard wiring diagram of motor and power to connect outside power." 	ON				
11	<p>Over Position error value</p> <p>The difference of Pulse command and encoder feedback pulse is over the default of Pn308 or Pn309.</p>	<ol style="list-style-type: none"> 1. Increase the position loop gain (Pn310 及 Pn311) value. 2. Increase the position loop front back gain (Pn307) value to enhance the reaction speed of motor. 3. Extend the time of ac/deceleration or reduce load inertia in available range. 4. Check if the motor wiring (U, V, W) is completed. 	<p>Turn ALRS(DI) ON</p>	0	1	0	0

Fault Code	Fault Name and Definition	Corrective Actions	Clearing Method	Fault Status Digital Output			
				CN1-25 BB/A3	CN1-24 ST/A2	CN1-23 PC/A1	CN1-22 LM/A0
12	<p>Motor overspeed</p> <p>Motor's speed is 1.5 times then motor's inertia speed.</p>	<ol style="list-style-type: none"> 1. Reduce the speed of enter command. 2. Electric gear ratio's incorrect setting; please check related setting. 3. Adjust speed loop gain appropriately (Sn211 & Sn213) to accelerate the motor's reaction speed. 	<p>Turn ALRS(DI) ON</p>	0	0	1	1
13	CPU Error		Reset	0	0	1	0

	Control system can not normally operate.	Turn off the power. Turn on again after 30min. If error alarm still exists, it might be the interference of inside of the driver. Please refer to the chapter 2: "motor and power's standard diagram to connect outside power.	Power Supply				
14	Dirve forbid error When input contact point CCWL & CWL operate at the same time and alarm occur. *High electric potential or low electric potential, please refer to 5-6-1 to set.	1. Stop the input contact point CCWL or CWL action. 2. Inside of the driver is interference. Please refer to Chapter 2 : "The diagram of motor and power and control" & "Diagram of signal and standard wiring."	Turn ALRS(DI) ON	0	0	0	1
15	Driver overheat Power transistor's temperature is over 90 degree Celsius.	Re-overload will cause driver overheat, please correct the rotation method.	Turn ALRS(DI) ON	0	0	0	0

Explanation of Error Alarm Elimination :

1. Reset: Use the 2 suggestions below to eliminate error alarm:

- (a) Reset the input contact point: After error is eliminated, stop input contact **SON** operation (it means clear Servo ON), then enter contact point **ALRS** action. Then the error alarm can be eliminated and let the driver operate normally. High electric potential or low electric potential, please refer to **5-6-1** to set
- (b) Key reset: After error is eliminated, stop input contact SON operation(it means clear Servo ON), then press the button  and  at the same time, then the error alarm can be eliminated and let the driver operate normally.

2. Power reset: After error is eliminated, reset the Servo (turn off the power and re-input the power), then the error alarm can be eliminated and let the driver work normally.

Suggest strongly when using power reset to eliminate error alarm, stop input contact Son operation (it means clear Servo ON).

※ **Attention: Befor error alarm is eliminated, it need to confirm if the controller release command to the driver. Otherwise it might cause Motor Overshooting.**

